

10.3.5.5. ActiveDatasetTimestamp Attribute

This attribute SHALL be null if the Thread Border Router has no dataset configured, otherwise it SHALL be the timestamp value extracted from the Active Dataset value configured by the Thread Node to which the border router is connected. This attribute SHALL be updated when a new Active dataset is configured on the Thread network to which the border router is connected.

10.3.5.6. PendingDatasetTimestamp Attribute

This attribute SHALL be null if the Thread Border Router has no Pending dataset configured, otherwise it SHALL be the timestamp value extracted from the Pending Dataset value configured by the Thread Node to which the border router is connected. This attribute SHALL be updated when a new Pending dataset is configured on the Thread network to which the border router is connected.

10.3.6. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	GetActive-DatasetRequest	client ⇒ server	DatasetResponse	M	M
0x01	GetPending-DatasetRequest	client ⇒ server	DatasetResponse	M	M
0x02	DatasetResponse	client ⇐ server	N		M
0x03	SetActive-DatasetRequest	client ⇒ server	Y	M T	M
0x04	SetPending-DatasetRequest	client ⇒ server	Y	M T	PC

10.3.6.1. GetActiveDatasetRequest Command

This command SHALL be used to request the active operational dataset of the Thread network to which the border router is connected.

If the command is not executed via a CASE session, the command SHALL fail with a status code of `UNSUPPORTED_ACCESS`.

If an internal error occurs, then this command SHALL fail with a `FAILURE` status code sent back to the initiator.

Otherwise, this SHALL generate a `DatasetResponse` command.