

10.3.6.2. GetPendingDatasetRequest Command

This command SHALL be used to request the pending dataset of the Thread network to which the border router is connected.

If the command is not executed via a CASE session, the command SHALL fail with a status code of `UNSUPPORTED_ACCESS`.

If an internal error occurs, then this command SHALL fail with a `FAILURE` status code sent back to the initiator.

Otherwise, this SHALL generate a `DatasetResponse` command.

10.3.6.3. DatasetResponse Command

This command is sent in response to `GetActiveDatasetRequest` or `GetPendingDatasetRequest` command. The data for this command SHALL be as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Dataset	octstr	max 254			M

10.3.6.3.1. Dataset field

If no dataset (active or pending as requested) is configured, this field SHALL be set to empty.

Otherwise, this field SHALL contain the active or pending dataset of the Thread network to which the Border Router is connected as an octet string containing the raw Thread TLV value of the dataset, as defined in the [Thread specification](#).

10.3.6.4. SetActiveDatasetRequest Command

This command SHALL be used to set the active Dataset of the Thread network to which the Border Router is connected, when there is no active dataset already.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Active-Dataset	octstr	max 254			M
1	Bread-crumbs	uint64	all			O

10.3.6.4.1. ActiveDataset Field

This field SHALL contain the active dataset to set of the Thread network to configure in the Border Router as an octet string containing the raw Thread TLV value of the dataset, as defined in the [Thread specification](#).