

10.3.6.4.2. Breadcrumb Field

See Breadcrumb Attribute section of General Commissioning Cluster in [\[MatterCore\]](#) for usage.

10.3.6.4.3. Effect on receipt

If the command is not executed via a CASE session, the command SHALL fail with a status code of `UNSUPPORTED_ACCESS`.

If this command is received without a Fail Safe Context (see `ArmFailSafe` Command of General Commissioning Cluster in [\[MatterCore\]](#)), then this command SHALL fail with a `FAILSAFE_REQUIRED` status code sent back to the initiator.

If any of the parameters in the `ActiveDataset` is invalid, the command SHALL fail with a status code of `INVALID_COMMAND`.

If this command is invoked when the `ActiveDatasetTimestamp` attribute is not null, the command SHALL fail with a status code of `INVALID_IN_STATE`. The administrator MAY use the `SetPendingDatasetRequest` command to modify the future active dataset.

If this command is invoked and the `ActiveDatasetTimestamp` attribute is null, the Thread Border Router SHALL configure and activate its active dataset using the `ActiveDataset` parameter.

The activation process SHALL be a time-bound process that completes before expiration of a fail-safe timer. The fail-safe timer SHALL be set at the beginning of the activation process.

If the fail-safe timer expires prior to activation process completion, the command SHALL respond with `TIMEOUT`, and the Border Router state SHALL revert to the configuration set prior to the fail-safe timer being armed, see `ArmFailSafe` Command of General Commissioning Cluster in [\[MatterCore\]](#).

After successfully creating or joining a Thread network with the new active dataset, the `InterfaceEnabled` attribute SHALL be updated to `TRUE`, indicating that the associated Thread Interface is active and functioning. The `ActiveDatasetTimestamp` attribute SHALL be updated with the `ActiveDataset` timestamp. If the `Adjacent Infrastructure Link` of the Border Router is connected, then the device SHOULD also enable and operate Thread Border Routing functionality using the Thread and `Adjacent Infrastructure Link` interfaces.

If this command is received during the activation process triggered by a previous `SetActiveDatasetRequest` command, then the command SHALL fail with a status code of `BUSY`.

10.3.6.5. SetPendingDatasetRequest Command

This command SHALL be used to set or update the pending Dataset of the Thread network to which the Border Router is connected, if the Border Router supports [PAN Change](#).

If the command is not executed via a CASE session, the command SHALL fail with a status code of `UNSUPPORTED_ACCESS`.