

11.3.5.3.1. Pan Field

This field SHALL indicate the mechanical pan value in angular degrees of angle. A zero value SHALL indicate the home position horizontal reference for the direction of view of the camera. A negative value SHALL indicate a leftward rotation of the camera about the vertical axis of the camera coordinate system. A positive value SHALL indicate a rightward rotation of the camera about the vertical axis of the camera coordinate system.

11.3.5.3.2. Tilt Field

This field SHALL indicate the mechanical tilt value in angular degrees of angle. A zero value SHALL indicate a vertical reference for the direction of view of the camera. A negative value SHALL indicate a downward rotation of the camera about the horizontal axis of the camera coordinate system. A positive value SHALL indicate an upward rotation of the camera about the horizontal axis of the camera coordinate system.

11.3.5.3.3. Zoom Field

This field SHALL indicate the zoom value to use. A value of 1 SHALL indicate the widest possible optical field of view. A value of ZoomMax SHALL indicate the narrowest possible field of optical view.

11.3.5.4. MPTZPresetStruct Type

This type is used to save a preset location for mechanical pan, tilt and zoom.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	PresetID	uint8	1 to MaxP-resets				M
1	Name	string	max 32				M
2	Settings	MPTZStruct					M

11.3.5.4.1. PresetID Field

This SHALL be derived from uint8 and represents the ID for a saved set of preset values for mechanical pan, tilt and zoom.

11.3.5.4.2. Name Field

The SHALL be a string representing the name of the Preset.

11.3.5.4.3. Settings Field

This SHALL hold the mechanical pan, tilt and zoom values.