

11.3.7.1. MPTZSetPosition Command

This command SHALL move the camera to the provided values for pan, tilt, and zoom in the mechanical PTZ. The data for this command SHALL be as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Pan	int16	PanMin to PanMax			[MPAN].b+
1	Tilt	int16	TiltMin to TiltMax			[MTILT].b+
2	Zoom	uint8	1 to Zoom-Max			[MZoom].b+

11.3.7.1.1. Pan Field

This field SHALL indicate the absolute pan value in angular degrees.

11.3.7.1.2. Tilt Field

This field SHALL indicate the absolute tilt value in angular degrees.

11.3.7.1.3. Zoom Field

This field SHALL indicate the absolute zoom value.

11.3.7.1.4. Effect on Receipt

The process below SHALL be followed by the camera when receiving this command:

- If the camera is already engaged in a command that results in a physical move, or if the camera is otherwise unable to apply the changes at the time of receipt:
 - Fail the command with the status code BUSY, and end processing with no other side effects.
- Initiate movement of the camera to the new values of Pan, Tilt, or Zoom.
- Set [MovementState](#) to [Moving](#).
- Respond with the status code SUCCESS.
- Once the camera has completed the physical movement to the target values:
 - Set [MovementState](#) to [Idle](#).
 - Update the values in [MptzPosition](#) to the values as received. Any values that are not present in this command's fields SHALL NOT be modified.

11.3.7.2. MPTZRelativeMove Command

This command SHALL move the camera by the delta values relative to the currently defined position. The data for this command SHALL be as follows: