

11.7.9.2.1. TransportConfiguration Field

This field SHALL be a [TransportConfigurationStruct](#) representing the newly allocated transport. If automatic stream selection was requested, the used Stream ID fields will be present in the TransportOptions field.

11.7.9.3. DeallocatePushTransport Command

This command SHALL be generated to request the Node deallocates the specified transport.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ConnectionID	PushTransportConnectionID	0 to 65534			M

11.7.9.3.1. ConnectionID Field

This field SHALL be a [PushTransportConnectionID](#) representing the allocated transport to deallocate.

11.7.9.3.2. Effect on Receipt

The following process SHALL be followed when the server receives this command:

- If no entry can be found for the passed in *ConnectionID* in the [CurrentConnections](#) list attribute:
 - Fail the command with the status code NOT_FOUND, and end processing with no other side effects.
- If the associated fabric of that entry is not the accessing fabric:
 - Fail the command with the status code NOT_FOUND, and end processing with no other side effects.
- If the transport is currently uploading:
 - Fail the command with the status code BUSY, and end processing with no other side effects.
- Remove that entry from the [CurrentConnections](#) list attribute.
- Using the [TLSEndpointID](#) field of that entry, decrement the ReferenceCount field of the matching EndpointID entry in the TLS Client Management Cluster's ProvisionedEndpoints list.
- Deallocate the transport using the passed in *ConnectionID*.

11.7.9.4. ModifyPushTransport Command

This command is used to request the Node modifies the configuration of the specified push transport.