

- Else if the passed in *TransportStatus* field is set to Active:
 - Enable transmissions on the transport identified by the id.
 - If all [Privacy Related attributes](#) are False:
 - If the transport's trigger type is [Continuous](#):
 - Begin transmission immediately.
 - Else if the transport's trigger type is [Command](#) or [Motion](#), and the underlying trigger is currently active and still within the [Time Control Bounds](#):
 - Begin transmission immediately.
- Set [TransportStatus](#) of the transport identified by the id to the value in the *TransportStatus* field of this command.

11.7.9.6. ManuallyTriggerTransport Command

This command SHALL be generated to request the Node to manually start the specified push transport.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ConnectionID	PushTransportConnectionID	0 to 65534			M
1	ActivationReason	TriggerActivationReasonEnum	all			M
2	TimeControl	TransportMotionTriggerTimeControlStruct				O
3	UserDefined	octstr	max 256			[METADATA]

11.7.9.6.1. ConnectionID Field

This field SHALL be a [PushTransportConnectionID](#) representing the push transport to start or stop.

11.7.9.6.2. ActivationReason Field

This field SHALL provide information as to why the transport was started or stopped.

11.7.9.6.3. TimeControl Field

This field SHALL be a struct of type [TransportMotionTriggerTimeControlStruct](#), but the *BlindDuration* field SHALL be ignored.