

12.1.6.5. Other Device Operations

The RVC Run Mode cluster's SupportedModes attribute list MAY include modes that have neither the Idle nor the Cleaning mode tags, for example the Mapping mode tag.

Starting, pausing, resuming and stopping these other operations have similar preconditions, actions and side effects as those described above for the cleaning operations.

12.1.6.6. Device Error Handling

When in an error condition, as indicated by the RVC Operational State cluster's OperationalState attribute, out-of-band action will be required to clear that condition.

If an error occurs while the device operates, such as while cleaning or while mapping, the device MAY pause and set the RVC Operational State cluster's OperationalState attribute to Error. If the operation can be resumed after the error is cleared, the device SHALL set the RVC Operational State cluster's OperationalState attribute to Paused and MAY be resumed either via a Resume command, if implemented, or by out-of-band actions, such as by pressing the robot's physical buttons.

Note that certain errors may not pause or disable the device. For example, a dual-function device, that can both vacuum and mop, may report a WaterTankEmpty error but may still be able to be used if it has a vacuum only cleaning mode. Certain modes of the RVC Run Mode and the RVC Cleaning Mode clusters MAY become unavailable and the ChangeToModeResponse commands' Status-Code SHALL be set to InvalidInMode, when attempting to switch to those modes.