

```

"musiccast_network":{
    "ready":true,
    "device_type":"root",
    "child_num":1,
    "initial_join_running":false
    "extend_1_band":"",
    "wlan1_ch":0,
    "dfs":[
        false,
        0
    ],
    "mac_address":{
        "wired_lan":"00A0DE012345",
        "wireless_lan":"78A501012345",
        "wireless_direct":"78A501012346"
    },
    "vtuner_id":"00A0DE012345",
    "airplay_pin":"abc123",
}

```

#### 4.4. setWiredLan

For setting Wired Network. Network connection is switched to wired by using this API. If no parameter is specified, current parameter is used. If set parameter is incomplete, it is possible not to provide network availability.

##### Request Parameters

name	Type	required	description
dhcp	string	no	Specifies DHCP setting
ip_address	string	no	Specifies IP Address
subnet_mask	string	no	Specifies Subnet Mask
default_gateway	string	no	Specifies Default Gateway
dns_server_1	string	no	Specifies DNS Server 1
dns_server_2	string	no	Specifies DNS Server 2

URI	<BaseURL>/v1/system/setWiredLan
Method	POST
Example Request (URI)	http://{host}/YamahaExtendedControl/v1/system/setWiredLan
Example Request (json)	{     "dhcp":false,     "ip_address":"192.168.0.11",     "subnet_mask":"255.255.255.0",     "default_gateway":"192.168.0.1",     "dns_server_1":"192.168.0.1",     "dns_server_2":"0.0.0.0" }