

## 8.9.5.13 INTENSET1

Address offset: 0x314

## Enable interrupt

### 8.9.5.14 INTENCLR1

Address offset: 0x318

## Disable interrupt