

8.10.7.3 TASKS STOP

Address offset: 0x064

Stop the counter

8.10.7.4 TASKS CLEAR

Address offset: 0x068

Clear the counter

8.10.7.5 TASKS PWMSTART

Address offset: 0x06C

Start the PWM

8.10.7.6 TASKS PWMSTOP

Address offset: 0x070

Stop the PWM