

Enable or disable interrupt

5.6.1.11 INTENSET

Address offset: 0x304

Enable interrupt

5.6.1.12 INTENCLR

Address offset: 0x308

Disable interrupt