

### 9.6.6.1.13 RESET

Address offset: 0x520

## System reset request.

Only the enumerated values are supported, writing other values has unpredictable effect.

## 9.7 TAD — Trace and debug control

## Configuration interface for trace and debug

Please refer to the [Trace](#) section for more information about how to configure the trace and debug interface.

**Note:** When the trace port is enabled, all pins assigned to the trace port are acquired by the TAD peripheral and cannot be used for GPIO or other functions. This applies even when using the serial trace mode (SWO). See [Pin assignment chapter](#) for more information.

### 9.7.1 Registers

## Instances

Instance	Domain	Base address	TrustZone			Split access	Description
			Map	Att	DMA		
TAD : S	GLOBAL	0x50053000	US	S	NA	No	Trace and debug control
TAD : NS		0x40053000					