

#### **8.23.10.4.2.1 TASKS\_DMA.TX.START**

Address offset: 0x050

Starts operation using easyDMA to load the values. See peripheral description for operation using easyDMA.

#### **8.23.10.4.2.2 TASKS DMA.TX.STOP**

Address offset: 0x054

Stops operation using easyDMA. This does not trigger an END event.

### 8.23.10.5 SUBSCRIBE STOP

Address offset: 0x084

## Subscribe configuration for task STOP

## 8.23.10.6 SUBSCRIBE SUSPEND

Address offset: 0x08C

Subscribe configuration for task SUSPEND