Bit number				31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
ID				O N M L K J I H G F E D C B A
Reset 0x00000000				**0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0**

ID	R/W	Field	Value ID	Value	Description
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
E	RW W1S	LASTTX			Write '1' to enable interrupt for event LASTTX
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
F	RW W1S	DMARXEND			Write '1' to enable interrupt for event DMARXEND
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
G	RW W1S	DMARXREADY			Write '1' to enable interrupt for event DMARXREADY
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
H	RW W1S	DMARXBUSERROR			Write '1' to enable interrupt for event DMARXBUSERROR When this event is generated, the address which caused the error can be read from the BUSERRORADDRESS register.
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
I-L	RW W1S	DMARXMATCH[i] (i=0..3)			Write '1' to enable interrupt for event DMARXMATCH[i]
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
M	RW W1S	DMATXEND			Write '1' to enable interrupt for event DMATXEND
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
N	RW W1S	DMATXREADY			Write '1' to enable interrupt for event DMATXREADY
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled
O	RW W1S	DMATXBUSERROR			Write '1' to enable interrupt for event DMATXBUSERROR When this event is generated, the address which caused the error can be read from the BUSERRORADDRESS register.
			Set	1	Enable
			Disabled	0	Read: Disabled
			Enabled	1	Read: Enabled

8.23.10.24 INTENCLR

Address offset: 0x308

Disable interrupt