

## 28.1 Red symbols

Red symbols indicate an error condition that requires immediate intervention.

	The coolant temperature warning lamp lights up red – The coolant temperature has reached a critical value.
	The oil pressure warning lamp lights up red – The oil pressure is too low. Stop immediately, taking care not to endanger yourself or other road users in the process, and switch off the engine.

## 28.2 Yellow and orange symbols

Yellow and orange symbols indicate an error condition that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

	ABS warning lamp lights up/flashes yellow – ABS is not active. The ABS warning lamp also lights up if a malfunction is detected.
	Fuel level warning lamp lights up orange – The fuel level has reached the reserve mark.
	Malfunction indicator lamp lights up/flashes orange – The OBD has detected a malfunction in the vehicle electronics. Come safely to a halt, and contact an authorized Husqvarna Motorcycles workshop.

## 28.3 Green and blue symbols

Green and blue symbols reflect information.

	The high beam indicator lamp lights up blue – The high beam is switched on.
	The idle indicator lamp lights up green – The transmission is in neutral.
	Turn signal indicator lamp flashes green – The turn signal is switched on.

# INDEX

<b>1</b>	
<b>12-V battery</b>	
installing .....	88
removing .....	87
<b>12-V battery</b>	
charging .....	89
<b>A</b>	
<b>ABS</b>	67
<b>ABS fuses</b>	
changing .....	91
<b>ACC1</b>	
front .....	98
<b>ACC2</b>	
front .....	98
<b>Accessories</b>	14
<b>Air filter</b>	
installing .....	58
removing .....	58
<b>Anti-lock braking system</b>	67
<b>Auxiliary substances</b>	14
<b>B</b>	
<b>Brake discs</b>	
checking .....	68
<b>Brake fluid</b>	
adding to front brake .....	69
adding to rear brake .....	75
<b>Brake fluid level</b>	
front brake, checking .....	69
rear brake, checking .....	74
<b>Brake lining retainers</b>	
of front brake, checking .....	70
of rear brake, checking .....	76
<b>Brake linings</b>	
changing on the front brake .....	71
changing on the rear brake .....	76
of front brake, checking .....	70
of rear brake, checking .....	76
<b>Brakes</b>	38
<b>Braking</b>	38
<b>Breakdown</b>	
towing .....	41
<b>C</b>	
<b>Capacity</b>	
coolant .....	103, 105, 125
engine oil .....	112, 125
fuel .....	42, 125
<b>Chain</b>	
checking .....	61
cleaning .....	59
dirt, checking for .....	59
<b>Chain guide</b>	
checking .....	61
setting .....	64
<b>Chain tension</b>	
adjusting .....	61
checking .....	60
<b>Changing the headlight bulb</b>	95
<b>Clutch</b>	
checking/correcting fluid level .....	65
<b>Clutch lever</b>	
basic position, adjusting .....	64
<b>Combination instrument</b>	
activation .....	26
adjusting .....	26
clock, setting .....	28
kilometers or miles, setting .....	28
messages .....	26
overview .....	26
service display, setting .....	29
<b>Coolant</b>	
antifreeze and coolant level, checking .....	100
changing .....	104
draining .....	102
level, checking .....	101
<b>Cooling system</b>	
filling/bleeding .....	103
<b>Customer service</b>	14
<b>D</b>	
<b>Diagnostics connector</b>	99
<b>E</b>	
<b>Emergency OFF switch</b>	20
<b>Engine</b>	
running in .....	32
<b>Engine guard</b>	
installing .....	66
removing .....	66
<b>Engine number</b>	18
<b>Engine oil</b>	
adding .....	112
changing .....	109
<b>Engine oil level</b>	
checking .....	109

<b>Engine sprocket</b>	.....	19
checking	.....	61
<b>Environment</b>	.....	12
<b>F</b>		
<b>Figures</b>	.....	14
<b>Foot brake lever</b>	.....	24
adjusting basic position	.....	74
free travel, checking	.....	73
<b>Fork</b>	.....	45
compression damping, adjusting	.....	45
dust boots, cleaning	.....	52
fork legs, bleeding	.....	52
offset	.....	45
rebound, adjusting	.....	46
<b>Fork offset</b>	.....	45
<b>Fork part number</b>	.....	18
<b>Fork protector</b>		
installing	.....	53
removing	.....	53
<b>Front fender</b>		
installing	.....	58
removing	.....	57
<b>Front wheel</b>		
installing	.....	80
removing	.....	79
<b>Fuel screen</b>		
changing	.....	108
<b>Fuel tank filler cap</b>		
closing	.....	23
opening	.....	22
<b>Fuel, oils, etc.</b>	.....	14
<b>Fuse</b>		
of individual electrical power consumers,		
changing	.....	93
<b>G</b>		
<b>Grab handles</b>	.....	23
<b>H</b>		
<b>Hand brake lever</b>	.....	19
basic position, adjusting	.....	68
<b>Handlebar position</b>	.....	49
adjusting	.....	49
<b>Headlight</b>		
range, adjusting	.....	97
setting, checking	.....	97
<b>Headlight mask with headlight</b>		
installing	.....	95
removing	.....	94
<b>Horn button</b>	.....	19
<b>I</b>		
<b>Ignition lock</b>	.....	21
<b>Implied warranty</b>	.....	14
<b>Intended use</b>	.....	6
<b>K</b>		
<b>Key number</b>	.....	17
<b>L</b>		
<b>Light switch</b>	.....	20
<b>Loading the vehicle</b>	.....	32
<b>Luggage</b>	.....	32
<b>M</b>		
<b>Main fuse</b>		
changing	.....	90
<b>Manufacturer warranty</b>	.....	14
<b>Misuse</b>	.....	6
<b>Motorcycle</b>		
cleaning	.....	114
lift stand, raising with	.....	51
lifting gear at rear, raising with	.....	51
removing from lift stand	.....	51
removing the rear from the lifting gear	.....	52
<b>O</b>		
<b>Oil filter</b>		
changing	.....	109
<b>Oil screens</b>		
cleaning	.....	109
<b>Overview of indicator lamps</b>	.....	22
<b>Owner's Manual</b>	.....	12
<b>P</b>		
<b>Parking</b>	.....	40
<b>Passenger foot pegs</b>	.....	24
<b>Position light lamp</b>		
changing	.....	96
<b>Preparing for use</b>		
advice on preparing for first use	.....	31
after storage	.....	118
checks and maintenance measures when		
preparing for use	.....	34
<b>Protective clothing</b>	.....	12
<b>R</b>		
<b>Rear hub damping rubbers</b>		
checking	.....	83
<b>Rear sprocket</b>		
checking	.....	61

# INDEX

<b>Rear wheel</b>	
installing . . . . .	81
removing . . . . .	80
<b>Refueling</b>	
fuel . . . . .	42
<b>Riding</b>	
36	
starting off . . . . .	36
<b>Riding mode</b>	
changing . . . . .	106
<b>Rubber grip</b>	
checking . . . . .	65
<b>S</b>	
<b>Safe operation</b>	
11	
<b>Seat</b>	
mounting . . . . .	55
removing . . . . .	55
unlocking . . . . .	23
<b>Service</b>	
14	
<b>Service schedule</b>	
43-44	
<b>Shift lever</b>	
24	
adjusting the basic position . . . . .	107
basic position, checking . . . . .	107
<b>Shifting</b>	
36	
<b>Shock absorber</b>	
45	
compression damping, general . . . . .	46
high-speed compression damping, adjusting .	47
low-speed compression damping, adjusting .	47
rebound damping, adjusting . . . . .	48
<b>Shock absorber article number</b>	
18	
<b>Side cover</b>	
mounting . . . . .	57
removing . . . . .	57
<b>Side stand</b>	
25	
<b>Spare parts</b>	
14	
<b>Spoke tension</b>	
checking . . . . .	85
<b>Start button</b>	
20	
<b>Starting</b>	
34	
<b>Steering head bearing play</b>	
adjusting . . . . .	54
checking . . . . .	54
<b>Steering lock</b>	
21	
<b>Stopping</b>	
40	
<b>Storage</b>	
117	
<b>T</b>	
<b>Technical specifications</b>	
capacities . . . . .	125
<b>chassis</b>	
. . . . .	125
<b>chassis tightening torques</b>	
. . . . .	127
<b>electrical system</b>	
. . . . .	126
<b>engine</b>	
. . . . .	121
<b>engine tightening torques</b>	
. . . . .	122
<b>fork</b>	
. . . . .	126
<b>shock absorber</b>	
. . . . .	127
<b>tires</b>	
. . . . .	126
<b>Throttle grip</b>	
. . . . .	19
<b>Tire condition</b>	
checking . . . . .	84
<b>Tire pressure</b>	
checking . . . . .	85
<b>Tire repair spray</b>	
using . . . . .	86
<b>Tool set</b>	
removing . . . . .	55
storing . . . . .	56
<b>Towing</b>	
. . . . .	41
<b>Traction control</b>	
adjusting . . . . .	106
<b>Transport</b>	
. . . . .	41
<b>Troubleshooting</b>	
. . . . .	119-120
<b>Turn signal bulb</b>	
changing . . . . .	98
<b>Turn signal switch</b>	
. . . . .	20
<b>Type label</b>	
. . . . .	17
<b>U</b>	
<b>Use definition</b>	
. . . . .	6
<b>V</b>	
<b>Vehicle identification number</b>	
. . . . .	17
<b>View of vehicle</b>	
front left . . . . .	15
rear right . . . . .	16
<b>W</b>	
<b>Winter operation</b>	
checks and maintenance steps . . . . .	115
<b>Work rules</b>	
. . . . .	12



3402756en

09.10.2023



**Husqvarna®**  
MOTORCYCLES

**Husqvarna Motorcycles GmbH**  
Stallhofnerstraße 3 | 5230 Mattighofen | Austria  
[www.husqvarna-motorcycles.com](http://www.husqvarna-motorcycles.com)



Photo: Mitterbauer/KISKA,  
Husqvarna Motorcycles GmbH