

Comtrend GRG-4284 GPON ONT Troubleshooting Guide

To troubleshoot the Comtrend GRG-4284 GPON ONT, diagnose its status using the four physical LED indicators on the front panel: Power, LOS (Loss of Signal), PON (Passive Optical Network), and LAN.

1. Read the LED Indicators

Power LED Off: The device is not receiving electrical power.

LOS LED Solid Red or Blinking Red: The ONT has lost its optical signal connection to the central office.

PON LED Off or Blinking Green: The ONT is not registered or authenticated with the provider Optical Line Terminal (OLT).

LAN LED Off: There is no physical connection detected between the ONT and your Wi-Fi router or computer.

2. Isolate and Resolve Specific Failures

Fixing Power Issues: Verify that the power adapter is pushed firmly into both the wall outlet and the ONT DC 12V port. Confirm you are using the original 12V / 0.5A power supply. Press the physical Power ON/OFF button on the back of the device if it was accidentally turned off.

Fixing LOS (Red Light) Issues: Check the green SC/APC fiber optic connector plugged into the bottom or back of the unit. Unplug it gently, ensure no dust is inside, and click it back into place. Avoid bending the yellow fiber optic cable sharply, as macro-bends snap the glass core internally and block light transmission.

Fixing PON (Authentication) Issues: If the LOS light is normal but PON will not turn solid green, the device cannot authenticate with your Internet Service Provider (ISP). This happens during outages or if the PLOAM / ONT ID password is missing or incorrect. You will need to contact your ISP to push a remote OMCI configuration profile to re-register the hardware.

Fixing LAN (No Internet to Router) Issues: Disconnect and securely reconnect the Ethernet cable bridging the Gigabit LAN port of the ONT to the WAN port of your router. Try swapping out the network cable for a known working Category 5e or Category 6 cable to rule out wire degradation.

3. Perform a Hard Factory Reset

If the ONT becomes completely unresponsive or its internal software hangs up, perform a factory reset: Leave the device completely powered on. Find the small recessed Reset hole on the rear panel. Insert a straightened paperclip or pin into the hole. Press and hold down the internal button firmly for 10 to 15 seconds. Release the button and wait 2 to 3 minutes for the system boot cycle to finish.

ZTE Home Gateway ZXHN H3600P Troubleshooting Guide

The ZTE ZXHN H3600P is a WiFi 6 certified home gateway router. The front panel LED indicators show: Power, Broadband, Internet, Phone, LAN, 2.4G, 5G, WPS, USB. The back panel has: On/Off button, Power port, LAN1, LAN2, LAN3 ports, WAN port, USB port, Phone port.

1. LED Indicator Meanings for ZTE ZXHN H3600P

Power LED Green: Router is powered on and operating normally.

Broadband LED Green: Router has a physical connection to the upstream network or ONT via the WAN port.

Broadband LED Off: No physical connection on the WAN port. The Ethernet cable between the ONT LAN port and the router WAN port is missing, loose, or faulty.

Internet LED Green: Router has obtained a valid IP address from the ISP and internet is working.

Internet LED Off: Router is connected to broadband physically but cannot obtain internet service from the ISP. This means the upstream ONT or fiber line has a problem, or ISP authentication is failing.

LAN LED Green: At least one wired device is connected to the LAN ports.

LAN LED Off: No wired devices connected. This is normal if all devices use WiFi.

2.4G LED Green: 2.4 GHz WiFi radio is active and broadcasting.

5G LED Green: 5 GHz WiFi radio is active and broadcasting.

2. Diagnostic Scenarios and Step-by-Step Fixes

SCENARIO A: Broadband LED Off, Internet LED Off, Power LED Green

Diagnosis: The router has power but is not detecting any physical signal on the WAN port. The Ethernet cable from the ONT to the router WAN port is missing, unplugged, or broken. The router itself is working but it cannot reach the internet because there is no upstream connection.

Step 1: Locate the WAN port on the back of the ZTE router. It is labeled WAN and is separate from the LAN1, LAN2, LAN3 ports.

Step 2: Check that an Ethernet cable is firmly plugged into the WAN port of the router and into the LAN port of the ONT or modem.

Step 3: If the cable looks connected but Broadband LED is still off, try a different Ethernet cable (Category 5e or Category 6).

Step 4: Power-cycle the router and ONT. Unplug both from power, wait 30 seconds, plug the ONT in first, wait 1 minute, then plug the router in.

Step 5: Wait 2 to 3 minutes for all lights to stabilise. If Broadband LED turns green, proceed to check Internet LED.

SCENARIO B: Broadband LED Green, Internet LED Off, Power LED Green

Diagnosis: The router has a physical WAN connection (Broadband is green) but cannot obtain internet service from the ISP. This means the ONT or fiber line upstream has a fault. The most common cause is that the ONT has lost its fiber optical signal (LOS condition). The router itself is fine.

Step 1: The problem is upstream of the router. Check the ONT (the small box that connects the fiber cable to your home network).

Step 2: Look at the LED indicators on the ONT. A flashing red or solid red LOS (Loss of Signal) LED means the ONT has lost its fiber optical signal.

Step 3: If the ONT LOS LED is red or flashing red: unplug the fiber optic cable (the thin yellow or green cable going into the ONT), check the connector tip for dust or dirt, blow gently to clean, and firmly re-insert it until it clicks.

Step 4: Do not bend the fiber optic cable sharply. Sharp bends break the glass fiber inside and permanently block light transmission.

Step 5: Power-cycle the ONT by unplugging its power, waiting 30 seconds, and plugging it back in. Wait 3 minutes for it to reconnect.

Step 6: If after reseating the fiber cable the LOS LED stops flashing and turns off or turns green, the ONT has restored its signal. The Internet LED on the router should turn green within 1 to 2 minutes.

Step 7: If the ONT LOS LED continues to flash red after reseating the fiber cable, the fault is in the external fiber line and requires a field technician from the ISP. Escalate the issue.

SCENARIO C: All LEDs Off except Power

Diagnosis: Router has power but no connectivity at all. Perform a full power-cycle first, then check all cable connections.

Step 1: Unplug the router power cable, wait 30 seconds, and plug it back in.

Step 2: Check all cables: WAN port must have an Ethernet cable going to the ONT.

Step 3: If still no improvement after power-cycle, perform a factory reset using a paperclip in the recessed Reset button on the back, hold for 10 seconds.

3. Full Troubleshooting Workflow: Internet Down from Start to Resolution

This workflow describes the complete sequence to restore internet when a customer reports no internet connectivity on a ZTE ZXHN H3600P router connected to a GPON fiber ONT.

Phase 1 - Initial Assessment:

Ask the customer to check the LED indicators on the front of the router. The most important LEDs to identify are Power, Broadband, and Internet.

Phase 2 - Broadband LED is Off:

If Broadband LED is off: the WAN Ethernet cable is not connected or is faulty. Ask the customer to check the cable from the ONT LAN port to the router WAN port. Ask them to unplug and re-plug the cable firmly, or try a different cable. After reconnecting the cable, wait 30 seconds. If Broadband LED turns green, move to Phase 3.

Phase 3 - Broadband LED is Green but Internet LED is Off:

The router has a physical connection but the ONT cannot provide internet service. The ONT likely has a fiber signal loss. Ask the customer to look at the ONT (the optical network terminal, a separate smaller box). Ask what LED indicators are lit on the ONT. If the LOS LED is flashing red or solid red, the ONT has lost its fiber optical signal.

Phase 4 - ONT LOS LED is Flashing Red:

Instruct the customer to re-seat the fiber optic cable on the ONT. The fiber optic cable is a thin yellow cable plugged into the bottom or side of the ONT. They should gently unplug it, check for dust on the connector, and plug it back in firmly. Then power-cycle the ONT. Wait 3 minutes.

Phase 5 - After Re-seating Fiber Cable:

If LOS LED stops flashing and goes off or turns green: the optical signal is restored. The router Internet LED should turn green within 1 to 2 minutes and internet should be working.

If LOS LED continues to flash red: the fault is in the external fiber network. A field technician is required. Escalate to support with the following details: router model ZTE ZXHN H3600P, ONT LOS LED flashing red after fiber cable re-seated, all customer-side troubleshooting steps completed.

4. Video Analysis Guide for LED Status


When a customer uploads a video of their router or ONT, analyze each frame to identify LED states. In a video, pay attention to: LEDs that are flashing or blinking (a flashing red LOS LED is the most critical indicator of fiber signal loss), LEDs that are steady green (normal operation), and LEDs that are completely off (no connection on that interface). A red flashing LOS LED visible in any frame of the video means the ONT has lost its fiber optical signal and the fiber cable must be re-seated.

5. When to Escalate

Escalate to a support technician when: the ONT LOS LED continues to flash red after re-seating the fiber cable and power-cycling the ONT; the router Internet LED remains off after all troubleshooting steps; the customer has tried all steps two or more times without success; there is physical damage visible to the fiber cable or ONT.

Pictures of ZTE Home Gateway ZXHN H3600P


view of front side:



side view



back view:



common scheme connections:

