

MGB Geohazard Threat Advisory (Rainfall Accumulation)

This process outlines the steps for MGB technical staff to analyze rainfall accumulation and review the summarized affected areas at both the national and regional levels. It is designed to guide users in interpreting rainfall data accurately, validating results, and ensuring a consistent approach to assessing impacted regions for informed decision-making.

- Obtain the rainfall TIFF file from PAGASA, which contains geospatial rainfall data used as the primary input for analysis.
- Convert the TIFF (raster) file into a vector format to enable accurate interpretation of boundaries, overlays, and spatial relationships (regions, provinces, municipalities, barangays).
- Input the converted vector data into the system's analytical model for processing.
- Apply predefined rainfall hazard thresholds using GSM (50, 80, 100) and WRF (50, 120, 150) to assess varying rainfall intensity levels.
- Generate outputs identifying affected regions and barangays, including administrative boundaries and pixel-level hazard classifications on the map.
- Display the results on the OCD Regional Office dashboard for review, interpretation, and validation by regional users.
- Allow OCD Regional Offices to submit a request for threshold adjustments if national standards do not reflect local conditions.
- Route the threshold modification request to the MGB Dashboard for evaluation and approval.
- Upon approval, automatically apply the updated thresholds across the system.
- Update both OCD and MGB dashboards with revised visualizations and summaries of affected regions and barangays, ensuring accurate and context-specific decision-making.

