

QUICK REFERENCE GUIDE (QRG): SIGN-IN TO THE OLT (SUPERVISOR-EXTRACTION)



Purpose of this QRG

• To teach you how to sign-in to the Operator Log Tool (OLT)

Intended Audience for this QRG

Supervisors - Extraction

Purpose of the OLT

- To meet regulatory & legislative requirements
- To provide shift handover reports to incoming shifts
- · To enable shift logs to be viewed across site
- To improve decision-making (by interfacing with SAP and generating useful management reports)
- To maintain a safe work place

Prerequisites

- You must have access to the OLT software application
- You must have an Operator role (Upgrading) assigned to you in the OLT

Helpful Hints

• Examples of other user roles include: Area Managers; Supervisors; Operators; Read-only users and more

Procedure



to launch the program.

- 1. Double-click the Operator Log Tool (OLT) icon (located on your desktop)
- 2. As required, complete the following fields:

Field	Sub-steps/Description
User Name	Type Operxx (where xx = number provided by trainer) in the User Name field
	Sign into the Operator Log Tool
	User Name : Password :
Password	Not required in training environment (ie leave the password textbox blank) Note: Use your regular Windows User Name and password to log into the non- training environment.

3. Click Sign-in button sign in.

Last updated: November 3, 2010



QUICK REFERENCE GUIDE (QRG): SIGN-IN TO THE OLT (SUPERVISOR-EXTRACTION)



4. When the Select Work Assignment screen appears, complete the following fields:

Field	Sub-steps/Description
Assignments	- Assignments
	O No Assignment
	Click 'Select Assignment' radio button Select Assignment to choose a Work
	Assignment. Note: Assignment radio button allows the tool to filter information by role and
	by Work Assignment Note: Assignments can be set to: No Assignment or Select Assignment.
Assignment Category	Click drop-down arrow in Assignment Category box to scroll through available categories. Click 'UP1-Coker' to select it from the list.
	Assignment Category: UP1 - Coker
	Note: *Assignment Categories vary by location and by role.
Functional Location(s)	Accept default Functional Location(s).
	Note: The 'system' automatically' selects check boxes next to Functional
	Locations depending on Work Assignment, location, and role.
	If desired, you may click check box(s) next to Functional Locations to de-
	select or select additional FLOCs.
	Note: If you logged on previously, you may click the 'Load Previous FLOCs'
	button Load Previous FLOCs to load the same FLOCs you selected
	earlier.
	Click Accept button to accept default (or your) FLOC selection(s)

5. If Shift Selector screen appears, click to select appropriate shift.

Last updated: November 3, 2010

Page 2 of 2