Laptop Troubleshooting Manual

Synthetic internal training document · Department: Laptop Support · Revision: 1.0

Laptop will not start

Check the power adapter connection and wall outlet. Inspect the charging light. Hold the power button for 10 seconds, release it, wait five seconds, then press once. Disconnect docks and USB devices before retrying. If there is no light or fan activity with a known-good adapter, record the laptop asset tag and escalate to hardware support.

Slow laptop

Open Task Manager and sort processes by CPU, Memory and Disk. Close only applications the employee recognizes. Restart the laptop if updates are pending. Keep at least 15 percent disk space free. Do not delete system folders. Record the process name and resource usage if one application repeatedly consumes resources.

Overheating

Place the laptop on a hard flat surface and keep air vents clear. Shut down if the case becomes unusually hot or the fan makes grinding sounds. Do not open the chassis or remove the battery. Contact hardware support for inspection.

Blue screen

Record the stop code and the time of failure. Disconnect recently attached peripherals. If Windows starts, check whether a driver or update was installed immediately before the problem. Do not repeatedly force shutdown during updates. Escalate repeated blue screens with the stop code and device serial number.