SystemVerilog Assertions Checker Library Reference Manual

Version C-2009.06 June 2009

Comments?
E-mail your comments about this manual to: vcs_support@synopsys.com.



Copyright Notice and Proprietary Information

Copyright © 2008 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Synopsys permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any. Licensee must assign sequential numbers to all copies. These copies shall contain the following legend on the cover page:

This document is duplicated with the perm	nission of Synopsys, In	c., for the exclusive use of
	and its employees. This	s is copy number"

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Registered Trademarks (®)

Synopsys, AMPS, Cadabra, CATS, CRITIC, CSim, Design Compiler, DesignPower, DesignWare, EPIC, Formality, HSIM, HSPICE, iN-Phase, in-Sync, Leda, MAST, ModelTools, NanoSim, OpenVera, PathMill, Photolynx, Physical Compiler, PrimeTime, SiVL, SNUG, SolvNet, System Compiler, TetraMAX, VCS, Vera, and YIELDirector are registered trademarks of Synopsys, Inc.

Trademarks (TM)

AFGen, Apollo, Astro, Astro-Rail, Astro-Xtalk, Aurora, AvanWaves, Columbia, Columbia-CE, Cosmos, CosmosEnterprise, CosmosLe, CosmosScope, CosmosSE, DC Expert, DC Professional, DC Ultra, Design Analyzer, Design Vision, DesignerHDL, Direct Silicon Access, Discovery, Encore, Galaxy, HANEX, HDL Compiler, Hercules, Hierarchical Optimization Technology, HSIMplus, HSPICE-Link, iN-Tandem, i-Virtual Stepper, Jupiter, Jupiter-DP, Jupiter-XT, Jupiter-ASIC, Liberty, Libra-Passport, Library Compiler, Magellan, Mars, Mars-Xtalk, Milkyway, ModelSource, Module Compiler, Planet, Planet-PL, Polaris, Power Compiler, Raphael, Raphael-NES, Saturn, Sciroccoi, Star-RCXT, Star-SimXT, Taurus, TSUPREM-4, VCS Express, VCSi, VHDL Compiler, VirSim, and VMC are trademarks of Synopsys, Inc.

Service Marks (SM)

MAP-in, SVP Café, and TAP-in are service marks of Synopsys, Inc.

SystemC is a trademark of the Open SystemC Initiative and is used under license. ARM and AMBA are registered trademarks of ARM Limited. Saber is a registered trademark of SabreMark Limited Partnership and is used under license. All other product or company names may be trademarks of their respective owners.

Contents

1.	The SystemVerilog Assertions (SVA) Checker Library
	Overview
	Global Controls
	Checker Triggering
	Custom Reporting
	Viewing Coverage Results
	Shared Syntax
	Using Coverage Level to Report Checker Results
	Use Mode in SystemVerilog
	Use Mode in VHDL (VCS MX) 1-14
2.	SVA Basic Checkers
	Checker Descriptions
	assert_always

	assert_always_on_edge	2-23
	assert_change	2-26
	assert_cycle_sequence	2-30
	assert_decrement	2-34
	assert_delta	2-37
	assert_even_parity	2-40
	assert_fifo_index	2-42
	assert_frame	2-47
	assert_handshake	2-51
	assert_implication	2-56
	assert_increment	2-59
	assert_never	2-62
	assert_next	2-64
	assert_no_overflow	2-68
	assert_no_transition	2-72
	assert_no_underflow	2-75
	assert_odd_parity	2-79
	assert_one_cold	2-82
	assert_one_hot	2-85
	assert_proposition	2-88
	assert_quiescent_state	2-90
	assert_range	2-93
	assert_time	2-97
	assert_transition	2-101
	assert_unchange	2-104
	assert_width	2-108
	assert_win_change	2-112
	assert_win_unchange	2-116
	assert_window	2-118
	assert_zero_one_hot	2-122
3.	SVA Advanced Checkers	
	Checker Descriptions	3-125
	·	

Shared Syntax	3-126
assert_arbiter	3-126
assert_bits	3-133
assert_code_distance	3-136
assert_data_used	3-139
assert_driven	3-143
assert_dual_clk_fifo	3-145
assert_fifo	3-150
assert_hold_value	3-156
assert_memory_async	3-159
assert_memory_sync	3-166
assert_multiport_fifo	3-175
assert_mutex	3-182
assert_next_state	3-184
assert_no_contention	3-188
assert_packet_flow	3-191
assert_rate	3-193
assert_reg_loaded	3-195
assert_req_ack_unique	3-199
assert_req_requires	3-202
assert_stack	3-206
assert_valid_id	3-212
assert_value	3-218

1

The SystemVerilog Assertions (SVA) Checker Library

The SystemVerilog Assertions (SVA) Checker Library consists of two parts:

- SVL (described in Chapter 2) consists of checkers that have the same behavior and controls as those in the Open Verification Library (OVL) - see the Accellera Open Verification Library Reference Manual available at http://www.verificationlib.org/. These checkers have additional features such as coverage in the SVA Library.
- SVA Advanced Checkers (described in Chapter 3) contains checkers that generally verify more complex behaviors. These have similar controls to the SVL checkers, but, in addition, they allow selecting the sampling clock edge(s), posedge or negedge Coverage is also provided.

Note that the header of each checker file also contains a description of the behavior and parameters.

Overview

The checker library resides in a release in the directory

```
$VCS_HOME/packages/sva/

or

$PIONEER HOME/packages/sva/
```

The library consists of 53 checker files having the name assert_checker_name.v. There is also a symbolic link to that file with the name assert_checker_name.sv that can be used in situations where parts of the Verilog design follow Verilog2001 syntax and should be compiled with that in mind to avoid keyword clashes with SystemVerilog keywords. In that way, the extension .sv identifies the checkers to be compiler with SystemVerilog, while the files with the .v extension will compile with Verilog2001 syntax and keywords.

The checkers have dual functions:

- As a verification object using assert property statements.
 This form is employed for verifying the behavior as specified for the checker.
- As a coverage objects using cover property and cover points implemented using the equivalent of covergroup statements. This form is employed to obtain information about the observed presence of certain behavioral patterns in the design - coverage of such patterns.

The two forms can coexist or be enabled independently as described later -the sections "Global Controls" and "Shared Syntax".

Note also that there is header file sva_std_task.h in the directory. It contains user-modifiable reporting tasks and is included in each checker using 'include.

Global Controls

The following symbols are macro's defined using `define and apply to all instances of the checkers.

ASSERT ON

When this macro is defined, the assertions and related variables in checkers are included, i.e., the checking functionality is enabled.

COVER ON

When this macro is defined, the coverage items in the checkers are included. I.e., the coverage functionality is enabled. Note that additional per-instance control is provided using the checker parameters <code>coverage_level_1</code>, <code>coverage_level_2</code>, and <code>coverage_level_3</code>.

ASSERT_INIT_MSG

When this macro is defined, then all checker instances will output a message to stdout to indicate their hierarchical name.

ASSERT GLOBAL RESET

When this macro is defined its defining expression is taken as the reset signal for all the checkers. Otherwise, the reset_n port signal is used as reset.

ASSERT MAX REPORT ERROR

When this global macro variable is defined, the assertion instance stops reporting messages if the number of errors for that instance is greater than the value defined by the macro. Using this macro as described requires modifying the reporting tasks in sva std task.h.

SVA CHECKER INTERFACE

If not defined, the interface is a SystemVerilog "module". If defined then the checker interface is "interface". The parameters and ports remain the same in both cases.

SVA CHECKER NO MESSAGE

When defined it eliminates reporting the user message when a assertion fails. It doesn not control the default failure message from the simulator.

Checker Triggering

In the SVL library (Chapter 2) all but one checker, assert_proposition, is triggered at the positive edge of a triggering signal or expression *clk*.

In the Advanced Checker Library (Chapter 3), all the checkers can select the sampling edge(s) using a parameter. It can be either the positive or the negative edge of the clock port expression.

The values of all actual signals or expressions in the ports of the checkers are sampled just before the sampling edge of clk. Therefore, any pulses happening on the signals / expressions between consecutive sampling edges of clk are not observed by the checkers.

Moreover, whenever an edge of a signal / expression on a port of a checker other than the clock is used in the checker, the value is the sampled form of the edge as detected by looking at two consecutive samples of the signal.

The checker assert_proposition monitors an expression at all times and triggers by a change of its value to 0.

Custom Reporting

As in OVL, if you wish to have more elaborate error reporting, counting, etc., you must edit the sva_std_task.h file that is distributed with the library and also resides in the directory

```
$VCS_HOME/packages/sva/
or
$PIONEER HOME/packages/sva/
```

This file is automatically 'include -ed in each checker. If the location of the header file is changed, the +incdir+ directive must also be modified accordingly.

Viewing Coverage Results

See the *VCS User Guide* or the *Pioneer User Guide* for information on viewing coverage results.

Shared Syntax

Many checkers share the same syntax elements. These elements are described in this section in order to avoid repeating their descriptions throughout this document.

severity level

Severity of the failure with default value of 0. Currently SystemVerilog does not provide support of severity levels through a parameter or a variable, hence this parameter is provided only for compatibility with older versions of the checkers. However by modifying the error tasks in the sva_std_task.h file appropriately, severity level can be taken into account. For example, the simulation can be terminated when a failure of an assertion occurs and the checker severity level is set to some specific value.

options

Currently, the only supported option is options=1, which defines the assertion as an assumption for formal tools. The default is 0 (no options specified). ¹

msg

Error message that will be printed when the assertion fires using the default definition of the sva_checker_error task that is included in the sva_std_task.h file. Its output can also be controlled by the macro SVA_CHCKER_NO_MESSAGE.

category

^{1.} Note that Magellan does not use options to determine the role (assume or assert) of the assertions.

Specifies the category of the assertion (Default = 0). This parameter can be used to group assertions used for a similar purpose, and provide a selection/filtering mechanism to enable/ disable individual or groups of assertions.

coverage level i

Specifies which coverage levels should be enabled (provided that the symbol COVER_ON is defined) by specifying parameters. There are three coverage levels controlled by parameters coverage_level_1, coverage_level_2, and coverage_level_3. The bits in each of the parameters when set to 1 enable some specific coverage point, one per bit. The number of bits used thus depends on the number of cover points in the checker at each level and varies from checker to checker. Generally, the following levels are supported (Default = Coverage Level 1).

Level 1: Basic coverage, implemented using cover property statements. Used by simulation and Magellan.

Level 1 coverages are enabled by setting bits in coverage level 1 to 1.

Example: The number of Enqueues and Dequeues in a FIFO.

Level 2: Usually includes data coverage on ranges of values. These are coverage items which show certain interesting activities of the RTL behavior in the form of statistics. Used in simulation only but may also include cover properties on some particular sequences that can be of interest as search goals for formal tools.

Level 2 coverages are enabled by setting bits in coverage_level_2 to 1.

Example: Range of latency values classified on at-least-once basis.

Level 3: Cover property coverage of specific corner points as specified. Used primarily by formal tools as goals. These cover properties can be enabled in simulation too, however, the same information can be obtained from Level 2 range coverages in the extreme bins. These coverage items ensure that the corner case condition of the RTL design block are verified during testing.

Level 3 coverages are enabled by setting bits in coverage level 3 to 1.

Examples: The number of times FIFO reached HIGH water mark. The number of times ACK was received at the next clock after REQ was issued. The number of times the specified Min latency value was reached.

inst name

Instance name of assertion monitor.

clk

Sampling clock of the assertion.

reset_n

Signal indicating completed initialization when set to 1. Note that reset_n is used as an asynchronous reset so that glitches on the sequence or expression may cause the checker to reset.

Using Coverage Level to Report Checker Results

As described in the previous section, you use *coverage_level_i* to generate coverage reports of checker results. This section describes how to generate and view those reports.

Generating a Report

To generate coverage level reports, you set the bits for the desired levels of coverage to 1 when specifying a checker. The checker descriptions in chapters 2 and 3 describe the coverage levels available for each checker.

To generate a report:

- Instantiate or bind the checker in your design as described in the sections "Use Mode in SystemVerilog" and "Use Mode in VHDL (VCS MX)".
- 2. Set the bits for desired coverage to 1 when specifying the checker.

```
For example, in the checker <code>assert_fifo_index</code> below, <code>coverage_level_1</code> and <code>coverage_level_2</code> are specified to have the two <code>coverage_level_1</code> properties and the three <code>coverage_level_2</code> properties reported.
```

```
assert_fifo_index #(0, 4, 1, 1, 1, "ERROR: Overflow or
Underflow in fifo", 0, 3, 7, 31)
invalid_fifo (clk, reset_n, push_sig, pop_sig)
```

Note the following:

- The default for <code>coverage_level_1</code> is on, so it is not necessary to specify <code>coverage_level_1</code> to generate results. However, since <code>coverage_level_1</code> has two bits, specifying 3 sets both bits to 1.
- Similarly, coverage_level_2 has three bits, so specifying 7 sets all three bits to 1.
- coverage_level_3 has four bits, so specifying 31 sets all four bits to 1..
- 3. Compile the design as described in the sections "Use Mode in SystemVerilog" and "Use Mode in VHDL (VCS MX)".
- 4. Run the simulation.
- 5. Generate the report by entering:

```
assertCovReport -cm_assert_dir coverage_directory_name
Your results are generated.
```

Viewing Results

Results are generated as html files in the subdirectory report.fcov in the coverage .vdb directory you specified in the previous section. You can access the results from the file report.index.html in the .vdb directory or navigate to the subdirectory and view the files directly. The following files are generated:

- category.html displays results by category.
- hier.html displays the hierarchical results
- instance_name__vmm_details.html shows level 2 coverage results.

- tests.html shows the tests results.
- vmm_hier.html is the hierarchical report.

Figure 1-1 is an example of a hierarchical report displaying a summary of instance coverage results and a summary of cover directives generaed by <code>coverage_level_1</code> and <code>coverage_level_3</code>.

Figure 1-1 Results for coverage levels 1 and 3

Functional Coverage: Synopsys Checkers Hierarchical Report

List of Instances	Number of Assertions	Number of Cover Directives for Sequences	of Cover Directives for	Number of Events	
testbench.FIFO.invalid_fifo	0	0	7	0	Level 2 report

Cover Directive for Properties

testbench.FIFO.invalid_fifo

Name	Attempts	Matches	Vacuous	Incompletes
cov_level_1_0.cover_nb_of_push_operations	26	13	0	0
cov_level_1_1.cover_nb_of_pop_operations	26	13	0	0
cov_level_3_0.cover_eq_nb_of_simultaneous_push_pop	26	7	0	0
cov_level_3_1.cover_eq_nb_of_simultaneous_push_pop_when_empty	26	1	0	0
cov_level_3_2.cover_eq_nb_of_simultaneous_push_pop_when_full	26	0	0	0
cov_level_3_3.cover_nb_of_times_empty_reached_on_pop	26	5	0	1
cov_level_3_4.cover_nb_of_times_full_reached_on_push	26	0	0	1

Clicking the link to the level 2 report in the instance table displays the report as shown in Figure 1-2.

Functional Coverage: Synopsys Checker Level 2 Report

Checker: assert_fifo_index

Instance:

doorbell_coverage_assertions.rx_fifo_checker

cov level 2 0.observed number of pushes

Index is the observed number of simultaneous pushes



cov level 2 1.observed number of pops

Index is the observed number of simultaneous pops



cov level 2 2.observed outstanding contents

Index is the observed number of outstanding contents



0 50

In the figure:

- The green zones indicate what was covered.
- * delimits the specified range observed,

- is a point in the range
- is an interval.

The first two graphs show the range observed was [0:1] and was covered. The third one has an observed range [1:16] with 1, 2, 3 and 4 covered and 5-16 not covered. Note that the 16 is displayed vertically.

Use Mode in SystemVerilog

The Entire Design Targets SystemVerilog

In VCS, to use the SVA Checker Library with a design written in SystemVerilog (which thus respects its enlarged set of keywords), you instantiate or bind any number of the checkers in the design and indicate the placement of the library using the Verilog library mechanism as follows:

```
vcs -sverilog +define+ASSERT_ON+COVER_ON \
  <design files and other options> \
  -y $VCS_HOME/packages/sva +libext+.v \
  +incdir+$VCS HOME/packages/sva
```

Note that $+define+ASSERT_ON$ on the VCS command line is necessary to turn on the assertions in all checker instances. Alternately or in addition, by defining COVER_ON the coverage functionality can be included (it can be further controlled at the instance level by the checker parameter coverage_level_i, where i = 1, 2, or 3.

To gather coverage information using the coverage functionality of the checkers, do not include the -cm assert option. This is because coverage on cover property and covergroup statements is automatically turned on in VCS.

Some Design Files Are Restricted to Verilog2001

In this case, the Verilog2001 files have names with the .v extensions, while all SystemVerilog files, including the checkers, have a name with the .sv extension. In the case of the checkers, it is the symbolic link with the .sv extension that is used. The vcs compilation command line will then have the following form:

```
vcs -sverilog+define+ASSERT_ON+COVER_ON \
<design files and other options> -y $VCS_HOME/packages/sva \
+libext+.sv +verilog2001ext+.v +incdir+$VCS_HOME/packages/
sva
```

The compiler uses Verilog2001 syntax for all .v files, and SystemVerilog syntax for all other files including those with the .sv extension.

Note: To use the .sv checkers,

```
-y $VCS_HOME/packages/sva_cg +libext+.sv
```

must be placed ahead of any other option.

Use Mode in VHDL (VCS MX)

The SVA Checker Library .v files can be found in the \$VCS_HOME/packages/sva/ directory.

There is also a VHDL package called sva_lib in this directory, containing the component definitions for all the checkers in the library. The name of the file is component.sva_v.vhd.

To use the SVA library in VHDL, do the following:

1. Compile the component package in a library. For example, suppose that the default WORK library is used. The command to compile the package is then:

```
vhdlan $VCS HOME/packages/sva/components.sva v.vhd
```

2. Compile the selected SVA checkers using vlogan and deposit them in a VHDL library. For example, suppose again that the default WORK library is used and that you wish to compile all the checkers in the library (it takes a fraction of a second to complete). Then the command is:

Other macro definitions can be supplied with +define.

Note that if you choose to compile only some specific checkers that are described in Chapter 2, you also must compile the file sva_std_edge_select.v. This is because these checkers allow specification of the sampling clock edge.

3. To use the compiled checkers in the VHDL design, you must include commands to use the following libraries:

```
library IEEE;
use IEEE.STD_LOGIC_1164.all;
library WORK;
use WORK.sva_lib.all;
```

and instantiate the checker component(s) as any other VHDL entity.

Note that the signals on the checker ports are of the IEEE std_ulogic and unsigned types.

Example

```
library IEEE;
use IEEE.STD LOGIC_1164.all;
library WORK;
use WORK.sva lib.all;
entity top is
 generic (P1 : integer := 7;
         P2 : integer := 31);
end top;
architecture top arch of top is
signal a,b,c : std ulogic vector(P1 downto 0);
signal clk : std ulogic;
component child is
    generic (p : integer := 10);
    port (in1, in2 : std ulogic vector(p downto 0);
          clk : std logic;
          out1 : out std ulogic vector(p downto 0));
end component;
begin
-- Some design entity instance
i1 : child generic map(P1) port map(a,b,clk,c);
 -- sva assert always checker
always inst : assert always port map(clk, '1', a(1));
-- sva assert cycle sequence checker
seq inst : assert cycle sequence
          generic map (0, P1+1, 0, 0, "a3")
```

```
port map(clk, '1', a);

process
begin
    clk <= '0';
    wait for 3 ns;
    clk <= '1';
    wait for 3 ns;
end process;
end top_arch;

configuration cfg_top of top is
    for top_arch
    end for;
end;</pre>
```

2

SVA Basic Checkers

This chapter contains 31checkers. All checkers, except assert_proposition, are triggered at the positive edge of a triggering signal or expression clk.

The values of all actual signals or expressions in the ports of the checkers are sampled just before the positive edge of clk. Therefore, any pulses happening on the signals / expressions between consecutive positive edges of clk are not observed by the checkers.

Moreover, whenever an edge of a signal / expression on a port of a checker other than the clock is used in the checker, it is the sampled form of the edge as detected by looking at two consecutive samples of the signal.

The checker assert_proposition monitors an expression at all times and triggers at the falling edge of the test_expr.

Checker Descriptions

This section provides syntax and descriptions, and examples for all SVA checkers. Note that each checker example is followed by an example of the checker written in the alternative name-based format.

assert_always

The assert_always checker continuously monitors <code>test_expr</code> at every positive edge of clock, <code>clk</code>. It verifies that <code>test_expr</code> will always evaluate true. If test_expr evaluates to false, the assertion will fire (that is, an error condition will be detected in the code.) The <code>test_expr</code> can be any valid Verilog expression

Syntax

Arguments

test expr

Expression being verified at the positive edge of clk.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)

Cover property cover_always indicates that the test_expr was asserted when enabled by reset_n.
```

Example

```
'define ASSERT_ON
'define COVER_ON
```

```
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk) begin
    if (reset n == 0 \mid | count >= 9)
        count <= 1'b0;
    else
        count <= count + 1;</pre>
end
assert_always //coverage_level_1 = 7 level 1
#(0, 0, "ERROR: count not within 0 and 9", 0, 15, 0, 0)
valid count
(clk, reset n, (count >= 4'b0000) && (count <= 4'b1001));
endmodule
```

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_always #(.severity_level(0),.options(0),
   .msg("ERROR: count not within 0 and 9"),.category(0),
   .coverage_level_1(15),.coverage_level_2(0),
   .coverage_level_3(0))
valid_count (.clk(clk),.reset_n(reset_n),
   .test expr((count >= 4'b0000) && (count <= 4'b1001));</pre>
```

assert_always_on_edge

The checker continuously monitors the <code>test_expr</code> at every specified edge of the sampling_event. <code>test_expr</code> should always evaluate true at the <code>sampling_event</code>. If <code>test_expr</code> evaluates to false the assertion will fire.

Note that the transition on the sampling event is as determined by sampling <code>sampling event</code> at two consecutive clock ticks.

Syntax

Arguments

edge type

Selects the transition for sampling event.

```
0 - no edge (default)1 - positive edge2 - negative edge3 - any edge
```

Note that the transition is as determined by samplingsampling_event at two consecutive clock ticks.

```
sampling event
```

Expression defines when to evaluate *test_expr*. Transition of sampling_event are selected by *edge type*.

```
test expr
```

Expression being verified at the positive edge of clk AND if sampling event matches transition selected by edge type.

Coverage Modes

cov_level_1_0 (bit 0 set in coverage_level_1)
Cover property cover_always_on_edge indicates that the
 test_expr was asserted on the specified edge of
 sampling event.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk, sig;
child CH (reset n, clk, sig);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    sig = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
always #40 sig = ~sig;
endmodule
module child (reset n, clk, sig);
input reset n, clk, sig;
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk) begin
    if (reset n == 0 \mid \mid count >= 9)
        count <= 1'b0;
    else
        count <= count + 1;</pre>
```

end

```
assert_always_on_edge
#(0, 1, 0, "ERROR: count not within 0 and 9", 0, 15, 0, 0)

valid_always_on_edge
  (clk, reset_n, sig,
    (count >= 4'b0000) && (count <= 4'b1001));
endmodule</pre>
```

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_always_on_edge ##(.severity_level(0),
  .options(0),.msg("ERROR: count not within 0 and 9"),
  .category(0),.coverage_level_1(15),.coverage_level_2(0),
  .coverage_level_3(0))
valid_always_on_edge (.clk(clk),.reset_n(reset_n),
  .test_expr((count >= 4'b0000) && (count <= 4'b1001));</pre>
```

assert_change

Change assert_change checker continuously monitors the start_event at every positive edge of the clock. When start_event is true, the checker ensures that the expression, test_expr changes values on a clock edge at some point within the next num_cks number of clocks. This assertion will fire upon a violation.

Syntax

Arguments

width

Width of the expression, test expr. Default = 1.

num cks

Number of clocks for $test_expr$ to change its value before an error is triggered after $start_event$ is asserted. Default = 1.

flag

- 0 Ignore any start_event assertion after the first one has been detected. Default = 0.
- 1 Re-start monitoring test_expr, if start_event is asserted in any subsequent clock while monitoring test expr.
- 2 Issue an error if an asserted start_event occurs in any clock cycles while monitoring test_expr.

```
start_event
```

Starting event that triggers monitoring of the test_expr.

```
test expr
```

Expression or variable being verified at the positive edge of c1k.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1)
 Cover property cover_change indicates that the exp changed
 within num_cks.
- cov_level_1_1 (bit 1 set in coverage_level_1)
 Cover property cover_start_event indicates that the
 start event occurred.
- cov_level_2_0 (bit 0 set in coverage_level_2)
 Cover point observed_delay indicates which delays within from
 start event were observed at least once.
- cov_level_3_0 (bit 0 set in coverage_level_3)
 Cover property cover_overlapping_start_events indicates that
 the start_event occured while there was another evaluation
 attempt in progress.
- cov_level_3_1 (bit 1 set in coverage_level_3)
 Cover property cover_change_after_1_clk indicates that the
 test_expr changed value at the next clock tick after
 start_event.
- cov_level_3_2 (bit 2 set in coverage_level_3)
 Cover property cover_change_after_num_cks indicates that the
 test_expr changed value at num_clk clock ticks after
 start_event.

Example

'define ASSERT_ON 'define COVER_ON module testbench;

```
reg reset_n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset_n, clk);
input reset n, clk;
reg start;
reg [3:0] expr;
integer count;
initial $monitor ("count = %d start = %b expr = %b \n",
count, start, expr);
always @(posedge clk)
begin
     if (reset n == 0)
     begin
         start <= 0;
         expr <= 4'b0000;
         count <= 0;
     end
     else
         count <= count + 1;</pre>
    if (count == 3 | count == 4 | count == 5 | count ==
6 | count == 7 | count == 8 | count == 9)
         expr <= 4'b0110;
     else
         expr <= expr + 1;
```

```
if (count == 4)
         start <= 1;
else
         start <= 0;
end

//Coverage levels 1 and 2 enabled
assert_change #(0, 4, 4, 0, 0, "ERROR: expr value did not change in the specified number of clock cycles after start_event", 0, 15, 15, 0)
valid_change (clk, reset_n, start, expr);
endmodule</pre>
```

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_change #(.severity_level(0),.width(4),.num_cks(4),
   .flag(0),.options(0),.msg("ERROR: expr value did not change
in the specified number of clock cycles after
   start_event"),.category(0),.coverage_level_1(15),
   .coverage_level_2(15),.coverage_level_3(0))
valid_change(.clk(clk),.reset_n(reset_n),
   .start_event(start_event),.test_expr(test_expr));
```

assert_cycle_sequence

This checker verifies the following conditions:

- When necessary_condition = 0, if all num_cks-1 first events of a sequence (event_sequence[num_cks-1:1]) are true, the last sequence (event_sequence[0]) should follow.
- When necessary_condition = 1, if the first event of a sequence (event_sequence[num_cks-1]) is true, then all the remaining event sequence[num_cks-2:0] events should follow.

Syntax

Arguments

num clks

The width of the event_sequence (number of clock cycles of the event_sequence) that must be valid. Otherwise, an assertion will fire. Should be num cks > 1.

```
necessary condition
```

Either 1 or 0. The default is 0.

```
event sequence
```

A verilog concatenation expression, where each bit represents an event.

Coverage Modes:

```
cov level 1 0 (bit 0 set in coverage level 1) :
```

Cover property, <code>cover_cycle_sequence_antecedent_match</code>, indicates that the antecedent part of the sequence matched (i.e., the checker was triggered).

```
cov_level_1_1 (bit 1 set in coverage_level_1) :
   Cover property, cover_cycle_sequence, indicates that the
   complete sequence occurred.
```

```
cov_level_3_0 (bit 0 set in coverage_level_3) :
   Cover property, cover_sequence_slice[i,] indicates that the
   sequence matched at least till the 'i'-th boolean expression.
```

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #100 \text{ reset n} = 1;
    #980 $finish;
end
always #50 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg e1, e2, e3, e4, e5;
req [3:0] count;
initial $monitor ("count = %d e1 = %b e2 = %b e3 = %b e4 =
```

```
%b e5 = %b \n", count, e1, e2, e3, e4, e5);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        count <= 4'b0000;
        e1 <= 0;
        e2 <= 0;
        e3 <= 0;
        e4 <= 0;
        e5 <= 0;
    end
    else
        count <= count + 1;</pre>
    case(count)
        4'b0001: e1 <= 1;
        4'b0010: e2 <= 1;
        4'b0011: e3 <= 1;
        4'b0100: e4 <= 1;
        4'b0101: e5 <= 1;
    endcase
end
//Coverage level 1 enabled by default
assert cycle sequence
#(0, 5, 1, 0, "ERROR: event sequence did not complete")
valid seq (clk, reset n, {e1,e2,e3,e4,e5});
endmodule
```

```
assert_cycle_sequence #(.severity_level(0),.num_cks(5),
   necessary_condition(1),.options(0),
   .msg("ERROR: event sequence did not complete"))
valid_seq (.clk(clk),.reset_n(reset n),
```

.event_sequence{e1,e2,e3,e4,e5});

assert decrement

The assert_decrement checker continuously monitors the $test_{expr}$ at every positive edge of the clock signal, clk. It checks that the $test_{expr}$ will never decrease by anything other than the value specified by value. The $test_{expr}$ can be any valid Verilog. The check will not start until the first clock tick after $reset_{n}$ is asserted.

Syntax

Arguments

width

Width of test expr with default value of 1.

value

Maximum decrement value allowed for test_expr with default value of 1.

```
test expr
```

Expression being verified at the positive edge of clk.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
   Cover property, cover_of_test_expr_change, indicates that
   test_expr_changed value.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2) :
   Cover point, cover_observed_decrement indicates all the
   observed decrement values of the test_expr when it changes.
```

cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property, cover_decrement_eq_to_value, indicates that
 the reduction in test_expr was exactly equal to the value
 parameter.

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 4'b1111;</pre>
    else
        count <= count - 2;
end
```

```
//Coverage level 1 enabled
assert_decrement
#(0, 4, 2, 0, "ERROR: count has decreased beyond allowable
limit ")
valid_count_decrease (clk, reset_n, count);
endmodule
```

```
assert_decrement #(.severity_level(0),.width(4),.value(4),
.options(0),.msg("ERROR: count has decreased
  beyond allowable limit "))
valid_count_decrease(.clk(clk),.reset_n(reset_n),
  .start event(start event),.count(count));
```

assert delta

The assert_delta checker continuously monitors the $test_expr$ at every positive edge of clock signal, clk. It verifies that $test_expr$ will never change value by anything less than min and anything more than max value. The $test_expr$ can be any valid Verilog expression. The check will not start until the first clock after reset n is asserted.

Syntax

Arguments

width

Width of $test_{expr}$ with default value of 1. However, with the value of 1 the assertion cannot fail and a warning is issued at time 0. The default is set to 1 for compatibility with OVL

min

Minimum changed value allowed for $test_expr$ in two consecutive clocks of clk. Default = 1.

max

Maximum changed value allowed for test_expr in two consecutive clocks of clk. Default = 1.

test_expr

Expression being verified at the positive edge of clk.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
Cover property, cover_test_expr_change, indicates that the
test expr has changed value.
```

```
cov_level_1_1 (bit 1 set in coverage_level_1)
Cover property, cover_delta, indicates that test_expr changed
value within the min:max range.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2)

Cover point, observed_delta, reports the observed delta values
that occured at least once on a value change in the test_expr.
```

```
cov_level_3_0 (bit 0 set in coverage_level_3)
   Cover property, cover_delta_eq_to_min, indicates that the delta
   value was exactly equal to the specified min value when the
   test expr changed value.
```

```
cov_level_3_1 (bit 1 set in coverage_level_3) :
   Cover property, cover_delta_eq_to_max, indicates that the delta
   value was exactly equal to the specified max value when the
   test expr changed value.
```

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;

child CH (reset_n, clk);

initial begin
    $vcdpluson;
    clk = 0;
    reset_n = 0;
    #40 reset_n = 1;
    #980 $finish;
end

always #20 clk = ~clk;
endmodule
```

```
module child(reset n, clk);
input reset n, clk;
reg [7:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 8'b11111111;</pre>
    else
        count <= count - 2;
end
//Coverage level 3 enabled
assert delta
#(0, 8, 2, 4, 0, "ERROR: count has decreased by greater than
the max (4) or less than the min (2) limit", 0, 0, 0, 15)
valid delta (clk, reset n, count);
endmodule
```

```
assert_delta
#(.severity_level(0),.width(8),.min(2),.max(4),
   .options(0),.msg("ERROR: count has decreased by greater
   than the max (4) or less than the min (2) limit"),
   .category(0), .coverage_level_1(0), .coverage_level_2(0),
   .coverage_level_3(15))
valid_delta(.clk(clk),.reset_n(reset_n),.count(count));
```

assert_even_parity

The assert_even_parity checker continuously monitors the $test_expr$ at every positive edge of the clock signal, clk. It verifies that $test_expr$ will always have an even number of bits asserted.

Syntax

Arguments

width

Width of the monitored expression test expr.

test expr

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
Cover property cover_test_expr_change indicates that the
  test expr changed value.
```

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;
child CH (reset_n, clk);
initial begin
    $vcdpluson;
    clk = 0;
```

```
reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule.
module child(reset n, clk);
input reset n, clk;
req [7:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 8'b11111111;</pre>
    else
        count <= count << 2;</pre>
end
//Coverage level 1 enabled by default
assert even parity // no cover selected
#(0, 8, 0, "ERROR: count has odd number of bits asserted")
valid count even (clk, reset n, count);
endmodule
```

9119....9 91912 9

Name-based Example

```
assert_even_parity #(.severity_level(0),.width(8),
   .opotions(0),.msg("ERROR: ccount has odd number of bits
asserted"))
valid_count_even(.clk(clk),.reset_n(reset_n),
   .count(count));
```

assert_fifo_index

The assert_fifo_index checker ensures that the FIFO element (a) never overflows and underflows (b) allows/disallows simultaneous push and pop.

Syntax

Arguments

depth

Depth of the FIFO, default 1. It should never be set to 0, otherwise an assertion will fire.

```
push_width
```

Width of the push signal, default 1.

```
pop width
```

Width of the pop signal, default 1.

options

Currently, the only supported option is options=1, which defines the assertion is an assumption for formal tools.

If bit 1 of options is set (i.e., option &2 != 0) then simultaneous push and pop operations are disallowed in the same clock cycle. (Note that multiple pushes or pops are allowed always, provided that push width, resp. pop width, is greater than 1.)

push

The value of push indicates the number of writes that are occurring on that particular clock cycle. The <code>push_width</code> defines the width of the <code>push</code> expression. By default, only a single write can be performed on a particular clock cycle.

pop

The value of pop indicates the number of reads that are occurring on that particular clock cycle. The pop_width defines the width of the pop expression. By default, only a single read can be performed on a particular clock cycle.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1) :
 Cover property, cover_nb_of_push_operations, indicates that
 push was greater than 0.
- cov_level_1_1 (bit 1 set in coverage_level_1) :
 Cover property, cover_nb_of_pop_operations, indicates that pop
 was greater than 0.
- cov_level_2_0 (bit 0 set in coverage_level_2) : Cover point, observed_number_of_pushes, reports the observed value of simultaneous pushes (i.e., the value of the push expression) that occurred at least once.
- cov_level_2_1 (bit 1 set in coverage_level_2) :
 Cover point, observed_number_of_pops, reports the observed
 value of simultaneous pops (i.e., the value of the expression
 push) that occurred at least once.
- cov_level_2_2 (bit 2 set in coverage_level_2) :
 Cover point, observed_outstanding_contents, reports the
 observed value of outstanding contents in the FIFO that occured
 at least once.

```
cov level 3 0 (bit 0 set in coverage level 3) :
   Cover property, cover eq nb of simultaneous push pop,
   indicates that push == pop occurred simultaneously, when push
   and pop were not 0.
cov level 3 1 (bit 1 set in coverage level 3) :
   Cover property,
   cover eq nb of simultaneous push pop when empty,
   indicates that push == pop occurred simultaneously, when both
   push and pop were not 0 and the FIFO was empty.
cov level 3 2 (bit 2 set in coverage level 3) :
   Cover property,
   cover eq nb of simultaneous push pop when full, indicates
   that push == pop occurred simultaneously, when both push and
   pop were not 0 and the FIFO was full.
cov level 3 3 (bit 3 set in coverage level 3) :
   Cover property, cover nb of times empty reached on pop,
   indicates that the FIFO reached empty on a pop.
cov level 3 4 (bit 4 set in coverage level 3) :
   Cover property, cover nb of times full reached on push,
   indicates that the FIFO reached full on a push.
```

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;
fifo FIFO (reset_n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
```

```
#40 reset_n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
endmodule
module fifo(reset n, clk);
input reset n, clk;
reg [3:0] fifo;
reg push sig, pop sig;
always @(posedge clk) #5 push sig = ~push sig;
always @(negedge clk) #45 pop sig = ~pop sig;
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        push sig <= 0;</pre>
        pop sig <= 1'b0;</pre>
        fifo <= 4'b0000;
    end
    if (push_sig)
    begin
        fifo <= fifo << 1;
        fifo <= fifo + 1;
        $display("time = %d fifo = %b push sig = %b \n",
$time, fifo, push sig);
    end
    if (pop sig)
    begin
        fifo <= fifo >> 1;
        display("time = %d fifo = %b pop sig = %b \n",
$time, fifo, pop sig);
    end
end
```

```
//Coverage level 1 enabled by default
assert_fifo_index
#(0, 4, 1, 1, 1, "ERROR: Overflow or Underflow in fifo")
invalid_fifo (clk, reset_n, push_sig, pop_sig);
endmodule
```

```
assert_fifo_index
#(.severity_level(0),.depth(4),.push_width(1),.
    pop_width(1), .options(1),.msg("ERROR: Overflow
    or Underflow in fifo"))
invalid_fifo(.clk(clk),.reset_n(reset_n),.count(count));
```

assert frame

The assert_frame checker validates proper cycle timing relationships between two events in the design. When a start_event evaluates true, then the test_expr must evaluate true within a minimum and maximum number of clock cycles.

Syntax

Arguments

min cks

Minimum number of clock cycles, within which the $test_expr$ should not become true. When min_cks is 0 then $test_expr$ can occur at the same time as $start_event$ or after as controlled by $max\ cks$. Default = 0.

max cks

Maximum number of clock cycles, before which $test_expr$ must become true. This check will be disabled when max_cks is not specified, i.e., when $min_cks > 0$ and $max_cks == 0$. If both min_cks and max_cks are 0 then $test_expr$ must occur at the same time as there is a 0 to 1 transition on $start_event$. Default = 0.

flaq

- 0 Ignores any asserted start_event after the first one has been detected (default);
- 1 Re-start monitoring test_expr if start_event is asserted in any subsequent clock while monitoring test_expr;

2 - Issue an error if an asserted <code>start_event</code> occurs in any clock cycle while monitoring <code>test_expr</code>.

```
start event
```

Starting event that triggers monitoring of the test_expr. The start event is a cycle transition from 0 to 1.

test expr

Expression being verified at the positive edge of c1k.

Coverage Modes

cov_level_1_0 (bit 0 set in coverage_level_1) :
 Cover property, cover_start_event, indicates that

the start event occured.

- cov_level_1_1 (bit 1 set in coverage_level_1) :
 Cover property, cover_frame, indicates that the test_expr
 became true within a minimum and maximum number of clock
 cycles after the occurence of the start event.
- cov_level_2_0 (bit 0 set in coverage_level_2) :
 Cover point, observed_delay, reports the observed delay from a
 rising start event to the subsequent rising test expr.
- cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property, cover_overlapping_start_events, indicates
 that the start_event occured while there was already an
 evaluation in progress.
- cov_level_3_1 (bit 1 set in coverage_level_3) :
 Cover property, cover_frame_exactly_at_min_cks, indicates
 that the test_expr became true exactly at min_cks after
 start_event occurred.

cov_level_3_2 (bit 2 set in coverage_level_3) :
 Cover property, cover_frame_exactly_at_max_cks, indicates
 that the test_expr became true exactly at min_cks after
 start event occurred.

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg start, expr;
integer count;
initial $monitor ("count = %d start = %b expr = %b \n",
count, start, expr);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        count <= 0;
        start <= 0;
```

```
assert_frame
#(.severity_level(0),.min_cks(2),.max_cks(4),.flag(0),
   .options(1),.msg("ERROR: expr is not true in the
   intended time window after start_event"),
   .category(0), .coverage_level_1(0), .coverage_level_2(1),
   .coverage_level_3(0))
invalid_frame(.clk(clk),.reset_n(reset_n),
   .start_event(start),.test_expr(expr));
```

assert_handshake

The assert_handshake checker continuously monitors the req and ack signals at every positive edge of the clock clk.

Note that both req and ack must go inactive (0) prior to starting a new cycle.

There are no defaults for this assertion; therefore, if you do not specify parameters, the corresponding assertion is not included. To activate one or more checks in the checker, the corresponding parameters should be specified with a non-zero value.

Syntax

Arguments

```
min ack cycle
```

Activate min_ack_cycle check if greater than default value of 0.

When this parameter is greater than 0, the assertion will ensure that an ack does not occur before min_ack_cycle clock ticks.

```
max ack cycle
```

Activate max_ack_cycle check if greater than default value of 0.

When this parameter is greater than 0, the assertion will ensure that an ack does not occur after max_ack_cycle clock ticks.

```
req drop
```

Activate req_drop check if greater than default value of 0.

When this parameter is greater than 0, the assertion will ensure that req remains active until an ack is asserted.

```
deassert count
```

Activate <code>deassert_count</code> if greater than default value of 0. When this parameter is greater than 0, the assertion will ensure that <code>req</code> becomes inactive (0) within <code>deassert_count</code> clock ticks after <code>ack</code> is asserted.

```
max ack length
```

Activate max_ack_length check if greater than default value of 0.

When this parameter is greater than 0, the assertion will ensure that ack is not asserted for greater than max_ack_length clock cycles (that is, check for ack stuck active) and does not become inactive (0) within deassert count clocks after ack is asserted.

req

Signal that starts the transaction.

ack

Signal that terminates the transaction.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
    Cover property, cover_nb_of_reqs, indicates that req was
    asserted.
```

```
cov_level_1_1 (bit 1 set in coverage_level_1) :
    Cover property, cover_nb_of_acks, indicates that ack was
    asserted.
```

```
cov_level_1_2 (bit 2 set in coverage_level_1)
Cover property, cover_req_eventually_followed_by_ack,
indicates that there was a req followed eventually by an ack.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2)

Cover point, observed_delay_pos_req_pos_ack, records the delay between the arrival of a req and the subsequent arrival of an ack.
```

```
cov_level_2_1 (bit 1 set in coverage_level_2)

Cover point, observed_delay_pos_ack_neg_req, records the delay between arrival of an ack and the deassertion of the req.
```

```
cov_level_3_0 (bit 0 set in coverage_level_3)

Cover property, cover_ack_exactly_after_min_ack_cycles, indicates that the observed latency between req and ack was equal to the specified ack_cycle value.
```

```
cov_level_3_1 (bit 1 set in coverage_level_3)

Cover property, cover_ack_exactly_after_max_ack_cycles, indicates that the observed latency between req and ack was equal to the specified ack_cycle value.
```

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;

child CH (reset_n, clk);

initial begin
    $vcdpluson;
    clk = 0;
    reset_n = 0;
    #40 reset_n = 1;
    #1000 $finish;
end

always #20 clk = ~clk;
endmodule
```

```
module child(reset n, clk);
input reset_n, clk;
reg req, ack;
integer count;
initial monitor ("count = %d req = %b ack = %b \n", count,
req, ack);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        req <= 0;
        ack <= 0;
        count <= 0;
    end
    else
        count <= count + 1;</pre>
    if (count == 4)
        req <= 1;
    if (count == 6)
        ack <= 1;
    if (count == 9)
        ack <= 0;
end
//Default coverage 1 enabled
assert handshake #(0, 3, 5, 0, 0, 3, 0,
"ERROR: handshake incorrect")
invalid handshake (clk, reset n, req, ack);
endmodule
```

```
assert_handshake
#(.severity_level(0),.min_ack_cycle(3),.max_ack_cycle(5),
    .req_drop(0),.deassert_count(0),.max_ack_length(3),
    .options(0),.msg("ERROR: handshake incorrect"))
invalid_handshake(.clk(clk),.reset_n(reset_n),
    .req(req),.ack(ack));
```

assert_implication

The assert_implication checker continuously monitors the antecedent_expr. If it evaluates to true, then this checker will verify that the consequent expr is true.

When antecedent_expr is evaluated to false, then consequent_expr expression will not be checked at all and the implication is satisfied.

Syntax

Arguments

```
antecedent expr
```

Expression verified at the positive edge of c1k.

```
consequent expr
```

Expression verified if antecedent expr is true.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
    Cover property cover_nb_of_antecedent_expr indicates that the
    antecedent_expr was asserted when enabled by reset_n

cov_level_1_1 (bit 1 set in coverage_level_1) :
    Cover property cover_implication indicates that the implication
    was non-vacuously covered when enabled by reset n.
```

```
'define ASSERT_ON 'define COVER ON
```

```
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #1000 $finish;
end
always #20 clk = \simclk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg expr1, expr2;
integer count;
initial $monitor ("count = %d expr1 = %b expr2 = %b \n",
count, expr1, expr2);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        expr1 <= 0;
        expr2 <= 0;
        count <= 0;
    end
    else
        count <= count + 1;</pre>
    if (count == 4)
    begin
        expr1 <= 1;
        expr2 <= 1;
    end
```

```
end
//Coverage levels all disabled
assert_implication #(0, 0, "ERROR: implication violated",
0, 0)
invalid_handshake (clk, reset_n, expr1, expr2);
endmodule
```

```
assert_implication #(.severity_level(0),.options(0),
   .msg("ERROR: implication violated"),.category(0),
   .coverage_level_1(0))
invalid_handshake (.clk(clk),.reset_n(reset_n),
   .antecedent expr(expr1),.consequent expr(expr2));
```

assert_increment

The assert_increment checker continuously monitors the $test_expr$ at every positive edge of the triggering event, clk. It verifies that $test_expr$ will never increase by anything other than the value specified by value. The $test_expr$ can be any valid Verilog expression. The check will not start until the first clock after the reset n is asserted.

Syntax

Arguments

width

Width of test_expr with default value of 1. However, with the value of 1 the assertion cannot fail and a warning is issued at time 0. The default is set to 1 for compatibility with OVL.

value

Maximum increment value allowed for $test_expr$ with default value of 1.

```
test expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property, cover_of_test_expr_change, indicates that the
   test_expr changed when enabled by reset_n.

cov_level_2_0 (bit 0 set in coverage_level_2)
```

Cover point, observed_increment, records the increment value of test expr whenever the test expr changes.

cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property, cover_increment_eq_to_value, indicates that
 the increment value of test_expr was exactly equal to the
 specified value.

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
   reset n = 0;
    #40 reset n = 1;
   #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
       count <= 4'b0000;
```

```
assert_increment #(.severity_level(0), width(4), value(4),
    .options(0), .msg("ERROR: count has increased beyond allowable
    limit"), .category(0), .coverage_level_1(0),
    .coverage_level_2(0), .coverage_level_3(1))
invalid_count_increase (.clk(clk), .reset_n(reset_n),
    .test_expr(count));
```

assert never

The assert_never checker continuously monitors the $test_expr$ at every positive edge of the triggering event or clock clk. It verifies that $test_expr$ will never evaluate true. The $test_expr$ can be any valid Verilog expression. When $test_expr$ evaluates true, this checker will fail.

Syntax

Arguments

test expr

Expression being verified at the positive edge of clk.

Notes

 If the test_expr contains any x or z values then the checkers is effectively disabled and the assertion

```
assert_never_contains_x_z_value will fire.
```

• There are no cover properties or cover groups in thie checker. Therefore the coverage-level_i parameters are not provided.

```
'define ASSERT_ON
module testbench;
reg reset_n, clk;
child CH (reset_n, clk);
initial begin
    clk = 0;
    reset_n = 0;
    #40 reset_n = 1;
```

```
#980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
req [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0 || count <= 9)
        count <= 4'b1011;</pre>
    else
        count <= count + 1;</pre>
end
assert never #(0, 0, "ERROR: count within 0 and 9")
valid expr (clk, reset n,
  (count >= 4'b0000) && (count <= 4'b1001));
endmodule
```

```
assert_never #(.severity_level(0),.options(0),
  .msg("ERROR: count within 0 and 9"),
valid_expr (.clk(clk),.reset_n(reset_n),
  .test_expr((count >= 4'b0000) && (count <= 4'b1001));</pre>
```

assert next

The assert_next checker validates proper cycle timing relationships between two events in the design. When a start_event evaluates true, then the test_expr must evaluate true exactly num_cks number of clock cycles later.

This checker supports overlapping sequences. For example, if you assert that $test_expr$ will evaluate true exactly four cycles after $start_event$, it is not necessary to wait until the sequence finishes before another sequence can begin.

Syntax

Arguments

num cks

The number of clocks <code>test_expr</code> must evaluate to true after <code>start_event</code> is asserted.

check overlapping

If true, permits overlapping sequences. In other words, a new start_event can occur (starting a new sequence in parallel) while the previous sequence continues.

only if

If true, a test_expr can only evaluate true, if preceded num_cks earlier by a start_event. If test_expr occurs without a start_event, then an error is flagged.

start event

Starting event that triggers monitoring of the test expr.

```
test expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
   Cover property, cover_start_event, indicates that the
    start_event occurred.

cov_level_1_1 (bit 1 set in coverage_level_1) :
   Cover property, cover_next, indicates that the test_expr became
   true exactly after num_cks from the start_event.

cov_level_3_0 (bit 0 set in coverage_level_3) :
   Cover property, cover_overlapping_start_events, indicates
   that a start_event occured while there was another evaluation
   in progress.
```

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;
child CH (reset_n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset_n = 0;
    #40 reset_n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
```

endmodule

```
module child(reset n, clk);
input reset n, clk;
reg start, expr;
integer count;
initial $monitor ("count = %d start = %b expr = %b\n",
count, start, expr);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        start <= 0;
        expr <= 0;
        count <= 0;
    end
    else
        count <= count + 1;</pre>
    if (count == 4)
        start <= 1;
    else
        start <= 0;
    if (count == 8)
        expr <= 1;
    else
        expr <= 0;
end
//Cover property, cover start event at level 1 enabled
assert next #(0, 4, 0, 1, 0, "ERROR: expr is not true within
the specified number of clock cycles after start event", 0,
invalid next (clk, reset n, start, expr);
endmodule
```

```
assert_next #(.severity_level(0),num_cks(4),
  check_overlapping(0), only_if(1),.options(0),
  .msg("ERROR: expr is not true within the specified number of
  clock cycles after start_event"),.category(0),
  .coverage_level_1(1))
invalid_next (.clk(clk),.reset_n(reset_n),
  .start_event(start), .test_expr(expr));
```

assert_no_overflow

The assert_no_overflow checker continuously monitors the $test_expr$ at every positive edge of the triggering event or clock clk. This assertion verifies that a specified $test_expr$ will never:

 Change value from a max value (default (2**width) -1) to a value greater than max

or

• Change value from a max value (default (2**width) -1) to a value less than or equal to a min value (default 0).

The test expr can be any valid Verilog expression.

Syntax

Arguments

width

Width of the monitored expression test_expr.

min

Minimum value sampled at clock (t+1) of c1k with default value of 0.

max

Maximum value sampled at clock ($_t$) of clk with default value of (2**width-1).

```
test expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
Cover property, cover_nb_of_test_expr_changes, indicates that the test_expr changed value.

cov_level_2_0 (bit 0 set in coverage_level_2)
Cover point, cover_observed_value, reports all the values taken by test_expr

cov_level_3_0 (bit 0 set in coverage_level_3)
Cover property, cover_test_expr_reached_min_value, indicates that the test_expr reached the min parameter value.

cov_level_3_1 (bit 1 set in coverage_level_3)
Cover property, cover_test_expr_reached_max_value, indicates that the test_expr reached the max parameter value.
```

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;

child CH (reset_n, clk);

initial begin
    clk = 0;
    reset_n = 0;
    #20 reset_n = 1;
    #980 $finish;
end

always #10 clk = ~clk;
```

```
module child(reset n, clk);
input reset n, clk;
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 4'b0011;
    if (count >= 4'b0010 && count <= 4'b1001)
    begin
        case(count)
            4'b0010: count <= 4'b1010;
            4'b0011: count <= 4'b1011;
            4'b0100: count <= 4'b1100;
            4'b0101: count <= 4'b1101;
            4'b0110: count <= 4'b1110;
            4'b0111: count <= 4'b1111;
            4'b1000: count <= 4'b0000;
            4'b1001: count <= 4'b0010;
       endcase
    end
    else
    begin
        case(count)
            4'b1010: count <= 4'b0011;
            4'b1011: count <= 4'b0100;
            4'b1100: count <= 4'b0101;
            4'b1101: count <= 4'b0110;
            4'b1110: count <= 4'b0111;
            4'b1111: count <= 4'b1000;
            4'b0000: count <= 4'b1001;
            4'b0001: count <= 4'b0010;
       endcase
    end
end
//Coverage level 1 enabled by default
```

```
assert_no_overflow #(0, 4, 2, 9, 0, "ERROR: count changed
from max (9) value to a value either > max (9) or <= min (2)")
value_overflow (clk, reset_n, count);
```

endmodule

Name-based Example

```
assert_no_overflow #(.severity_level(0),.width(4),
   .min(2),.max(9),.options(0),.msg("ERROR:count
   changed from max (9) value to a value either > max (9)
   or <= min (2)"))
value_overflow(.clk(clk),.reset_n(reset_n),
   .test_expr(count));</pre>
```

assert_no_transition

The assert_no_transition checker continuously monitors the $test_expr$ variable at every positive edge of the triggering event, positive clk edge. When this variable evaluates to the value of $start_state$, the monitor ensures that $test_expr$ will never transition to the value of $next_state$. The width parameter defines the size (that is, number of bits) of the $test_expr$.

Syntax

Arguments

width

Width of the monitored expression test expr.

test expr

Expression being verified at the positive edge of c1k.

start state

Triggering state of test expr.

next state

Invalid state for the machine represented by $test_expr$ when traversed from state $start_state$. The value of $next_state$ at the time when $test_expr$ becomes equal to $start_state$ is that used for comparison with $test_expr$ even when $test_expression$ changes to a new value in subsequent cycles.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property, cover_nb_of_times_start_state_occured,
   indicates that test_expr was set to the value specified in
   start_state.

cov_level_2_0 (bit 0 set in coverage_level_2) :
   Cover point, observed_hold_time, records the number of clk
   cycles the test_expr remained in start_state before making a
   transition to another state other than next_state.
```

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    clk = 0;
   reset n = 0;
   #40 reset n = 1;
   #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [3:0] count, start, next;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
```

endmodule

Name-based Example

```
assert_no_transition
#(.severity_level(0),.width(4),.options(0),
.msg("ERROR: count has reached the next state of 9 from the
start state of 3"), .category(0), .coverage_level_1(0),
.coverage_level_2(1),
transition_stop (.clk(clk),.reset_n(reset_n),
.test_expr((count),.start_state(start),.next_state(next));
```

assert_no_underflow

The assert_no_underflow checker continuously monitors the $test_expr$ at every positive edge of the triggering event or clock clk. This assertion verifies that $test_expr$ will never:

• Change value from a min value (default = 0) to a value less than min,

or

Change to a value greater than or equal to max (default (2**width) 1).

The test expr can be any valid Verilog expression.

Syntax

Arguments

width

Width of the monitored expression test expr.

min

Minimum value sampled at clock (t) of c1k with default value of 0.

max

Maximum value sampled at clock (t+1) of c1k with default value of (2**width - 1).

```
test expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
Cover property, cover_nb_of_test_expr_changes, indicates that the test_expr changed when enabled by reset_n.

cov_level_2_0 (bit 0 set in coverage_level_2)
Cover point, observed_value, records the values taken by test_expr

cov_level_3_0 (bit 0 set in coverage_level_3)
Cover property, cover_test_expr_reached_min_value, indicates that the test_expr changed to value equal to min.

cov_level_3_1 (bit 1 set in coverage_level_3)
Cover property, cover_test_expr_reached_max_value, indicates that the test_expr changed to value equal to max.
```

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;

child CH (reset_n, clk);

initial begin
    clk = 0;
    reset_n = 0;
    #40 reset_n = 1;
    #980 $finish;
end

always #20 clk = ~clk;
endmodule

module child(reset_n, clk);
input reset_n, clk;
```

```
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 4'b0011;
    if (count >= 4'b0010 && count <= 4'b1001)
    begin
        case(count)
            4'b0010: count <= 4'b0001;
            4'b0011: count <= 4'b1011;
            4'b0100: count <= 4'b1100;
            4'b0101: count <= 4'b1101;
            4'b0110: count <= 4'b1110;
            4'b0111: count <= 4'b1111;
            4'b1000: count <= 4'b0000;
            4'b1001: count <= 4'b0010;
       endcase
    end
    else
    begin
        case (count)
            4'b1010: count <= 4'b0011;
            4'b1011: count <= 4'b0100;
            4'b1100: count <= 4'b0101;
            4'b1101: count <= 4'b0110;
            4'b1110: count <= 4'b0111;
            4'b1111: count <= 4'b1000;
            4'b0000: count <= 4'b1001;
            4'b0001: count <= 4'b0010;
       endcase
    end
end
//Coverage level 3 enabled
assert no underflow #(0, 4, 2, 9, 0, "ERROR: count changed
from min (2) to a value either < min (2) or >= max (9)", 0,
0, 0, 0)
value underflow (clk, reset n, count);
```

```
assert_no_underflow #(.severity_level(0),.width(4),
   .min(2),.max(9),.options(0),.msg("ERROR:count changed
from min (2) to a value either < min (2) or >= max (9) "),
   .category(0), .coverage_level_1(0),
   .coverage_level_2(0),.coverage_level_3(0))
value_underflow(.clk(clk),.reset_n(reset_n),
   .test_expr(count));
```

assert_odd_parity

The assert_odd_parity checker monitors for odd number of '1's in $test_expr$ at every positive edge of the clock, clk. The $test_expr$ can be any valid Verilog expression.

Syntax

Arguments

width

Width of the monitored expression test expr.

```
test expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
Cover property cover_test_expr_change indicates that the
test expr changed value.
```

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;
child CH (reset_n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
```

```
#40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [6:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        count <= 7'b1111111;</pre>
    end
    else
        count <= count << 1;</pre>
end
//There are 7 bits in test expr
//By default Level 1 //coverage is enabled
assert odd parity #(0, 7, 0,
  "ERROR: count does not have an odd number of bits asserted")
valid count odd (clk, reset_n, count);
endmodule
```

```
assert_odd_parity #(.severity_level(0),.width(7),
.options(0),.msg("ERROR:count does not have an odd number
of bits asserted"))
valid_count_odd(.clk(clk),.reset_n(reset_n),
```

.test_expr(count));

assert_one_cold

The assert_one_cold checker ensures that the variable, test_expr, has only one bit low at any positive clock edge when the checker is configured for no inactive states.

The checker can also be configured to accept all bits equal to either 0 or 1 as the inactive level.

The test_expr can be any valid Verilog expression.

Syntax

Arguments

width

Width of the monitored expression test expr.

inactive

Specifies the inactive state of test_expr.

If *inactive* is set to 0, then this checker acts like a zero_one_cold checker (that is, the inactive state of *test_expr* is all zeroes).

If *inactive* is set to 1, then this checker acts like a <code>one_one_cold</code> checker (that is, the inactive state is all ones).

The default value (that is, 2) specifies that there is no inactive state (that is, always one_cold).

```
test expr
```

Expression being verified at the positive edge of clk.

Coverage Modes

```
Cov_level_1_0 (bit 0 set in coverage_level_1)

Cover property cover_test_expr_change indicates that the 
test_expr changed value.

cov_level_2_0 (bit 0 set in coverage_level_2)

Cover point bit_is_0_after_a_change reports which bit in 
test_expr was 0 at least once after a change of test_expr value.

cov_level_2_1 (bit 1 set in coverage_level_2)

Cover property cover_test_expr_with_all_1 indicates that the 
test_expr was all 1s. Enabled when inactive == 1.

cov_level_2_2 (bit 2 set in coverage_level_2)

Cover property cover_test_expr_with_all_0 indicates that the 
test_expr was all 0s. Enabled when inactive == 0.

cov_level_3_0 (bit 0 set in coverage_level_3)

Cover property cov_level_3[i].cover_test_expr_bit_is_0 
indicates that bit i of test_expr was 0 when test_expr changed
```

Example

value.

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;
child CH (reset_n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset_n = 0;
    #40 reset_n = 1;
    #980 $finish;
end
```

```
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
req [7:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 8'b11111110;</pre>
    else
        count <= ((count << 1) | {7'b0000000, count[7]});</pre>
end
//The check is done on count having 8 bits, inactive is 0
//Level 1 coverage is enabled by default.
assert one cold #(0, 8, 0, 0, "ERROR: count is not one-cold")
  invalid one cold (clk, reset n, count);
endmodule
```

```
assert_one_cold #(.severity_level(0),.width(8),
   .inactive(0),.options(0),.msg("ERROR: count is not one
   cold"))
invalid_one_cold(.clk(clk),.reset_n(reset_n),
   .test_expr(count));
```

assert one hot

The assert_one_hot checker ensures that the variable, test_expr, has only one bit set to 1 at any positive clock clk edge. The test expr can be any valid Verilog Expression.

Syntax

Arguments

width

Width of the monitored expression *test_expr*.

```
test_expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property cover_test_expr_change indicates that the
   test_expr changed value.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2)
   Cover point cover_test_expr_bit_is_1 indicates which bit in
   test_expr was 1 at least once after a change of test_expr value.
```

```
cov_level_3_0 (bit 0 set in coverage_level_3)
  Cover property
  test_expr_bit_is_1[i].cover_test_expr_bit_is_1 indicates
  that bit i of test_expr was 1 when test_expr changed value.
```

```
'define ASSERT ON
```

```
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [7:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
        count <= 8'b00000001;
    else
        count <= ((count << 1) | {7'b0000000, count[7]});</pre>
end
//The width of count is 8 bits
//Coverage Level 1 is enabled by default.
assert one hot #(0, 8, 0, "ERROR: count is not one-hot")
invalid one hot (clk, reset n, count);
endmodule
```

```
assert_one_hot #(.severity_level(0),.width(8),
   .inactive(0),.options(0),.msg("ERROR:count is not
   one-hot"))
invalid_one_hot(.clk(clk),.reset_n(reset_n),
   .test expr(count));
```

assert_proposition

The assert_proposition checker continuously monitors the <code>test_expr</code>. Hence, this assertion is unlike <code>assert_always</code>; that is, <code>test_expr</code> is not being sampled by a clock. This <code>assert_proposition</code> assertion verifies that <code>test_expr</code> will always evaluate true. If <code>test_expr</code> evaluates to false while <code>reset_n</code> is 1, an assertion will fire (that is, an error condition will be detected in the code). The <code>test_expr</code> can be any valid Verilog expression.

Syntax

Arguments

test_expr
Expression being verified.

Note

There is no cover property or cover group in this checker. Therefore the coverage level i parameters are not provided.

```
'define ASSERT_ON
module testbench;
reg reset_n, clk, sig;
child CH (reset_n, sig);
initial begin
    clk = 0;
    reset_n = 0;
    sig = 0;
    #80 reset_n = 1;
```

```
#980 $finish;
end
always #20 clk = ~clk;
always #40 sig = ~sig;
endmodule
module child(reset n, sig);
input reset n, sig;
reg [3:0] count;
initial $monitor("time = %d count = %b \n", $time, count);
always @(sig)
begin
    if (reset_n == 0 | count >= 9)
        count <= 4'b0000;
    else
        count <= count + 1;</pre>
end
assert proposition
#(0, 0, "ERROR: count not within 3 and 9, both inclusive")
valid proposition
(reset n, (count >= 4'b0011) && (count <= 4'b1001));
endmodule
```

```
assert_proposition #(.severity_level(0),.property_type(0),
.msg("ERROR:count not within 3 and 9, both inclusive"),
valid_proposition(.reset_n(reset_n),
.test_expr(count >= 4'b0011) && (count <= 4'b1001));</pre>
```

assert_quiescent_state

The assert_quiescent_state checker verifies that the value in the variable, state_expr, is equal to the value specified by <code>check_value</code> and optionally at the end of simulation using the macro <code>`ASSERT_END_OF_SIMULATION</code>. Verification occurs when a sampled rising edge (as sampled by <code>clk</code>) is detected on <code>sample_event</code>.

Syntax

Arguments

width

Width of the monitored expression state expr.

state_expr

Expression being verified at the positive edge of c1k.

check value

Specifies value for state_expr when quiescent. (i.e., a signal that holds the value to be compared with state_expr when sample event is asserted).

sample event

Triggers the quiescent state check when a sampled rising edge is detected (as sampled by c1k).

`ASSERT END OF SIMULATION

This macro can be used to quiescent the state expression at the end of simulation. For example:

+define+ASSERT_END_OF_SIMULATION=top.sim_end
If this macro is associated with a signal it will trigger when this
signal raises (sampled transition by the clock).

Coverage Modes

cov_level_1_0 (bit 0 set in coverage_level_1)
 Cover property cover_quiescent_state indicates that the
 quiescent state was reached

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk, sig;
child CH (reset n, clk, sig);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    sig = 0;
    #80 \text{ reset n} = 1;
    #980 $finish;
end
always #20 clk = ~clk;
always #40 sig = ~sig;
endmodule
module child(reset n, clk, sig);
input reset n, clk, sig;
reg [3:0] count, value;
initial $monitor(" sig = %b count = %b \n", sig, count);
```

```
always @(posedge clk)
begin
    if (reset_n == 0)
    begin
        count <= 4'b0000;
        value <= 4'b0100;</pre>
    end
    else
        count <= count + 1;</pre>
    if (count >= 9)
        count <= 1'b0;
end
//Coverage level 1 enabled by default
assert quiescent state #(0, 4, 0, "ERROR: count not equal
to 4 when sampled on posedge of event sig")
valid q state (clk, reset n, count, value, sig);
endmodule
```

```
assert_quiescent_state #(.severity_level(0),.width(4),
  .property_type(0),.msg("ERROR:count not equal to 4 when
  sampled on posedge of event sig"))
valid_q_state(.clk(clk),.reset_n(reset_n),
  .state_expr(count),.check_value(value),
  .sample event(sig));
```

assert_range

The assert_range checker continuously monitors the <code>test_expr</code> at every positive edge of the triggering event, clk. The checker ensures that the value of <code>test_expr</code> will always be within the <code>min</code> and <code>max</code> value range. The <code>min</code> and <code>max</code> should be a valid parameter and <code>min</code> must be less than or equal to <code>max</code>. The <code>test_expr</code> can be any valid Verilog expression.

Syntax

Arguments

width

Width of the monitored expression test expr.

min

Minimum value allowed for range check. Default = 0.

max

Maximum value allowed for range check. Default = (2**width - 1).

est expr

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
Cover property, cover_nb_of_test_expr_changes, indicates that
the test expr changed value.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2)
   Cover point, cover_observed_value, reports all the values taken
by test_expr
```

cov_level_3_0 (bit 0 set in coverage_level_3)
 Coverproperty, cover_test_expr_reached_min_value, indicates
 that the test_expr reached the min parameter value.

```
cov_level_3_1 (bit 1 set in coverage_level_3)
Coverproperty, cover_test_expr_reached_max_value, indicates
that the test expr reached the max parameter value.
```

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [3:0] count;
initial $monitor("count = %b \n", count);
always @(posedge clk)
begin
    if (reset n == 0)
```

```
begin
        count <= 4'b0010;
    end
    if (count >= 4'b0010 && count <= 4'b1001)
    begin
        case(count)
            4'b0010: count <= 4'b1010;
            4'b0011: count <= 4'b1011;
            4'b0100: count <= 4'b1100;
            4'b0101: count <= 4'b1101;
            4'b0110: count <= 4'b1110;
            4'b0111: count <= 4'b1111;
            4'b1000: count <= 4'b0000;
            4'b1001: count <= 4'b0001;
       endcase
    end
    else
    begin
        case (count)
            4'b1010: count <= 4'b0011;
            4'b1011: count <= 4'b0100;
            4'b1100: count <= 4'b0101;
            4'b1101: count <= 4'b0110;
            4'b1110: count <= 4'b0111;
            4'b1111: count <= 4'b1000;
            4'b0000: count <= 4'b1001;
            4'b0001: count <= 4'b0010;
       endcase
    end
end
//Coverage level 2 enabled
assert range
#(0, 4, 2, 9, 0, "ERROR: count not within 2 and 9", 0, 0, 1, 0)
valid range (clk, reset n, count);
endmodule
```

```
assert_range
#(.severity_level(0),.width(4),.min(2),.max(9),
   .options(0),.msg("ERROR: count not within 2 and 9"),
   .category(0), .coverage_level_1(0),
   .coverage_level_2(10), .coverage_level_3(0))
valid_range(.clk(clk),.reset_n(reset_n),.test_expr(count))
:
```

assert time

The assert_time checker continuously monitors the start_expr. When this signal (or expression) evaluates true, the assertion monitor ensures that the test_expr evaluates to true for the next num cks number of clocks.

Syntax

Arguments

num cks

The number of clocks $test_{expr}$ must evaluate to true after start event is asserted.

flag

- 0 Ignores any asserted start_event after the first one has been detected (default);
- 1 Re-start monitoring test_expr if start_event is asserted in any subsequent clock while monitoring test expr;
- 2 Issue an error if an asserted start_event occurs in any clock cycle while monitoring test_expr.

```
start event
```

Starting event that triggers monitoring of the test_expr.

```
test expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property cover_start_event indicates that there was a
   start_event asserted.

cov_level_1_1 (bit 1 set in coverage_level_1)
   Cover property cover_time indicates that there was a match.

cov_level_3_0 (bit 0 set in coverage_level_3)
   Cover property cover_overlapping_start_events indicates that there were overlapping start events.
```

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
   clk = 0;
   reset n = 0;
   #40 reset n = 1;
   #1000 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg start, expr;
integer count;
initial $monitor ("count = %d start = %b expr = %b \n",
```

```
count, start, expr);
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        start <= 0;
        expr <= 0;
        count <= 0;
    end
    else
        count <= count + 1;</pre>
    if (count == 4)
        start <= 1;
    else
        start <= 0;
     if (count == 4 | count == 5 | count == 6 | count == 7 | count == 8 | count == 9)
        expr <= 1;
    else
        expr <= 0;
end
//The time interval is 4 clock cycles
//Restart checking on start event
//Coverage levels 1 and 3 are enabled
assert time \#(0, 4, 1, 0,
    "ERROR: expr not true within 4 cycles after start",
     0, 15, 0, 15)
valid time (clk, reset n, start, expr);
The time interval is 4 clock cycles, restart checking on
start event and coverage levels 1 and 3 are enabled
* /
endmodule
```

```
assert_time #(.severity_level(0),.num_cks(4),
   .flag(1),.options(0),.msg("ERROR: expr not true
   within4 cycles after start"),.category(0),
   .coverage_level_1(15),.coverage_level_2(0),
   .coverage_level_3(15))
valid_time(.clk(clk),.reset_n(reset_n),
   .start_event(start),.test_expr(expr));
```

assert transition

The assert_transition checker continuously monitors the $test_expr$ variable at every positive edge of the triggering event, clk. When $test_expr$ evaluates to the value of $start_state$, the checker ensures that $test_expr$ will always change to the value of $next_state$. The width parameter defines the size (that is, number of bits) of the $test_expr$.

Syntax

Arguments

width

Width of test expr with default value of 1.

```
test expr
```

State variable representing finite-state machine (FSM) being checked at the positive edge of *clk*.

```
start state
```

Triggering state of test_expr. The start_state value should be different from the next state value.

```
next state
```

Next valid state for machine represented by $test_expr$ when traversed from state start state.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
```

Cover property, cover_nb_of_times_start_state_occured, indicates that the test_expr entered the start_state.

cov_level_1_1 (bit 1 set in coverage_level_1)
 Cover property, cover_nb_of_transitions, indicates that the
 test_expr entered the start_state and made a transition to the
 next_state.

cov_level_2_0 (bit 0 set in coverage_level_2)

Cover point, observed_hold_time, reports the number of clk

cycles the test_exprremained in the start_state before making
a transition to the next_state.

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset_n, clk);
initial begin
   clk = 0;
   reset n = 0;
   #40 reset n = 1;
   #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [3:0] count, start, next;
initial $monitor("count = %b \n", count);
```

```
always @(posedge clk)
begin
    if (reset n == 0)
    begin
        count <= 4'b0000;
        start <= 4'b0011;
        next <= 4'b1001;
    end
    else
        count <= count + 4'b0001;</pre>
    if (count == 4'b0011)
        count <= 4'b0111;
end
//Cover point cov level 1 1 enabled at level 1
assert transition #(0, 4, 0, "ERROR: count did not reach the
next state of 9 from the start state of 3", 0, 2, 0, 0)
valid transition (clk, reset n, count, start, next);
endmodule
```

Name-based Example

```
assert_transition #(.severity_level(0), width(4),
  .property_type(0), .msg("ERROR: count did not reach the
  next state of 9 from the start state of 3"),.category(0),
  .coverage_level_1(2), .coverage_level_2(0),
  .coverage_level_3(0))
valid_transition (.clk(clk),.reset_n(reset_n),
  .test_expr(count),.start_state(start),
  .next_state(next));
```

assert_unchange

The assert_unchange checker continuously monitors the start_event at every positive edge of the triggering event, clk. When this signal (or expression) evaluates true, the checker ensures that the test_expr will not change values within the next num_cks number of clock cycles.

Syntax

Arguments

width

Width of the expression, test expr. Default = 1.

num cks

Number of clock cycles for $test_expr$ to change its value before an error is triggered after $start_event$ is asserted. Default = 1.

flag

- 0 Ignore any start_event assertion after the first one has been detected. Default = 0.
- 1 Re-start monitoring test_expr, if start_event is asserted in any subsequent clock while monitoring test expr.
- 2 Issue an error if an asserted <code>start_event</code> occurs in any clock cycles while monitoring <code>test_expr</code>.

```
start event
```

Starting event that triggers monitoring of the test_expr.

```
test expr
```

Expression or variable being verified at the positive edge of clk.

Coverage Modes

```
Cover property cover_start_event indicates that the start_event was asserted.

cov_level_1_1 (bit 1 set in coverage_level_1)
Cover property cover_unchange indicates that the test_expr remained stable the required time interval.

cov_level_3_0 (bit 0 set in coverage_level_3)
Cover property cover_overlapping_start_events indicates that a start event occurred while a previously triggered evaluation
```

Example

attempt was still in progress.

```
module child(reset n, clk);
input reset n, clk;
reg start;
reg [3:0] expr;
integer count;
initial $monitor ("count = %d start = %b expr = %b \n",
count, start, expr);
always @(posedge clk)
    begin
    if (reset n == 0)
    begin
         start <= 0;
         expr <= 4'b0000;
         count <= 0;
    end
    else
         count <= count + 1;</pre>
    if (count == 3)
         start <= 1;
    else
         start <= 0;
    if (count == 3 | count == 4 | count == 5)
         expr <= 4'b0110;
    else
         expr <= expr + 1;
// Coverage Level 2 selected by default
assert unchange #(0, 4, 4, 1, 0, "ERROR:test_expr changed
within 4 clock cycles")
valid unchange (clk, reset n, start, expr);
endmodule
```

The value of expr should not change within 4 clock cycles after start. expr has 4 bits and flag = 1, i.e., RESET ON START is requested. Coverage Level 1 is enabled by default. Since expr changes changes after 3 clock cycles the assertion will fire.

Name-based Example

```
assert_unchange #(.severity_level(0), width(4), num_cks(4),
  flag(1),.options(0), .msg("ERROR: test_expr changed
  within 4 clock cycles"))
valid_unchange (.clk(clk),.reset_n(reset_n),
  .start_event(start),.test_expr(expr));
```

assert width

The assert_width checker continuously monitors the test_expr. When this signal (or expression) evaluates true, it ensures that the test_expr evaluates to true for a specified minimum number of clock cycles and does not exceed a maximum number of clock cycles.

Syntax

Arguments

min cks

Specifies the minimum number of clock cycles where test_expr should be true. If the test_expr goes false before min_cks, then an error occurs. The default value is 1.

max cks

Specifies the maximum number of clock cycles where <code>test_expr</code> can be true. If set to 0, then there is no maximum check (any value is valid). If the <code>test_expr</code> is true for more than <code>max_cks</code>, then an error occurs. The default value is 1.

```
test expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
   Cover property, cover_nb_of_test_expr_posedges, indicates
   that a postive edge was observed on the test_expr.
```

```
cov level 1 1 (bit 1 set in coverage level 1) :
```

Cover property, <code>cover_width</code>, indicates that the <code>test_expr</code> was asserted for a duration defined by the <code>min_cks</code> and <code>max_cks</code> parameters.

```
Cover point, cover_observed_hold_time, reports the observed numbers of clock cycles for which the test_expr was asserted.

cov_level_3_0 (bit 0 set in coverage_level_3):
    Cover property,
    cover_test_exp_change_exactly_after_min_cks, indicates that the test_expr was sampled deasserted after being asserted for exactly min_cks clock ticks.

cov_level_3_1 (bit 1 set in coverage_level_3):
    Cover property,
    cover_test_exp_change_exactly_after_max_cks, indicates that the test_expr was sampled deasserted after being asserted that the test_expr was sampled deasserted after being asserted
```

Example

```
'define ASSERT_ON
'define COVER_ON
module testbench;
reg reset_n, clk;
child CH (reset_n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset_n = 0;
    #40 reset_n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
```

for exactly max cks clock ticks.

endmodule

```
module child(reset n, clk);
input reset n, clk;
reg expr;
integer count;
initial $monitor ("time = %d expr = %b, count = %d \n",
$time, expr, count);
always @(posedge clk)
begin
     if (reset n == 0)
     begin
         expr <= 0;
         count <= 0;
     end
     else
         count <= count + 1;</pre>
    if (count == 4 | count == 5 | count == 6 | count == 7)
         expr <= 1;
     else
         expr <= 0;
end
//Coverage is disabled on this instance
assert width #(0, 0, 4, 0, "ERROR: expr is not true for the
             specified number of clock cycles", 0, 0, 0, 0)
valid width (clk, reset n, expr);
endmodule
```

Name-based Example

```
assert width #(.severity level(0), min cks(0), max cks(4),
```

```
.options(0), .msg("ERROR: expr is not true for the
specified number of clock cycles"),.category(0),
.coverage_level_1(0), .coverage_level_2(0),
.coverage_level_3(0))
valid_width (.clk(clk),.reset_n(reset_n),
.test expr(expr));
```

assert_win_change

The assert_win_change checker continuously monitors the start_event at every positive edge of the triggering event, clk. When this signal (or expression) evaluates true, it ensures that the test_expr changes values prior to and including the end_event.

Syntax

Arguments

width

Width of test_expr with default value of 1.

start event

Starting event that triggers monitoring of the test expr

test expr

Expression being verified at the positive edge of clk.

end event

Event that terminates monitoring of a start event.

Coverage Modes

```
cov_level_1_0 (bit 0 is set in coverage_level_1)
   Cover property, cover_nb_of_start_events, indicates that the
   start_event was sampled high.
```

```
cov_level_1_1 (bit 1 is set in coverage_level_1)
   Cover property, cover_win_change, indicates that the test_expr
   changed value before and including the end_event.
```

cov_level_2_0 (bit 0 is set in coverage_level_2)
 Cover point, cover_observed_hold_time, reports the numbers of
 clock cycles for which the test_expr remained unchanged after
 the start event occurred.

```
cov_level_3_0 (bit 0 is set in coverage_level_3)
   Cover property,
```

cover_test_exp_change_exactly_at_end_event, indicates that a change on the test_expr was sampled at the same time as the end_event occurred.

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg start, expr, end event;
integer count;
initial $monitor ("expr = %b, start = %b end event = %b count
= %d \n", expr, start, end event, count);
```

```
always @(posedge clk)
begin
     if (reset n == 0)
     begin
         start <= 0;
         expr <= 0;
         end event <= 0;
         count <= 0;
     end
     else
         count <= count + 1;</pre>
     if (count == 4)
         start <= 1;
     else
         start <= 0;
     if (count == 7)
         expr = 1;
     if (count == 8)
         end event <= 1;
     else
         end event <= 0;
end
//Coverage level 1 enabled by default
assert win change #(0, 1, 0, "ERROR: expr did not change
                   even once between start and end events")
valid win change (clk, reset n, start, expr, end event);
endmodule
```

Name-based Example

```
assert_win_change #(.severity_level(0), width(1),
    .options(0), .msg("ERROR: expr did not change even
    once between start and end events"))
```

```
valid_win_change (.clk(clk),.reset_n(reset_n),
   .start_event(start),.test_expr(expr));
```

assert_win_unchange

The assert_win_unchange checker continuously monitors the start_event at every positive edge of the triggering event, clk. When this signal (or expression) evaluates true, it ensures that the test_expr will not change in value up to and including the end event.

Syntax

Arguments

width

Width of test expr with default value of 1.

start event

Starting event that triggers monitoring of the test_expr

test expr

Expression being verified at the positive edge of c1k.

end event

Event that terminates monitoring of a start_event.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
    Cover property, cover_nb_of_start_events, indicates that
    start_event was asserted.

cov_level_1_1 (bit 1 set in coverage_level_1)
```

Cover property, <code>cover_win_unchange</code>, indicates that <code>test_expr</code> remained stable for the duration between a <code>start_event</code> and an <code>end_event</code> including the arrival of <code>end_event</code>.

- cov_level_2_0 (bit 0 set in coverage_level_2)
 Cover point, observed_end_event_time, records the number of
 clock cycles between a start_event and the subsequent
 end_event.
- cov_level_3_0 (bit 0 set in coverage_level_3)
 Cover property,
 cover_test_expr_changes_exactly_after_end_event,
 indicates that the test expr changed at the clock tick just after

an end event.

assert window

The assert_window checker continuously monitors the start_event at every positive clock edge clk. When the start_event evaluates true, it ensures that the test_expr evaluates true at every successive positive clock edge clk up to and including the end event expression.

Note: This assertion does not evaluate <code>test_expr</code> on <code>start_event</code>, it begins evaluating on the next positive clock edge <code>clk</code>.

Syntax

Arguments

```
start event
```

Starting event that triggers monitoring of the test_expr

```
test expr
```

Expression being verified at the positive edge of clk.

```
end event
```

Event that terminates monitoring of a start_event.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
    Cover property, cover_nb_of_start_events, indicates that
    start_event was asserted.

cov_level_1_1 (bit 1 set in coverage_level_1)
```

Cover property, cover_window, indicates that test_exprremained asserted for the duration between a start_event and an end event including the arrival of end event.

```
cov_level_2_0 (bit 0 set in coverage_level_2)
   Cover point, observed_end_event_time, records the number of
   clock cycles between a start_event and the subsequent
   end_event.

cov_level_3_0 (bit 0 set in coverage_level_3)
   Cover property,
   cover_window_terminates_exactly_after_end_event,
   indicates that the test_expr was deasserted at the clock tick just
   after an end_event.
```

Example

```
'define ASSERT ON
'define COVER ON
module testbench:
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #1000 $finish;
end
always #20 clk = ~clk;
endmodule.
module child(reset n, clk);
input reset n, clk;
```

```
reg start, expr, end_event;
integer count;
initial $monitor ("expr = %b, start = %b end event = %b count
= %d \n", expr, start, end_event, count);
always @(posedge clk)
begin
     if (reset n == 0)
     begin
         start <= 0;
         expr <= 0;
         end event <= 0;
         count <= 0;
     end
     else
         count <= count + 1;</pre>
     if (count == 4)
         start <= 1;
     else
         start <= 0;
     if ((count >= 5 && count <= 8))
         expr = 1;
     else
         expr = 0;
     if (count == 8)
         end event <= 1;
     else
         end event <= 0;
end
//Coverage level 3 enabled
assert window #(0, 1, "ERROR: expr did not remain true at
every clock edge between start and end events", 0, 0, 0, 1)
valid window (clk, reset n, start, expr, end event);
endmodule
```

Name-based Example

```
assert_window #(.severity_level(0),.options(1),
   .msg("ERROR: expr did not remain true at every clock edge
between start and end events"),.category(0),
   .coverage_level_1(0), .coverage_level_2(0),
   .coverage_level_3(1))
valid_window (.clk(clk),.reset_n(reset_n),
   .start_event(start),.test_expr(expr),
   .end_event(end_event));
```

assert_zero_one_hot

The assert_zero_one_hot checker continuously monitors the test_expr at every positive edge of the triggering event, clk. It verifies that $test_expr$ will have exactly one bit asserted or no bit asserted, otherwise, an assertion will fire (that is, an error condition will be detected in the code). The $test_expr$ can be any valid Verilog expression.

Syntax

Arguments

width

Width of the monitored expression test expr.

```
test expr
```

Expression being verified at the positive edge of c1k.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property cover_test_expr_change indicates that the
   test_expr changed value.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2)
Cover property cover_test_expr_with_all_0 indicates that the
all 0 value occurred when test expr changed value.
```

```
cov_level_2_1 (bit 1 set in coverage_level_2)
   Cover point bit_is_1_after_a_change reports which bits in
   test expr were set to 1 at least once.
```

```
cov_level_3_0 (bit 0 set in coverage_level_3)
   Cover property
   test_expr_bit_is_1[i].cover_test_expr_bit_is_1 indicates
   that bit i was 1 after change of value.
```

Example

```
'define ASSERT ON
'define COVER ON
module testbench;
reg reset n, clk;
child CH (reset n, clk);
initial begin
    $vcdpluson;
    clk = 0;
    reset n = 0;
    #40 reset n = 1;
    #980 $finish;
end
always #20 clk = ~clk;
endmodule
module child(reset n, clk);
input reset n, clk;
reg [7:0] count;
initial begin
    $monitor("count = %b \n", count);
end
always @(posedge clk)
begin
    if (reset n == 0 | count == 8'b00000000)
        count <= 8'b00000001;
    else
        count <= ((count << 1) | {7'b0, count[7]});</pre>
```

```
if (count == 8'b10000000)
          count <= 8'b00000000;
end

//The tested expression count is 8 bits wide.
//Coverage level 1 enabled by default
assert_zero_one_hot #(0, 8, 0, "ERROR: count is not one-hot")
valid_zero_one_hot (clk, reset_n, count);
endmodule</pre>
```

Name-based Example

```
assert_zero_one_hot #(.severity_level(0),.width(8),
   .options(0),.msg("ERROR: count is not one-hot"))
valid_zero_one_hot (.clk(clk),.reset_n(reset_n),
   .test expr(count));
```

3

SVA Advanced Checkers

The 2nd part of the checker library contains 22 checkers plus an sva_std_edge_select.v file that contains an interface definition that is instantiated in all these new checkers and computes the appropriate clock edge.

The new checkers use the same controls as the SVL checkers in the previous chapter, but in addition they have a clock edge selection parameter, <code>edge_expr</code>.

Checker Descriptions

This section provides syntax and descriptions, and examples for all checkers.

Shared Syntax

Many checkers share the same syntax elements. In addition to using severity_level, reset_n, clk, msg and $coverage_level_i$, where i = 1, 2, or 3, described in Chapter 1, the checkers in this chapter can select the active edge of the clock:

```
edge_expr
```

Specifies the active edge for the clock signal (clk) in unit syntax. Use the following values to specify the edge type:

posedge: 0 (the default)

- negedge: 1

If edge_expr is not specified, it defaults to posedge.

assert arbiter

Ensures that a resource arbiter provides grants to corresponding requests within min lat and max lat cycles.

The checks are not enabled unless $reset_n$ evaluates true at the time of the request. The checks are performed on the active clk edge specification.

Syntax

Arguments

no_chnl

The number of channels (bits) in requests and grants. Default = 2.

bw prio

The number of bits that are used to encode $req_priority$. Default = 1.

grant one chk

If true, then the unit will check to ensure that only one grant is issued per clock cycle. Default = 1.

req priority chk

If true, then this checker will ensure that grants are issued according to the priority indicated in the $req_priority$ vector. $req_priority_chk$. $req_priority_chk$ functions on top of any other scheme using $arbitration_rule$. That is, if priority and, say, FIFO is selected then first priority arbitration is applied and if multiple requests exist at the highest priority level, the final selection must satisfy the FIFO rule.

If $req_priority_chk$ is 0 (disabled), then $req_priority$ is not taken into account in any of the other checks. However, the argument $req_priority$ must still have the correct dimension even though the actual values do not matter (e.g., pass vector of 0's). The $req_priority$ vector may be a design vector (i.e., not a constant array). However, while a request is being processed the $req_priority$ should not change, otherwise certain checks may produce incorrect results (success or failure). Default = 0.

arbitration rule

Selects which arbitration algorithm is verified among fairness, FIFO or least-recently used (LRU). It must be a compile-time constant.

```
arbitration_rule = 0 - no rule checked
arbitration_rule = 1 - fairness (round-robin)
arbitration_rule = 2 - FIFO
arbitration_rule = 3 - LRU
```

If fairness is selected, then this checker will ensure that no channel will be issued more than one grant while other channels have requests pending except if this is the only request at the highest $req_priority$ when $req_priority_chk$ is asserted.

If FIFO is selected, then this checker will ensure that grants are issued according to the order that their requests were received unless $req_priority_chk$ is asserted which means that the FIFO check is performed only on requests of the current highest $req_priority$.

If LRU is selected, then this checker will ensure that grants are issued to the least recently granted request. If $req_priority_chk$ is also asserted than LRU is applied to (simultaneous) highest priority requests. Note that initially, all requests are assumed to have happened equally in the past, so that the selection between them is arbitrary until granted at least once.

min lat

The minimum global grant latency. Default = 1.

If 0, then the grant is expected starting the same cycle as the request (i.e., combinational arbiter is possible with $max_lat = 0$). If priority arbitration check is enabled, then min_lat should be 0 or 1 only.

max lat

If $max_{lat} > 0$, it specifies the maximum global grant latency regardless of the selection criterion. That is, a persistent request must be granted within max_{lat} clock cycles. The check is useful in systems where a request must be granted within a certain latency even in the presence of other requests.

If $max \ 1at = 0$, the global latency check is disabled. Default = 0.

reqs

Requests signals as vectors.

Vector of size $[no_chn1-1:0]$ where the bits correspond to the corresponding channels in reqs. req is assumed to be 1 when active.

req priority

A [bw_prio*no_chnl-1 : 0] bitvector of bw_prio*no_chnl bits formed by concatenating non-negative integer req_priority values corresponding to the request lines. The right-most bw_prio bits in req_priority corresponds to channel 0, etc. The req_priority value 0 is the lowest req_priority.

grants

Grants signals as vectors. Vector of size $[no_chnl-1:0]$ where the bits correspond to the corresponding channels in grants. Assumed to be 1 when active.

Assumptions

When $req_priority_chk = 0$ it is assumed that the $req_priority$ vector is set to all 0 values.

It is preferrable that $min_lat > 0$ when $req_priority_chk = 0$, i.e., combinational response is possible only in $req_priority$ - based arbitration.

A grant is expected to be one clock cycle wide, unless the grant is for more than one consecutive request.

It is assumed that a request holds asserted until granted. It is assumed that a request is removed on the clock tick the grant is sampled, unless another request is immediately asserted. Its removal before a grant causes the grant to be cancelled, and this does cancel the check for a grant.

Failure modes

Upon failure assertion assert_arbiter_one_cycle_gnt[i] will report <code>!grants[i]</code> as the failing expression meaning that in position <code>i</code> the grant signal was not deasserted on the next cycle.

Assertion assert_arbiter_req_granted[i] will report failure when in position i the grant signal did not arrive within the specified latency.

Assertion assert_arbiter_granted_only_if_req[i] will report failure when in position i the grant signal occurred without a request being asserted at the same time.

Assertion assert_arbiter_highest_grant[i] will report failure when line i the granted request was not that of the highest req_priority.

Assertion assert_arbiter_fifo_chk[i][j] will report failure if on line j the grant was asserted before the grant on line i while the requests came in the opposite order.

Assertion assert_arbiter_two_active[i][j], a failure means that although there were continuous requests on lines i and j, the grant on line i arrived twice without a grant on line j.

Assertion assert_arbiter_single_grant will report failure there were more than one grant at the same time.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1)
 Cover property cover_arbiter_req_granted indicates there
 were granted requests for each channel
- cov_level_2_0 (bit 0 set in coverage_level_2)
 Cover property loop_A[i].cover_abandoned_reqindicates there
 were abandoned requests, for each channel
- cov_level_2_1 (bit 1 set in coverage_level_2)

 Cover point observed_latency indicates which request-to-grant latency within the range min-max occurred at least once.
- cov_level_2_2 (bit 2 set in coverage_level_2) :
 Cover point, concurrent_requests, reports which multiplicity of
 concurrent requests occurred. It is sampled when a grant to one
 of the requests is issued.
- cov_level_3_0 (bit 1 set in coverage_level_3)
 Cover property Cover property
 cover_req_granted_exactly_after_min_lat indicates how
 many times the req-to-grant latency was exactly equal to the
 specified min_lat value.
- cov level 3 1 (bit 2 set in coverage level 3)

Cover property

loop_A[i].cover_req_granted_exactly_after_max_lat
indicates how many times the req-to-grant latency was exactly
equal to the specified max lat value.

Example

The instance

```
assert_arbiter #(0, 2, 1, 1, 1, 0, 1, 5, 0, "arbiter failed", 0, 15, 15, 0)
arbiter inst (clk, 1, requests, 2'b1 0, grants);
```

There are 2 request and 2 grant lines, enabled all the time, $req_priority$ is 0 for channel 0 and 1 for channel 1, encoded over one bit; $grant_one_chk=1$, $req_priority_chk=1$, $arbitration_rule=0$, $min_lat=1$, $max_lat=5$. Signals are sampled at posedge clk. The (optional) message is "arbiter failed" and it is output in addition to the standard simulator message. Coverage levels 1 and 2 are enabled.

Name-based Example

```
assert_arbiter #(.severity_level(0),.no_chnl(2),
.bw_prio(1),.grant_one_chk(1),.req_priority_chk(1),
.arbitration_rule(0),.min_lat(1),.max_lat(5),
.edge_expr(0),.msg("arbiter failed"),.category(0),
.coverage_level_1(15),.coverage_level_2(15),
.coverage_level_3(0))
arbiter_inst (.clk(clk),.reset_n(1),.reqs(requests),
.req_priority(2'bl_0),.grants(grants));
```

assert_bits

Ensures that the value of exp has between min and max number of bits that are asserted or deasserted as indicated by the asserted flag. To specify a single number and not a range, use min = max.

Syntax

Arguments

min

Minimum number of bits asserted or deasserted. Valid values of constant parameters: min, max must be non-negative integers. Default = 1.

max

Maximum number of bits asserted or deasserted. Valid values of constant parameters: min, max must be non-negative integers. Default = 1.

asserted

If deasserted evaluates true, then the check is to ensure that the specified number or range of bits in exp is 1. Otherwise, the check is to ensure the specified number or range of bits in exp is 0. Default = 1, meaning that the test is for bits set to 1.

exp_bw

The number of bits in *exp*.

Failure Modes

Upon failure, if asserted = 1, then failure indicates that the number of bits set to 1 in exp was not in the interval [min, max], and if deasserted = 1, then failure indicates that the number of bits set to 0 was not in the specified interval.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1)
 Cover property cover_bits_exp_change indicates that the exp
 changed.
- cov_level_1_1 (bit 1 set in coverage_level_1)
 Cover property cover_bits indicates that the number of bits
 asserted was within the min : max range.
- cov_level_3_0 (bit 0 set in coverage_level_3)
 Cover property cover_min_bits_asserted indicates that the
 number of bits set was exactly equal to the specified min value.
- cov_level_3_1 (bit 1 set in coverage_level_3)

 Cover property cover_max_bits_asserted indicates the number of times the number of bits set was exactly equal to the specified max value.

Example

This example verifies that exp of width 4 has between 1 and 3 bits set to 0. The checker is always enabled because $reset_n$ is 1 and exp is sampled at posedge clk. Coverage levels 1 and 3 are enabled.

```
assert_bits #(0, 1, 3, 0, 4, 5 , "bits failed", 0, 15, 0, 15)
    bits_inst ( clk, 1, exp);
```

Name-based Example

```
assert_bits #(.severity_level(0),.min12),
   .max(3),.asserted(0),.exp_bw(4),.edge_expr(5),
   .msg("bits failed"),.category(0),.coverage_level_1(15),
   .coverage_level_2(0),.coverage_level_3(15),
bits_inst (.clk(clk),.reset_n(1),.exp(exp));
```

assert code distance

Ensures that when exp changes, the number of bits that are different compared to exp2 are at least min but no more than max in number. The check is not enabled unless $reset_n$ evaluates true. The check is performed on the active c1k edge specification.

Syntax

Arguments

min

The minimum number of bits that are different (must be non-negative integer). min <= max. Default = 1.

max

The maximum number of bits that are different. Default = 1.

bw

The number of bits in exp and exp2. Default = 2.

exp

Signal being tested.

exp2

Signal that the signal under test (exp) is compared to.

Failure Modes

The assertion assert_code_distance will report failure when the expressions differ in more bits than the value of the max parameter or less than the min parameter.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1)
 Cover property cover_exp_change indicates that the exp changed
 value.
- cov_level_1_1 (bit 1 set in coverage_level_1)
 Cover property cover_code_distance_match indicates that the
 code distance was within the specified interval when exp changed.
- cov_level_2_0 (bit 0 set in coverage_level_2)
 Cover point observed_code_distance reports which code
 distances occured at least once.
- cov_level_3_0 (bit 0 set in coverage_level_3)
 Cover property cover_code_distance_eq_to_min indicates that
 the observed code distance was exactly equal to the specified min
 value.
- cov_level_3_1 (bit 1 set in coverage_level_3)
 Cover property cover_code_distance_eq_to_max indicates that
 the observed code distance was exactly equal to the specified max
 value.

Example

```
assert_code_distance #(0, 1, 3, 4, 0, "bad code", 0, 15, 15, 15)
cd_inst ( clk, 1, exp1, exp2);
```

Reports failure when the number of different bits is not within the interval 1 to 3 at positive edge of c1k. exp1 and exp2 are 4 bits wide. Coverage levels 1, 2 and 3 are enabled.

Name-based Example

```
assert_code_distance #(.severity_level(0),.min(1),
   .max(3),.bw(4),.edge_expr(0),.msg("bad code"),
   .category(0), .coverage_level_1(15),
   .coverage_level_2(15),.coverage_level_3(15))
cd inst (.clk(clk),.reset_n(1),.exp(exp1),.exp2(exp2));
```

assert data used

Ensures that data from src[sleft:sright] appears in dest[dleft:dright] within the window specified as start cycles from after the time trigger is asserted until finish number of cycles after trigger is asserted. The checks are not enabled unless $reset_n$ evaluates true. The checks are performed on the active clk edge specification.

Syntax

Arguments

sleft

The most significant bit of the source signal's (src) bit slice. Default = 1.

sleft - sright should be equal to dleft - dright otherwise some
bits would be lost or compared with 0

sright

The least significant bit of the source signal's (src) bit slice. Default = 0.

dleft

The most significant bit of the destination signal's (dest) bit slice. Default = 1.

dright

The least significant bit of the destination signal's (dest) bit slice. Default = 0.

Note: sleft - sright should be equal to dleft - dright; otherwise some bits would be lost or compared with 0

start

The number of cycles after the trigger signal (trigger) asserts to start the window. Default = 1.

Note that the specified number must be greater than or equal to 1.

finish

The number of cycles after the trigger signal (trigger) asserts to stop the window. Default = 1.

Note that the specified number must be greater than or equal to 0.

start = m, m>0, and finish = 0 means that the open-ended interval [m:\$] is to be used. Note that if this is the case, the assertion cannot be falsified.

trigger

Signal that triggers the start of the window.

src

Source signal.

dest

Destination signal.

Failure Modes

Upon failure the reported failing expression by the assertion sva_data_used is #[start:finish] (dest[dleft:dright] == sva_v_src_value) where sva_v_src_value is a variable that stores the original src value needed for the comparison.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property, cover_nb_of_times_trigger_asserted,
   indicates that trigger was asserted.
```

```
cov_level_1_1 (bit 1 set in coverage_level_1)
  Cover property, cover_data_used, indicates that the data from
  src[sleft:sright] appeared in dest[dleft:dright] within the
  specified window.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2)
Cover property, observed_delay, records the delay observed
between a trigger and the subsequent arrival of the data at
    dest[dleft:dright].
```

```
cov_level_3_0 (bit 0 set in coverage_level_3)
   Cover property,
```

cover_data_used_exactly_after_start_clk_cycles, indicates that data arrived at <code>dest[dleft:dright]</code> start number of clock cycle after a <code>trigger</code> was asserted.

```
cov_level_3_1 (bit 1 set in coverage_level_3)
   Cover property,
   cover_data_used_exactly_after_finish_clk_cycles,
   indicates that data arrived at dest[dleft:dright]finish number
   of clock cycle after a trigger was asserted.
```

Example

The transfer is triggered by the signal <code>load</code>, from <code>data[15:3]</code> to <code>out_reg[12:0]</code>, and it has to happen within 1 to 3 clock cycles. All 3 coverage levels are enabled.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_data_used #(.severity_level(0),.sleft(15),
   .sright(3),.dleft(12),.dright(0),
   .start(1),.finish(3),.edge_expr(0),
   .msg("data not used"),.category(0),
   .coverage_level_1(15),.coverage_level_2(15),
   .coverage_level_3(15)
   data_used_inst (.clk(clk),.reset_n(1),.trigger(load),
   .src(data),.dest(out reg));
```

assert driven

Ensure that all bits of exp are driven (none are floating z or x). The check is not enabled unless $reset_n$ evaluates true (1). The check is performed on the active c1k edge specification.

Syntax

Arguments

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Signal being tested.

Coverage Mode

```
cov_level_2_0 (bit 0 set in coverage_level_2)
Cover point, cover_observed_driven_X_or_Z, indicates which
bits were either x or z at any point of time during the simulation.
```

NOTE: Since the default coverage is always level 1, this coverage is not enabled by default! There is no coverage at level 1 and at level 3.

Example

```
assert_driven #(0, 16, 1, "bad X or Z", 0, 1, 0)
driven inst (clk, 1 , sig);
```

It will report a failure when at least one bit in the 16-bit bitvector exp was X or Z. Sampling is on negedge of clk due to edge_expr = 1. Coverage statistics for the level 2 will be generated by default.

NOTE: When this checker is used with SV Compiler for formal tools, the assertion is removed because the tool uses only 2-state signal values (case equality === with 1'bx is not synthesizable).

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_driven #(.severity_level(0),.bw(16),
   .edge_expr(1),.msg("bad X or Z"),.category(0),
   .coverage_level_1(1),.coverage_level_2(0),
   .coverage_level_3(0))
driven inst (.clk(clk),.reset n(1),.exp(sig));
```

assert dual clk fifo

Implements a checker for a dual-clock, single in- and single out-port queue.

Syntax

Arguments

depth

The maximum number of elements in the queue. Default = 2. The specified depth can be at most 2^{16} .

elem sz

The size of queue elements in bits. Default = 1.

```
hi water mark
```

If hi_water_mark is a positive value, then the level of the fill of the queue after enqueue will be checked to see if hi_water_mark is exceeded. Once high water has been exceeded once, this check is disabled until the FIFO size decreases again to or below the mark. If $hi_water_mark = 0$ then the high-water mark check is disabled and only overflow is checked, i.e., when the depth of the queue is exceeded (provided that $oflow_chk = 1$). Default = 0, check disabled.

eng lat

A compile-time non-negative integer constant that indicates the number of cycles between enq being asserted 1 and enq_data being valid in the corresponding position. At that point all enqueue data is dropped and further checking is disabled until dequeue occurs. If an enqueue and dequeue happen simultaneously then no overflow is reported. Default = 0.

deq lat

The number of deq_clk cycles between deq being asserted 1 and deq_data being valid. Default = 0.

oflow chk

When an enq bit is asserted 1: If $oflow_chk$ evaluates true, ensures that queue does not overflow the max size given in depth. depth (maximum size = t 2**16). Default = 1.

uflow chk

When a deq bit is asserted 1:if $uflow_chk$ evaluates true, ensures that queue was not empty (underflow); if a dequeue on empty is detected, then the check is disabled until the next enqueue operation. Default = 1.

value chk

If $value_chk$ evaluates true, ensures deq_data as selected by the same position as the highest priority deq bit is the same as that at the head of the queue. Default = 1.

eng edge expr

The active clock edge of eng clk. Default = 0.

deq_edge_expr

The active clock edge of deq_clk. Default = 0.

eng clk

Clock signal that synchronizes the enqueue side of the queue.

enq

When enq is asserted 1: If oflow_chk evaluates true, ensures that queue does not overflow the max size given in depth. The specified depth can be at most 2**16.

enq data

Data being enqueued.

deq clk

Clock signal that synchronizes dequeue side of the queue.

deq

Set to 1 when data is being dequeued.

deq data

Data being dequeued compared with the value at the head of the queue.

Failure Modes

Assertion assert_fifo_dcq_overflow will report a failure when enq is issued while the FIFO is full.

Assertion assert_fifo_dcq_underflow will report a failure when the dequeue command is issued and the FIFO is empty at that time.

Assertion assert_fifo_dcq_value_chk will report failure when there is a dequeue, the FIFO is not empty and the dequeued data does not match that on deq_data port..

Assertion assert_fifo_dcq_hi_water_chk will report a failure if the FIFO is filled above the high-water mark.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1)
 Coverproperty cover_number_of_enqs indicates that an enqueue
 occurred.
- cov_level_1_1 (bit 1 set in coverage_level_1) :
 Cover property, cover_number_of_deqs, indicates that a dequeue
 occurred.
- cov_level_1_2 (bit 2 set in coverage_level_1)
 Cover property cover_enq_followed_eventually_by_deq
 indicates that an enqueue was followed later by a dequeue.
- cov_level_2_0 (bit 0 set in coverage_level_2)

 Cover point observed_outstanding_contents indicates the fill levels reached at least once, sampled whenever the FIFO occupancy changed.
- cov_level_3_0 (bit 0 set in coverage_level_3)
 Cover property cover_fifo_hi_water_chk that the high water
 mark was reached on an enqueue.
- cov_level_3_1 (bit 1 set in coverage_level_3)
 Cover property cover_number_of_empty indicates that empty was
 reached on dequeue.
- cov_level_3_2 (bit 2 set in coverage_level_3)
 Cover property cover_number_of_full indicates that full was
 reached on enqueue.

Example

It will reset the queue when $reset_n$ is 0 (must cover at least one posedge (by default) eclk and one negedge dclk), the number of elements in the FIFO is 10, high-water mark is disabled by default, the data size is 16 bits, all checks (overflow, underflow and value) are enabled, there is only the default message. All 3 coverage levels are enabled.

assert_fifo

Implements a checker for a single-clock, single in- and single outport queue.

Syntax

Arguments

depth

The maximum number of elements in the queue. Default = 2. The specified depth can be at most 2^{16} .

elem sz

The size of queue elements in bits. Default = 1.

```
hi water mark
```

If hi_water_mark is a positive value, then the level of the fill of the queue after enqueue will be checked to see if hi_water_mark is exceeded. Once high water has been exceeded once, this check is disabled until the FIFO size decreases again to or below the mark. If $hi_water_mark = 0$ then the high-water mark check is disabled and only overflow is checked, i.e., when the depth of the queue is exceeded (provided that $oflow_chk = 1$). Default = 0, check disabled.

enq lat

A compile-time non-negative integer constant that indicates the number of cycles between enq being asserted 1 and enq_data being valid in the corresponding position. At that point all enqueue data is dropped and further checking is disabled until dequeue occurs. If an enqueue and dequeue happen simultaneously then no overflow is reported. Default = 0.

deq lat

The number of deq_clk cycles between deq being asserted 1 and deq_data being valid. Default = 0.

oflow chk

When an enq bit is asserted 1: If $oflow_chk$ evaluates true, ensures that queue does not overflow the max size given in depth. depth (maximum size = t 2**16). Default = 1.

uflow chk

When a deq bit is asserted 1:if $uflow_chk$ evaluates true, ensures that queue was not empty (underflow); if a dequeue on empty is detected, then the check is disabled until the next enqueue operation. Default = 1.

value chk

If $value_chk$ evaluates true, ensures deq_data as selected by the same position as the highest priority deq bit is the same as that at the head of the queue. Default = 1.

pass thru

If an enqueue and dequeue operation happens simultaneously on an empty queue, then the behavior depends on the *pass_thru* parameter (it must be a compile-time constant):

If $pass_thru = 0$ then the dequeue happens before enqueue, hence the empty condition is detected and reported and an underflow (provided that $uflow_chk = 1$). If $value_chk = 1$ then the value check fails. Default = 0.

If pass_thru = 1 then it is assumed that enqueue happens first and the data is immediately dequeued and compared with deq_data if value_chk is enabled. Also, there is no underflow error reported.

If an enqueue and a dequeue operation happen simultaneously on a full queue then no overflow is reported and the new element is enqueued while the element at the head of the queue is dequeued without changing the size of the queue.

enq

When enq is asserted 1: If $oflow_chk$ evaluates true, ensures that queue does not overflow the max size given in depth. The specified depth can be at most $2^{**}16$.

eng data

Data being enqueued.

dea

Set to 1 when data is being dequeued. When deq is asserted 1: If $uflow_chk$ evaluates true, ensures that queue was not empty (underflow). If a dequeue on empty is detected then the check is disabled until the next enqueue operation.

deg data

Data being dequeued.

Failure Modes.

Assertion assert_fifo_overflow will report a failure when enq is issued while the FIFO is full.

Assertion assert_fifo_underflow will report a failure when the deq command is issued delayed by deq_lat and the FIFO is empty at that time (and no simultaneous enq with pass_thru is enabled).

Assertion assert_fifo_value_chk will report (sva_v_q[sva_v_head_ptr] == deq_data)) as the failing expression when there is a dequeue and the FIFO is not empty and the data does not correspond to the expected value. It will report (enq_data == deq_data) as the failing expression if there is a dequeue and pass_thru is enabled (=1), otherwise if there is a dequeue on an empty FIFO it is a failure.

Assertion assert_fifo_hi_water_chk will report a failure if the FIFO fill crosses the high-water mark.

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
Cover property cover_number_of_enqs indicates that there was
an enqueue operation.
```

```
cov_level_1_1 (bit 1 set in coverage_level_1)
   Cover property cover_number_of_deqs indicates that there was
   a dequeue operation.
```

```
cov_level_1_2 (bit 2 set in coverage_level_1)
Cover property cover_simultaneous_enq_deq indicates the
number of simultaneous enqueue and dequeue operations.
```

```
cov level 1 3 (bit 3 set in coverage level 1)
```

Cover property <code>cover_enq_followed_eventually_by_deq</code> matches whenever there is an enqueue followed eventually by a dequeue.

- cov_level_2_0 (bit 0 set in coverage_level_2)
 Cover point observed_outstanding_contents reports which
 FIFO fill levels have been reached at least once.
- cov_level_3_0 (bit 0 set in coverage_level_3)
 Cover property cover_fifo_hi_water_chk indicates that the high
 water mark was reached on an enqueue.
- cov_level_3_1 (bit 1 set in coverage_level_3)

 Cover property cover_simultaneous_enq_deq_when_empty
 indicates that there were simultaneous enqueue and dequeue
 operations on an empty queue.
- cov_level_3_2 (bit 2 set in coverage_level_3)
 Cover poperty cover_simultaneous_enq_deq_when_full
 indicates that there were simultaneous enqueue and dequeue
 operations on a full queue.
- cov_level_3_3 (bit 3 set in coverage_level_3)
 Cover property cover_number_of_empty indicates that empty was
 reached on dequeue.
- cov_level_3_4 (bit 4 set in coverage_level_3)
 Cover property cover_number_of_full indicates that full was
 reached on enqueue.

Example:

A FIFO is initialized anytime reset is 1 (synchronously with posedge clk). There are up to 10 elements in the FIFO, the size of the data is 16 bits, $high_water$ mark is by default 0 (disabled), $data_in$ is enqueued when enqueue is 1 with no latency, $data_out$ must be equal to that at the head of the FIFO when dequeue is 1 with latency, and overflow, underflow and value checks are enabled with pass through when empty is allowed. All 3 coverage levels are enabled.

assert hold value

Ensure that exp remains at value for min to max number of cycles. That is, it must stay at value for min cycles, then it may change and after max cycles it must change to some other value. bw is the bit width of exp.

The check is not enabled unless $reset_n$ evaluates true (1). The check is performed on the active c1k edge specification and is triggered by a value change of exp to value.

min = max = 0 means that exp will change every cycle (i.e., keeps the value for one cycle).

```
min = max = 1 means that exp will keep value for two cycles.
```

A value min > 0 and max = 0 is interpreted as the open-ended interval [min:\$].

Syntax

Arguments

min

Minimum number of clock cycles to hold the value. Default = 0.

max

Maximum number of clock cycles to hold the value. Default = 0.

For an open-ended interval [min ...], set max equal to zero and min to greater than zero.

bw

The number of bits in the signal being tested (exp). Default = 2.

exp

Expression or signal being tested.

value

Value to hold by exp.

Failure Modes

The assertion assert_hold_value will report failure if exp does not hold the value for at least min+1 clock ticks or if it does not change from value at max+1 clock ticks at the latest.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1) :
 Cover property, cover_nb_of_exp_changes, indicates that the exp
 changed value.
- cov_level_2_0 (bit 0 set in coverage_level_2) :
 Cover point, observed_hold_time, reports the observed number
 of clock cycles during which exp was held at value triggered
 whenever there was a transition on exp to value.
- cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property, cover_hold_value_for_min_clks, indicates that
 the exp was held exactly equal to value for the specified min_clks.
- cov_level_3_1 (bit 1 set in coverage_level_3) :
 Cover property, cover_hold_value_for_max_clks, indicates that
 the exp was held exactly equal to value for the specified max_clks.

Example

```
assert_hold_value #(0, 3, 0, 4, 1,
"hold value error",0,15,15,0)
```

```
hold_value_inst ( clk, 1, sig, 4'h5);
```

A failure is reported if sig did not stay at 5 for at least 4 clock ticks. Since max = 0 there cannot be a failure on sig not changing from the value of 5 because the interval [3:0] is translated into the openended interval [3:\$].

All Level_1 and Level_2 coverages are enabled.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_hold_value #(.severity_level(0),.min(3),
.max(0),.bw(4),.edge_expr(1),.msg("hold_value_error"),
.category(0), .coverage_level_1(15),
.coverage_level_2(15),.coverage_level_3(0))
hold_value_inst (.clk(clk),.reset_n(1),.exp(sig),
.value(4'h5));
```

assert_memory_async

Ensures the integrity of an asynchronous memory contents and accesses.

Syntax

Arguments

data_bits

Number of bits in the data. Default = 1.

addr bits

Number of bits in the addresses. Default = 1.

mem sz

The number of words in the memory. Default = 2. The end_addr - start addr + 1 must be less than or equal to mem sz.

addr chk

If 1, checks that address is valid. Default = 1.

init chk

If 1, checks that addresses read have been previously written. Default = 1.

conflict chk

If 1, checks that simultaneous reading and writing of the same address does not occur. Default = 0.

This check should only be enabled when rclk = wclk. When the two clocks are different the conflict check does not make much sense.

pass thru

Specifies behavior when read and write happen at the same time on the same address. If 0, read gets the old data before the write. If 1, read gets the new data after the write. Default = 0.

read1 chk

If 1, checks that an address has at most one read between writes. Default = 0.

write1 chk

If 1, checks that an address is read at least once before it is overwritten. Default = 0.

value chk

If 1, checks that the value read from an address is the value that was written to that address. Default = 0.

w edge expr

The active clock edge of wclk . Default = 0, operation is indicated by negative edge.

r edge expr

The active clock edge of rclk. Default = 0, operation is indicated by negative edge.

start addr

Starting address of the memory.

end_addr

Ending address of the memory.

ren

Read enable.

raddr

Read address.

rdata

Read data.

wen

Write enable.

waddr

Write address.

wdata

Write data.

Note the following:

- When addr_chk evaluates true, ensures that start_addr ≤ raddr ≤ end_addr as sampled by the negedge of ren, and that start_addr ≤ waddr ≤ end_addr as sampled by the negedge of wen.
- There is thus no clock other than the ren and wen signals that indicate when each operation is to take place by their falling edges (i.e., it is assumed that they are positive pulses). This is the behavior when r_edge_expr (resp. w_edge_expr) is 0. When r_edge_expr is 1 (resp. w_edge_expr), the ren (resp. wen) signal is complemented and the positive edge of the (negative) pulse is used.
- Whenever the port reset_n is 0, it disables reading and writing to the memory.

- Al other checks apply only if the address is valid. Therefore, we recommend that addr chk be enabled.
- When init_chk evaluates true, ensures that addresses read Separate read and write port RAMs are naturally supported. For single port R/W RAMs, simply associated the same actuals with the appropriate parameters.
- the sampling is by negedge of ren (wen) if r_edge_expr (w_edge_expr) is 0 and by posedge of ren (wen) if r_edge_expr (w_edge_expr) is 1...

Failure Modes

Assertion assert_memory_async_init will report failure when the location was not initialized before reading as determined by negedge of ren if r_edge_expr is 0 and by posedge of ren if r_edge_expr is 1..

Assertion assert_memory_async_waddr_chk will report failure when the write address was not within the limits just before negedge of wen.

if w edge expr is 0 and by posedge of wen if w edge expr is 1.

if r_{edge_expr} (w_edge_expr) is 0 and by posedge of ren (wen) if r_{edge_expr} (w_edge_expr) is 1.

Assertion assert_memory_async_raddr_chk will report failure when the write address was not within the limits just before negedge of ren if r_edge_expr is 0 and by posedge of ren if r_edge_expr is 1.

Assertion assert_memory_read1_chk will report failure when the variables recording reads and writes indicated the same state as sampled by negedge of ren. Hence, there was more than one read between writes.

Assertion assert_memory_async_write1_chk will report failure if after the memory location was initialized the location was not read before the next write as sampled by negedg wen if w_edge_expr is 0 and by posedge of wen if w_edge_expr is 1.

Assertion assert_memory_async_val_chk will report failure if there is a disagreement between the value in the design rdata and that stored in the memory mirror as sampled by negedge of ren if r_edge_expr is 0 and by posedge of ren if r_edge_expr is 1.

The ren and wen signals are qualified by $reset_n$, i.e., no read or write takes place if $reset_n$ is asserted low (0).

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1) :
 Coverproperty, cover_number_of_reads, indicates that there was
 a read operation to any address.
- cov_level_1_1 (bit 1 set in coverage_level_1) :
 Cover property, cover_number_of_writes, indicates that there
 was a write operations to any address.
- cov_level_1_2 (bit 2 set in coverage_level_1) :
 Cover property, write_followed_by_read, indicates that there
 was a write followed by a read to the same address.
- cov_level_2_0 (bit 0 set in coverage_level_2) :
 Cover point, read, reports which addresses within the range
 [start addr : end addr] were read at least once.

- cov_level_2_1 (bit 1 set in coverage_level_2) :
 Cover point, write, reports which addresses within the range
 [start_addr : end_addr] were written at least once.
- cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property,
 - cover_two_or_more_writes_without_intervening_read, indicates that two writes occurred to the same (any) address without an intervening read operation to that address.
- cov_level_3_1 (bit 1 set in coverage_level_3) :
 Cover property,
- cover_two_or_more_reads_without_intervening_write, indicates that two reads occurred to the same (any) address without an intervening write operation to that address.
- cov_level_3_2 (bit 2 set in coverage_level_3) :
 Cover property, read_to_start_addr, indicates that a read
 operation occurred to the address start addr.
- cov_level_3_3 (bit 3 set in coverage_level_3)
 Cover property, write_to_start_addr, indicates that a write
 operation occurred to the address start_addr.
- cov_level_3_4 (bit 4 set in coverage_level_3) :
 Cover property, read_to_end_addr, indicates that a read
 operation occurred to the address end_addr.
- cov_level_3_5 (bit 5 set in coverage_level_3) :
 Cover property, write_to_end_addr, indicates that a write
 operation occurred to the address end_addr.
- cov_level_3_6 (bit 6 set in coverage_level_3) :
 Cover property, write_followed_by_read_to_start_addr, that
 there was a write operation followed by a read to the address
 start addr.

```
cov_level_3_7 (bit 7 set in coverage_level_3) :
   Cover property, write_followed_by_read_to_end_addr,
   indicates that there was a write operation followed by a read to
   the address end_addr.
```

Example

Memory accesses are to be checked with data and address width of 16 bits. The low address bound is 0, the high address bound is 16'h0fff, the memory size is 2**12 = 16'h1000. addr_chk, init_chk, read1_chk, write1_chk and value_chk are enabled. The default message is output upon failure. reset_n is 1, hence always enabled. Category is 0 by default. Since both w_edge_expr and r_edge_expr parameters are 0 by default, positive ren and wen pulses are assumed. Coverage Level 1 is enabled by default (all cover properties).

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_memory_async #(.severity_level(0),.data_bits(16),
    .addr_bits(16),.mem_sz(16'h1000),.addr_chk(1),
    .init_chk10),.read1_chk(1),.write1_chk(1),
    .value_chk(1))
mem_inst (.reset_n(1'b1),.start_addr(16'h0000),
    .end_addr(16'h0fff),.ren(ren),.raddr(addr),
    .rdata(rdata),.wen(wen),.waddr(addr),.wdata(wdata));
```

assert_memory_sync

Ensures the integrity of a synchronous memory contents and accesses.

Syntax

```
assert_memory_sync [#(severity_level, data_bits, addr_bits, mem_sz, addr_chk, init_chk, conflict_chk, pass_thru, read1_chk, write1_chk, value_chk, w_edge_expr, r_edge_expr, msg, category, coverage_level_1, coverage_level_2, coverage_level_3)]
inst_name (start_addr, end_addr, ren, raddr, rclk, rdata, wen, waddr, wclk, wdata);
```

Arguments

```
data bits
```

Number of bits in the data. Default = 1.

```
addr bits
```

Number of bits in the addresses. Default = 1.

```
mem sz
```

The number of words in the memory. Default = 2. The end_addr - start_addr + 1 must be less than or equal to mem_sz.

addr chk

If 1, checks that address is valid. Default = 1.

init chk

If 1, checks that addresses read have been previously written. Default = 1.

conflict chk

If 1, checks that simultaneous reading and writing of the same address does not occur. Default = 0.

This check should only be enabled when rclk == wclk. When the two clocks are different the conflict check does not make much sense.

pass_thru

Specifies behavior when read and write happen at the same time on the same address. If 0, read gets the old data before the write. If 1, read gets the new data after the write. Default = 0.

read1 chk

If 1, checks that an address has at most one read between writes. Default = 0.

write1 chk

If 1, checks that an address is read at least once before it is overwritten. Default = 0.

value chk

If 1, checks that the value read from an address is the value that was written to that address. Default = 0.

w edge expr

The active clock edge of wclk. Default = 0.

r_edge_expr

The active clock edge of rclk. Default = 0.

start addr

Starting address of the memory.

end addr

Ending address of the memory.

ren

Read enable.

raddr

Read address.

rclk

Read clock.

rdata

Read data.

wen

Write enable.

waddr

Write address.

wclk

Write clock.

wdata

Write data.

When addr_chk evaluates true, ensures that start_addr \le raddr \le end_addr when ren is true, and that start_addr \le waddr \le end_addr when wen is true. All other checks apply only if the address is valid. Therefore, we recommend that addr_chk be enabled.

When <code>init_chk</code> evaluates true, ensures that addresses read have been previously written.

When <code>value_chk</code> evaluates true, ensures that the value read from an address is the value that was written to that address.

A read/write conflict occurs when a read operation occurs simultaneous with a write operation on the same address. When a conflict occurs, a read is assumed to happen before a write in the same cycle.

When $conflict_chk$ evaluates true, ensures that simultaneous reading and writing of the same address does not occur. This check should only be enabled when rclk == wclk. When the two clocks are different the conflict check does not make much sense.

The pass_thru specification defines the behavior of the memory when a read and write occur simultaneously on the same address. When pass_thru = 0 then the read operation obtains the old data (before the write takes place). If pass_thru = 1, then the read operation gets the new value written in memory. Note that this option has effect only when value_chk or init_chk are enabled. Furthermore, pass_thru should only be enabled when rclk = wclk and conflict chk = 0.

When read1_chk evaluates true, ensures that an address has at most one read in between writes.

When write1_chk evaluates true, ensures that an address is read at least once before it is over-written by different data.

Separate read and write port RAMs are naturally supported. For single-port R/W RAMs, simply associate the same actuals with the appropriate parameters. For single clock synchronous RAMs, provide the same clock edge parameter for both rclk and wclk.

The parameters data_bits = number of bits in the data, addr_bits = number of bits in the addresses, start_addr = first address, end addr = last address, and mem sz = number of words, are

compile-time constant values which describe the layout of the memory. Note that end_addr - start_addr + 1 must be less than or equal to mem sz.

Failure Modes

Assertion assert_mem_init will report failure when the memory word was not initialized before reading and there was no simultaneous read and write with pass through allowed.

Assertion assert_mem_waddr_chk will report failure when the write address was not within the limits when wen was asserted.

Assertion assert_mem_raddr_chk will report failure when the read address was not within the limits when ren was asserted.

Assertion assert_mem_conflict_chk will report failure when wen and ren were asserted simultaneously and the write and read addresses were the same sampled by the write clock wclk.

Assertion assert_mem_read1_chk will report failure when at the time of failure the sva variables recording reads and writes indicated the same state. Hence there was more than one read between writes

Assertion assert_mem_write1_chk will report failure when after a memory location was initialized, neither the location was read before the next write nor there was a simultaneous read and write (as sampled by the write clock wclk) with pass thru disabled.

Assertion $assert_mem_val_chk$ will report failure when pass through is allowed and read and write happen at the same time (as sampled by the read clock rclk) to the same address and the data are not equal.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1)
 Cover property cover_number_of_reads indicates that a read
 operation occurred to any address.
- cov_level_1_1 (bit 1 set in coverage_level_1)
 Cover property cover_number_of_writes indicates that a write
 operation occurred to any address.
- cov_level_1_2 (bit 2 set in coverage_level_1)
 Cover property write_followed_by_read indicates that a write
 was followed by a read to the same address.
- cov_level_2_0 (bit 0 set in coverage_level_2)
 Cover point read indicates which addresses within the range
 start_addr: end_addr have been read at least once.
- cov_level_2_1 (bit 1 set in coverage_level_2)
 Cover point write indicates which addresses within the range
 start_addr:end_addr have been written at least once.
- cov_level_2_2 (bit 2 set in coverage_level_2)
 Cover point delay_from_read_to_write reports which delays
 were observed at least once from the last read in a sequence of
 reads to the nearest subsequent write.
- cov_level_2_3 (bit 3 set in coverage_level_2)
 Cover point delay_from_write_to_read reports which delays
 were observed at least once from the last write in a sequence of
 writes to the nearest subsequent read.
- cov_level_3_0 (bit 0 set in coverage_level_3)

Cover property

cover_two_or_more_writes_without_intervening_read indicates that two writes occurred to the same (any) address without an intervening read operation to that address.

cov_level_3_1 (bit 1 set in coverage_level_3)
 Cover property

cover_two_or_more_reads_without_intervening_write indicates that two reads occurred to the same (any) address without an intervening write operation to that address.

- cov_level_3_2 (bit 2 set in coverage_level_3)
 Cover property simultaneous_read_and_write_to_same_addr
 indicates that there were (quasi)simultaneous read and write
 operations to the same (any) address as seen by the read clock
 rclk.
- cov_level_3_3 (bit 3 set in coverage_level_3)
 Cover property

simultaneous_read_and_write_to_different_addr indicates that there were (quasi)simultaneous read and write operations to different addresses as seen by the read clock rclk.

- cov_level_3_4 (bit 4 set in coverage_level_3)
 Cover property read_to_start_addr indicates that read
 operations occurred to the address start addr.
- cov_level_3_5 (bit 5 set in coverage_level_3)
 Cover property write_to_start_addr indicates that operations
 occurred to the address start_addr.
- cov_level_3_6 (bit 6 set in coverage_level_3)
 Cover property read_to_end_addr indicates that read operations
 occurred to the address end addr.

- cov_level_3_7 (bit 7 set in coverage_level_3)
 Cover property write_to_end_addr indicates that write
 operations occurred to the address end_addr.
- cov_level_3_8 (bit 8 set in coverage_level_3)
 Cover property write_followed_by_read_to_start_addr
 indicates that a write operation was followed by a read to the
 address start_addr.
- cov_level_3_9 (bit 9 set in coverage_level_3)
 Coverproperty write_followed_by_read_to_end_addrindicates
 that a write operation was followed by a read to the address
 end_addr.

Example

Memory accesses are to be checked with data and address width of 16 bits, the low address bound is 0, the high address bound is 16'h0fff, the memory size is 2**12 = 16'h1000, the same clock is used for read and write, sampling by posedge in both cases (by default), addr_chk and init_chk are enabled by default, conflict_chk and pass_thru are enabled, read1_chk and write1_chk are disabled by default, and value_chk is enabled. The default message is output upon failure. By default coverage Level 1 is enabled.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert memory sync #(.severity level(1), .data bits(16),
```

```
.addr_bits(16), .mem_sz(16'h1000),.addr_chk(1),
.init_chk(1), .conflict_chk(1),.pass_thru(1),
.read1_chk(0), .write1_chk(0), .value_chk(1))
mem_inst (.start_addr(16'h0000), .end_addr(16'h0fff),
.ren(ren), .raddr(addr), .rclk(clk), .rdata(rdata),
.wen(wen), .waddr(addr), .wclk(clk), .wdata(wdata));
```

assert_multiport_fifo

Implements a checker for a single-clock, multi-port in and multiportout queue.

Syntax

```
assert_multiport_fifo [#(severity_level, depth, elem_sz, no_ports, hi_water_mark, enq_lat, deq_lat, oflow_chk, uflow_chk, value_chk, pass_thru, edge_expr, msg, category, coverage_level_1, coverage_level_2, coverage_level_3)]
inst_name (clk, reset_n, enq, enq_data, deq, deq_data);
```

Arguments

depth

The maximum number of elements in the queue. Default = 2. The specified depth can be at most 2^{16} . Default = 2.

elem sz

The size of queue elements in bits. Default = 1.

no ports

Number of ports. Default = 2.

hi water mark

If hi_water_mark is a positive value, then the level of the fill of the queue after enqueue will be checked to see if hi_water_mark is exceeded. Once high water has been reached once, this check is disabled until the FIFO size decreases again to or below the mark. If hi_water_mark = 0 then the high-water mark check is disabled and only overflow is checked, i.e., when the depth of the queue is exceeded (provided that oflow_chk = 1). Default = 0.

enq lat

A compile-time non-negative integer constant that indicates the number of cycles between enq being asserted 1 and enq_data being valid in the corresponding position. At that point all enqueue data is dropped and further checking is disabled until dequeue occurs. If an enqueue and dequeue happen simultaneously then no overflow is reported. Default = 0.

deq lat

The number of deq_clk cycles between deq being asserted 1 and deq_data being valid. Default = 0.

oflow chk

When an enq bit is asserted 1: If $oflow_chk$ evaluates true, ensures that queue does not overflow the max size given in depth. depth (maximum size = t 2**16). Default = 1.

uflow chk

When a deq bit is asserted 1:if $uflow_chk$ evaluates true, ensures that queue was not empty (underflow); if a dequeue on empty is detected, then the check is disabled until the next enqueue operation. Default = 1.

value chk

If $value_chk$ evaluates true, ensures deq_data as selected by the same position as the highest priority deq bit is the same as that at the head of the queue. Default = 1.

pass thru

If an enqueue and dequeue operation happens simultaneously on an empty queue, then the behavior depends on the *pass_thru* parameter (it must be a compile-time constant):

If $pass_thru = 0$ then the dequeue happens before enqueue, hence the empty condition is detected and reported and an underflow (provided that $uflow_chk = 1$). If $value_chk = 1$ then the value check fails. Default = 0.

If pass_thru = 1 then it is assumed that enqueue happens first and the data is immediately dequeued and compared with deq_data if value_chk is enabled. Also, there is no underflow error reported.

If an enqueue and a dequeue operation happen simultaneously on a full queue then no overflow is reported and the new element is enqueued while the element at the head of the queue is dequeued without changing the size of the queue.

enq and deq

Bit vectors of equal size no_ports . Each pair of corresponding bits in these vectors defines the enqueue and dequeue signals for a port. Their priority is such the bit 0 is the lowest priority, the highest order bit $no_ports-1$ is the highest priority. That is, the enqueue port and the dequeue port of the highest priority are processed at every c1k tick.

enq data

A concatenation of the data from the different ports. It is assumed that it is dimensioned as $[no_ports*elem_size-1:0]$, with data vectors appearing in the same order as the enq requests. Whenever a bit in enq is asserted 1, the corresponding data part in enq_dat must be valid after enq_lat clock cycles. Only the highest priority data is actually enqueued.

deq data

A concatenation of the data from the different ports. It is assumed that it is dimensioned as $[no_ports*elem_size-1:0]$, with data vectors appearing in the same order as the deq requests. Whenever a bit in deq is asserted 1, the corresponding data part in deq_dat must be valid after deq_lat clock cycles. The highest priority data is compared with the data at the head of the queue if $value\ chk$ evaluates true.

Failure Modes

Assertion assert_multiport_fifo_overflow will report a failure when enq is issued while the FIFO is full.

Assertion assert_multiport_fifo_underflow will report a failure when the *deq* command is issued and the FIFO is empty.

Assertion assert_multiport_fifo_value_chk will report failure when there is a dequeue and the FIFO is not empty and the dequeued value does not correspond to that on deg data.

Assertion assert_fifo_hi_water_chk will report a failure if the FIFO is filled above the high-water mark.

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
   Cover property, cover_number_of_engs, indicates that an
   enqueue operation occurred. The cover is incremented whenever
   enq > 0.

cov_level_1_1 (bit 1 set in coverage_level_1) :
   Cover property, cover_number_of_degs, indicates that a dequeue
   operation occurred. The cover is incremented whenever deq > 0.

cov_level_1_2 (bit 2 set in coverage_level_1) :
```

Cover property, <code>cover_port_enqued</code>, indicates for each port separately that that an enqueue operation occurred.

- cov_level_1_3 (bit 3 set in coverage_level_1) :
 Cover property, cover_port_dequed, indicates for each port
 separately that that a dequeue operation occurred.
- cov_level_1_4 (bit 4 set in coverage_level_1):

 Cover property,

 cover_enq_followed_eventually_by_deq_per_port, indicates

 for each port that a successful enq on a port was followed

 eventually by a successful deq.
- cov_level_2_0 (bit 0 set in coverage_level_2) :
 Cover point, observed_outstanding_contents, reports on the
 FIFO fill levels that occurred at least once.
- cov_level_2_1 (bit 1 set in coverage_level_2) :
 Cover property, cover_ignored_enque, indicates for each port
 whether an enqueue was ignored due to other higher priority
 requests.
- cov_level_2_2 (bit 2 set in coverage_level_2) :
 Cover property, cover_ignored_deque, indicates for each port
 whether a dequeue was ignored due to other higher priority
 requests.
- cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property, cover_fifo_hi_water_chk, indicates that the
 high water mark was reached on an enqueue.
- cov_level_3_1 (bit 1 set in coverage_level_3) :
 Cover property, cover_simultaneous_enq_deq_on_same_port,
 indicates for each port that successful enqueue and dequeue
 happened at the same time.

```
cov_level_3_2 (bit 2 set in coverage_level_3) :
   Cover property,
```

cover_simultaneous_enq_deq_on_different_port, indicates that successful enqueue and dequeue happened simultaneously on different ports.

- cov_level_3_3 (bit 3 set in coverage_level_3) :
 Cover property, cover_simultaneous_enq_deq_when_empty,
 indicates that there were successful simultaneous enqueue and
 dequeue operations on an empty queue.
- cov_level_3_4 (bit 4 set in coverage_level_3) :
 Cover poperty, cover_simultaneous_enq_deq_when_full,
 indicates that there were successful simultaneous enqueue and
 dequeue operations on a full queue.
- cov_level_3_5 (bit 5 set in coverage_level_3) :
 Cover property, cover_number_of_empty, indicates that empty
 queue was reached on a dequeue.
- cov_level_3_6 (bit 6 set in coverage_level_3) :
 Cover property, cover_number_of_full, indicates that full queue
 was reached on enqueue.

Example:

In this example, a FIFO is initialized anytime reset is 0 (synchronously with posedge clk); there are up to 10 elements in the FIFO; high_water mark is by default 0 (disabled); the size of the data is 16 bits; there are two channels (by default, i.e., enqueue, dequeue are 2-bit wide, data_in and data_out are bitvectors of

2*16 = 32 bits); data_in [16*i+:16] is enqueued when enqueue[i] is 1 with no latency; data_out [16*i+:16] must be equal to that at the head of the FIFO when dequeue[i] is 1 with no latency; and overflow, underflow and value checks are enabled by default with pass through when empty is allowed. All level 3 coverages are enabled.

assert_mutex

Ensures that a and b never evaluate true at the same time. The check is not enabled unless $reset_n$ evaluates true (1). The checks is performed on the active c1k edge specification.

Syntax

Arguments

a First signal being tested.

b

Second signal being tested.

Failure Modes

The assertion assert_mutex will report failure when a and b are both sampled 1 at the positive edge of c1k.

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property cover_changes_on_a indicates that a changed
   value.
```

```
cov_level_1_1 (bit 1 set in coverage_level_1)
    Cover property cover_changes_on_b indicates that b changed
    value.
```

Example

```
assert mutex mutex inst( clk, 1, gnt[0], gnt[1]);
```

In this example, $assert_mutex$ verifies that gnt[0] and gnt[1] are never 1 at the same time as sampled by posedge of clk. The checker is always enabled because $reset_n$ is constant 1. By default Level 1 coverages will be enabled.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_mutex mutex_inst
(.clk(clk),.reset n(1),.a(gnt[0]),.b(gnt[1]);
```

assert next state

Ensures that when exp is in current state cs that exp will transition to one of the specified legal next states in ns.

Syntax

Arguments

no ns

Specifies the number of legal next states possible from current state (cs). Default = 1.

width

The number of bits in the signal being tested (exp), the current state (cs), and each element of the bitvector ns of the concatenated legal state values (ns). Default = 1.

min hold

The minimum number of clock ticks the signal being tested (exp) must hold at the current state (cs) value. Default = 1.

max hold

The maximum number of clock ticks the signal being tested (exp) can hold at the the current state (cs) value. Default = 0.

disallow

If equal to 1, then a transition to none of the values in ns may occur. Otherwise, if disallow is equal to 0 then the check ensures a transition to one of the states occurs.

exp

Signal being tested.

CS

The current state. The check starts when exp = cs (and $reset_n = 1$).

ns

A bitvector of concatenated legal states that exp can transition to from cs.

The state transitions are checked at the active clk edge specification. For example, if width = 3, ns = 2, and the values are 3'b000 and 3'b110 then the value bound to the ns port should be 6'b000_110.

Note the following:

- max_hold indicates the maximum number of clock ticks the signal being tested (exp) may hold at the current state (cs) value.
- min_hold = max_hold = 1 indicates that the signal being tested (exp) changes to the next value on the next clock tick.
- min_hold = m, max_hold = 0 indicates that the signal being tested (exp) must hold the current state value (cs) for at least m clock ticks, no upper bound is imposed on when it must change.

 $min_hold = m$, $max_hold = n$, n => m indicates that the signal being tested (exp) must hold the current state value (cs) for at least m clock ticks and must advance to the next value within n ticks.

Assumptions

no_ns > 0 (and the ns array should have the correct number of elements. min_hold and max_hold both > 0, except when $min_hold > 0$ and $max_hold = 0$.

Failure Modes

When *disallow* = 0, the assertion assert_next_state will report failure when *exp* is not one of the expected next states.

When disallow = 1, the failure of the assertion assert_next_state means that the next state values and the hold intervals were satisfied, indicating that the design reached a disallowed state within the correct expected timing.

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property, cover_nb_of_next_state_transitions,
   indicates that the expr changed its state from cs to a state in ns
   (disallow = 0) or from the curent state to a state outside ns
   (disallow = 1), while meeting the hold times in the current state
   as defined by the min_hold and max_hold parameters.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2)
   Cover point, cover_observed_hold_time, reports on the number
   of clock cycles the test_expr remained in the current state cs
   before making a transition to one of the next_states (disallow
   = 0) or one of the states other than the next_states (disallow
   = 1).

cov_level_3_0 (bit 0 set in coverage_level_3)
```

Cover property,

cover_nb_of_transitions_from_cs_to_each_ns[i], indicates that the $test_expr$ made a transion from the current state cs to the 'i'th state in the ns. This coverage is only generated when disallow = 0.

Example

The example will verify that when $state_var$ takes on the value 0, then on the next posedge clk it will take on one of the values 0 or 2 (disallow = 1). The assertion is enabled when reset is 0.

```
assert_next_state
    #(0, 2, 4, 1, 1, 0, 0, "nxts_inst failed", 0, 1, 1, 1)
    nxt st inst (clk, !reset, state var, 4'h0, {4'h1, 4'h2});
```

All three coverage statistics will be generated for this checker.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_hold_value #(.severity_level(0),.no_ns(2),
.width(4),.min_hold(1),.max_hold(1),.disallow(0),
.edge_expr(0),.msg("nxts_inst failed"),
.category(0),.coverage_level_1(1),
.coverage_level_2(1),.coverage_level_3(1))
hold_value_inst (.clk(clk),.reset_n(!reset),
.exp(state_var),.cs(4'h0), .ns({4'h1, 4'h2}));
```

assert_no_contention

Ensures that bus always has a single active driver and that there is no X or Z on the bus when driven (en_vector != 0). The total number of en_vector bits that are asserted can be at most 1. Specify 0 for no minimum bus quiet time between bus transactions.

Syntax

Arguments

min quiet

The minimum number of cycles between bus activity during which all bits in en_{vector} must be 0. Default = 0.

max quiet

The maximum number of cycles that the bus can remain quiet (without an active driver). Default = 0.

```
bw en
```

The number of bits in en vector. Default = 2.

bw bus

The number of bits in the bus signal being tested (bus1). Default = 2.

en vector

Enable signals for bus drivers as a vector of cache bits.

bus1

Bus signal being tested.

Failure Modes

The assertion assert_no_contention_no_xs will report failure when the bus had an x or z on one of its bits when at least one driver was enabled (i.e., when en_vector was not all 0).

NOTE: The assertion assert_no_contention_no_xs is eliminated when the template or unit is used with Magellan. This is because the tool uses only 2-state signal values.

The assertion assert_no_contention_1_driver will report failure when there was more than one driver enabled.

The assertion assert_no_contention_quiet_time will report failure when the bus was not quiet for min_quiet clock cycles or that it remained quiet after max_quiet cycles. (Or that there was more than one driver after max_quiet cycles, however, this can be checked by observing the assertions assert no contention 1 driver.)

```
cov_level_1_0 (bit 0 set in coverage_level_1)
   Cover property driver[i].cover_driver_enable indicates
   indicates that each bit [i] in en_vector was set to 1 (enabled).
```

```
cov_level_2_0 (bit 0 set in coverage_level_2)
Cover point observed_quiet_cycles reports the numbers of quiet
cycles that occurred at least once. The report will also indicate
the specified min_quiet and max_quiet values.
```

```
cov_level_3_0 (bit 0 set in coverage_level_3)
```

Cover property

cover_no_contention_quiet_time_equal_to_min_quiet indicates that the observed quiet time was exactly equal to the specified min_quiet value.

```
cov_level_3_1 (bit 1 set in coverage_level_3)
    Cover property
```

cover_no_contention_quiet_time_equal_to_max_quiet indicates that the observed quiet time was exactly equal to the specified max quiet value.

Example

In this example, assert_no_contention verifies that signal bus that is 32 bits wide is driven at every clock cycle because $min_quiet = max_quiet = 0$, and there are two drivers because bw_en takes on the default value of 2. $reset_n$ is a constant 1. Hence the checker is enabled all the time. By default, Level 1 coverage is enabled.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_no_contention #(.severity_level(0),.min_quiet(0),
   .max_quiet(0),.bw_en(22),.bw_bus(32))
no_contention_inst (.clk(clk),.reset_n(1),
   .en_vector(bus_enables),.bus1(bus));
```

assert_packet_flow

The assert_packet_flow checker continuously monitors sop and eop at every positive edge of clock, clk. It does the following checks on the sequencing of sop and eop.

```
assert no eop till sop
```

After eop is issued or just after reset is deasserted, no eop should be asserted till sop is asserted.

```
assert no sop til eop
```

After sop is issued, no sop should be asserted till eop is asserted.

Syntax

Arguments

sop

Signal indicating start of packet.

eop

Signal indicating end of packet.

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
    Cover property, cover sop, indicates the number of sop.
```

```
cov_level_2_0 (bit 0 set in coverage_level_2) :

Cover point observed_sop_eop_delay provides a profile of the observed separation in clock cycles between sop and eop. The report shows which such delays were observed at least once.
```

cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property, cover_simultaneous_sop_eop, indicates the
 number of times eop and sop occured together.

Example

In this example, <code>assert_packet_flow</code> will report failure whenever <code>eop</code> happens without a preceding <code>sop</code> and whenver <code>sop</code> is followed by another <code>sop</code>. All the three coverage levels are enabled.

assert rate

The checker continuously monitors <code>test_expr</code> and <code>trigger</code> at every positive edge of the clock. Once <code>trigger</code> is sampled asserted, the checker will make sure that <code>test_expr</code> is remain high intermittently or continuously for <code>[min:max]</code> clock cycles within <code>period</code> clock cycles.

Syntax

Arguments

min

Minimum number of clock cycles for which test_expr need to be true within period number of clock cycles.

max

Maximum number of clock cycles for which test_expr need to be true within period number of clock cycles.

period

Number of clock cycles during which test_expr must be true [min:max] number of times.

trigger

Signal indicating the start of evaluation

test expr

Logical expression that is being verified at the positive edge of clk.

```
cov_level_1_0 (bit 0 set in coverage_level_1) :
```

Cover property, cover_rate, indicates the number of times the sequence matched within the limits specified.

- cov_level_1_1 (bit 1 set in coverage_level_1) :
 Cover property, cover_trigger, indicates the number of times
 trigger got asserted.
- cov_level_2_0 (bit 0 set in coverage_level_2):

 Cover point observed_nb_of_test_expr_high_within_period

 provides a profile of the number of clock cycles test_expr was
 high within period number of clock cycles. The report shows if any
 of these occurrences were observed at least once.
- cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property, cover_rate_min, indicates the number of times
 the sequence matched exactly at min limit.
- cov_level_3_1 (bit 1 set in coverage_level_3) :
 Cover property, cover_rate_max, indicates the number of times
 the sequence matched exactly at max limit.

Example

In this example, assert_rate will report failure if test_expr does NOT remain high intermittently or continuousely for minimum of 3 clock cycles to a maximum of 5 clock cycles within a continuous period of 6 clock cycles once trigger is sampled asserted, where trigger is a pulse indicating the start of the sequence evaluation. All three coverage levels are enabled.

assert_reg_loaded

Ensure that the register dst_reg is loaded with src data. The check for dst_reg holding the memorized value of src starts with delay cycles (minimum 1 which is default) after the trigger condition evaluates true and within end_cycle cycles after the trigger evaluates true or when stop evaluates true (whichever occurs first).

If used to control the end time stop should become true at least one clock cycle after dst_reg is loaded which means minimum 2 cycles after trigger.

The *src* value is "captured" when *trigger* evaluates true.

The check is made by comparing the <code>src</code> value against the <code>dst_reg</code> contents during the "load window". Once the register has loaded the value during the window, the check terminates with success.

The check is not enabled unless $reset_n$ evaluates true. The check is performed on the active c1k edge specification.

Syntax

Arguments

delay

The number of cycles after the trigger signal (trigger) goes true to start the window. Default = 1.

```
end cycle
```

The number cycles after the trigger signal (trigger) goes true to end the window. Default = 0.

bw

The number of bits in the source data (src) and the register under test (dst reg). Default = 2.

The width (bw) of src and dst_reg should correspond to the actual width of these operands. If bw is less than the actual width, the check might fail if the bits above bw are not zero. If bw is more than the actual width, the additional bits are taken to be zero. A bw of zero is illegal.

trigger

Signal that is part of starting the window.

src

Data loaded into the register.

req

Register being tested.

stop

Signal that stops the check.

Assumptions

If the window is terminated only by stop (i.e., there is no timeout and end_cycle does not apply), then end_cycle must be set to 0.

The width b_W of the src and dst_reg should correspond to the actual width of these operands. If b_W is less than the actual width, then the check may fail if the bits above the b_W are not 0. If b_W is more than the actual width, then the additional bits are taken to be 0.

Failure Modes

The assertion assert_reg_loaded will report failure when either stop became true or maximum delay end_cycle was reached while dst_reg was not yet equal to the stored value.

- cov_level_1_0 (bit 0 set in coverage_level_1) :
 Cover property, cover_nb_of_triggers, indicates that the trigger
 rose.
- cov_level_1_1 (bit 1 set in coverage_level_1) :
 Cover property, cover_reg_loaded, indicates that the dst_reg
 was successfully loaded with src within the specified time limits.
- cov_level_2_0 (bit 0 set in coverage_level_2):

 Cover point, observed_dst_reg_load_time, reports on the number clock cycles taken to load the dst_reg. The clock cycles are counted from the first assertion of trigger.
- cov_level_3_0 (bit 0 set in coverage_level_3) :
 Cover property,
 cover_nb_of_times_stop_happened_at_or_prior_to_end_cycle,
 indicates that a stop happened at or prior to end_cycle after the
 occurrence of a trigger.
- cov_level_3_1 (bit 1 set in coverage_level_3) :
 Cover property,
 cover_nb_of_times_no_stop_happened_till_end_cycle,
 indicates that no stop happened till the end_cycle expired after
 the occurrence of a trigger.
- cov_level_3_2 (bit 2 set in coverage_level_3) :
 Coverproperty, cover_data_transfer_exactly_at_end_cycles,
 indicates that the dst_reg was loaded wih src exactly at
 end_cycle.

```
cov_level_3_3 (bit 3 set in coverage_level_3) :
   Coverproperty, cover_data_transfer_exactly_at_delay_cycles,
   indicates that the dst reg was loaded wih src exactly at delay.
```

Example

In this example reg_data (of width 8 bits) is to be loaded by the value of data at posedge clk within 1 to 3 clock cycles from load evaluating true. By default Level 1 coverages are enabled.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_reg_loaded #(.severity_level(0),.delay(1),
   .end_cycle(3),.bw(32),.edge_expr(8)
rg_ld_inst (.clk(clk),.reset_n(1),.trigger(load),
   .src(data),.dst reg(reg data),.stop(0));
```

assert_req_ack_unique

Verifies that each req receives an ack within the specified interval min_time and max_time clock clk ticks. Note that acks are attributed to reqs in a FIFO manner.

Syntax

(Unit syntax only)

Arguments

min time

Defines the minimum time separation between a req and an ack.

Default = 1.

```
max_time
```

Defines the maximum time separation between a req and an ack Default = 1.

```
max time log 2
```

Specifies the superior integer of log2 of max_time, used to dimension the data structures. Default = 4 (= sup(log2(15))).

version

This parameter specifies two versions of the checker:

- 0 Selects a version that is suitable for max_time <= 15. It uses IDs to identify requests and then generates as many assertions as the max time clock ticks. Default = 0.
- 1 Selects a version that is suitable for <code>max_time > 15</code>. It uses a time stamp computed mod 2 <code>max_time</code> to mark the requests, the time stamp is enqueued. When an <code>ack</code> arrives it verifies that the time stamp at the head of the queue satisfies the timing requirements.

```
cov_level_1_0 (bit 0 set in coverage_level_1)
Cover property cover_number_of_req indicates that req was
asserted.
```

```
cov_level_1_1 (bit 1 set in coverage_level_1)
Cover property cover_number_of_ack indicates that ack was
asserted.
```

```
Level 2 and 3 are available only with version = 1 selection cov_level_2_0 (bit 0 set in coverage_level_2)

Cover point observed_latency reports the req-to-ack latencies observed at least once.
```

```
cov_level_2_1 (bit 1 set in coverage_level_2)
   Cover point outstanding_requests reports the numbers of
   outstanding requests that occurred at least once.
```

```
cov_level_3_0 (bit 0 set in coverage_level_3)
Cover property cover_ack_with_exact_min_lat indicates that
the observed latency was exactly equal to the specified min_time
value.
```

```
cov level 3 1 (bit 1 set in coverage level 3)
```

Cover property <code>cover_ack_with_exact_max_lat</code> indicates that the observed latency was exactly equal to the specified <code>max_time</code> value.

Example

The instance $req_grant_1_1$ of $assert_req_ack_unique$ verifies that for each request there is a grant received within 20 and 100 posedge edges of clk ($max_time_log_2$ is thus set to 7). The checker is reset on $reset_n$ low. Version 1 is used, i.e., using time stamps. Coverage Levels 1 and 3 are selected (coverage_level_1 = 3 and coverage_level_3 = 3).

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_req_ack_unique #(.severity_level(1),.min_time(20),
   .max_time(100),.max_time_log_2(7),.version(1),
   .edge_expr(0),.msg("req_ack failed"),.category(0),
   .coverage_level_1(3),.coverage_level_2(0),
   .coverage_level_3(3))
req_grant_1_1 (.clk(1'b1),.reset_n(reset_n),
   .reg(request),.ack(grant));
```

assert_req_requires

Ensures that if the trig_req expression evaluates true then the follow_req expression and follow_resp expression will evaluate true (in sequence) before the trig_resp expression evaluates true. The check is not enabled unless reset n evaluates true.

Syntax

Arguments

```
min lat
```

Defines the minimum latency from trig_req to trig_resp.

Default = 1.

max lat

Defines the maximum latency from trig_req to trig_resp.

max_lat == 0 means that there is no upper bound. Default = 0.

Assumptions

```
Time separations (in clock ticks) are t(trig_req) <= t(follow_req) < t(follow_resp) <= t(trig_resp), i.e., trig_req and follow_req, and follow_resp and trig_resp may coincide.
```

Note: If multiple overlapping evaluations are triggered, the latency coverage information may not be accurate since the vector does not distinguish which responses belong to which requests.

Coverage Modes

- cov_level_1_0 (bit 0 set in coverage_level_1)
 Cover property cover_no_of_trig_reqs indicates that the
 trig_req was asserted.
- cov_level_1_1 (bit 1 set in coverage_level_1)
 Cover property cover_cover_req_requires indicates that the
 specified sequence occurred.
- ov_level_2_0 (bit 0 set in coverage_level_2)

 Cover point observed_latency_btw_trig_req_and_trig_resp

 reports which values of latency between trig_req and trig_resp

 were observed at least once.
- cov_level_2_1 (bit 1 set in coverage_level_2)
 Cover point observed_latency_btw_trig_req_and_follow_req
 reports which latencies between trig_req and follow_req were
 observed at least once.
- cov_level_2_2 (bit 2 set in coverage_level_2)
 Cover point

observed_latency_btw_follow_req_and_follow_resp reports which latencies between follow_req and follow_resp were observed at least once.

cov_level_2_3 (bit 3 set in coverage_level_2)
 Cover point

observed_latency_btw_follow_resp_and_trig_resp reports which latencies between follow_resp and trig_resp were observed at least once.

cov_level_2_4 (bit 4 set in coverage_level_2)
Cover property cover_trig_req_follow_req indicates that there
was a a follow_req after a trig_req within max_lat cycles.

- cov_level_2_5 (bit 5 set in coverage_level_2)
 Cover property cover_trig_req_follow_req_follow_resp
 indicates that there was a follow_req after a trig_req and then
 followed by follow_resp within max_lat cycles..
- cov_level_3_0 (bit 0 set in coverage_level_3)
 Cover property cover_trig_resp_exactly_on_min_lat indicates
 that the observed latency between trig_req and trig_resp was
 exactly equal to the min_lat value.
- cov_level_3_1 (bit 1 set in coverage_level_3)

 Cover property cover_trig_resp_exactly_on_max_lat indicates
 that the observed latency between trig_req and trig_resp was
 exactly equal to the max_lat value.

Note: Coverage is collected correctly only when the transactions delimited by trig_req and trig_resp asserted do not overlap, i.e., there is no new assertion of trig_req while such a transaction is in progress.

Example:

meaning that min_lat == 1, max_lat == 10, and coverage Levels 2 and 3 are selected. The assertion verifies that req is followed by resp within 10 clock cycles. All other parameters take default values (posedge clk sampling).

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_req_requires #(.severity_level(0),.min_lat(1),
  .max_lat(10),.edge_expr(0),.msg("req_requires fails"),
  .category(0), .coverage_level_1(15),
  .coverage_level_2(63), .coverage_level_3(3))
req_resp_inst (.clk(clk),.reset_n(1),
  .trig_req(req),.follow_req(1'b1),
  .follow_resp(1'b1),.trig_resp(resp));
```

assert_stack

Checks operations on a stack.

Syntax

Arguments

depth

The maximum size of the stack, a compile-time integer constant $< 2^{**}16$. Default = 2.

elem sz

The width of data elements, a compile-time constant. Default = 1.

```
hi_water_mark
```

If hi_water_mark is a positive value, then the level of the fill of the queue after push will be checked to see if hi_water_mark is exceeded. Once high water has been exceeded once, this check is disabled until the stack size decreases again to or below the mark. Default = 0.

push lat

The number of clk cycles between push being asserted 1 and $push_data$ being valid. Default = 0.

pop_lat

The number of clk cycles between pop being asserted 1 and pop data being valid. Default = 0.

value_chk

If 1, checks that pop_data matches the data at the top of the stack. Default = 1.

push pop chk

If 1, checks that push and pop operations do not occur simultaneously. Default = 1.

push

Set to 1 when data is being pushed.

push_data

Data being pushed.

pop

Set to 1 when data is being popped.

pop data

Data being popped.

Note the following:

- All operations including reset are synchronous to a tick of clk.
- reset_n asserted 0 initializes the stack to empty.
- When push is asserted 1: Ensures no stack overflow. push_lat specifies the number of ticks of clk between the asserting of push and when push_data is valid. It must be a compile-time nonnegative integer constant (not an interval).
- If hi_water_mark is a positive value, then the fill of the stack after the push will be checked to see if hi_water_mark is exceeded (>=). Once high water has been exceeded once, this check is disabled until the stack falls below the mark again (<). hi water mark can be a constant or a design variable.
- If the stack depth is exceeded, a failure is reported and all further checks are disabled until the stack is reset.

- When pop is enabled: Ensures the stack is not empty when popped. If a pop is performed on an empty stack, all checking of pop operations is disabled until reset is applied or a push occurs.
- If $value_chk$ evaluates to 1, it ensures pop_data is what was on the top of the stack. pop_lat specifies the number of cycles of clk between the asserting of pop and when pop_data is valid. It must be a compile-time non-negative integer constant (not an interval).
- If push_pop_chk evaluates 1, ensures that push and pop operations do not occur simultaneously. If push and pop do occur simultaneously, the effect is the same as if push were done first followed by a pop (that is, the stack is not changed). If value_chk = 1, then pop_data is compared with push_data.

Failure Modes

Assertion assert_stack_overflow will report a failure when push is issued and the stack is full. The reported time of failure is on the clock tick following the failed deferred push operation.

Assertion assert_stack_underflow will report a failure when pop is issued and the stack is empty (and no simultaneous push). The reported time of failure is on the clock tick following the failed deferred push operation.

Assertion assert_stack_value_chk will report failure when pop_data value does not match the expected top-of-stack value, provided the stack is not empty or when the stack is empty and there is a simultaneous push and the value pushed on the stack does not match the value popped off the stack.

Assertion assert_stack_hi_water_chk will report a failure if the stack is filled above the high-water mark.

Assertion assert_stack_push_pop_fail will report a failure if push and pop are enabled simultaneously (and push_pop_chk is 1).

- cov_level_1_0 (bit 0 set in coverage_level_1)
 Cover property cover_number_of_pushes indicates that there was
 a push operation.
- cov_level_1_1 (bit 1 set in coverage_level_1)
 Cover property cover_number_of_pops indicates that there was
 a pop operation.
- cov_level_1_2 (bit 2 set in coverage_level_1)

 Cover property cover_push_followed_eventually_by_pop

 indicates that a push was followed eventually by a pop without an intervening push.
- cov_level_2_0 (bit 0 set in coverage_level_2)
 Cover point observed_outstanding_contents reports which
 observed fill levels were observed at least once.
- cov_level_3_0 (bit 0 set in coverage_level_3)
 Cover property cover_stack_hi_water_chk indicates that the
 high water mark was reached.
- cov_level_3_1 (bit 1 set in coverage_level_3)
 Cover property cover_simultaneous_push_pop indicates that
 there were simultaneous push and pop operations.
- cov_level_3_2 (bit 2 set in coverage_level_3)

 Cover property cover_simultaneous_push_pop_when_empty
 indicates that there were simultaneous push and pop operations
 while the stack was empty.

```
cov_level_3_3 (bit 3 set in coverage_level_3)
  Cover property cover_simultaneous_push_pop_when_full
  indicates that there were simultaneous push and pop operations
  while the stack was full.
```

```
ccov_level_3_4 (bit 4 set in coverage_level_3)
   Cover property cover_number_of_empty indicates that the stack
became empty after a pop.
```

```
ov_level_3_5 (bit 5 set in coverage_level_3)

Cover property cover_number_of_full indicates that the stack became full after a push.
```

Example:

When sys_reset is asserted 1 the stack is initialized. It is 10 elements deep and 16 bits wide. The water mark is set at 8 which means that the water-mark check is enabled. The push and pop latencies are both 0 which means that $data_in$ must be present at the same time as push is asserted and $data_out$ must be present at the same time as pop is asserted. The value check is enabled meaning that $data_out$ will be checked against the data expected on the top of the stack. Push-Pop check is disabled. Coverage Level 1 is selected by default.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_stack #(.severity_level(0),.depth(10),
    .elem_sz(16),.hi_water_mark(8),.push_lat(0),
    .pop_lat(0),.value_chk(1),.push_pop_chk(0))
```

```
stack_inst (.clk(clk),.reset_n(!sys_reset),.push(push),
.push_data(data_in),.pop(pop),.pop_data(data_out));
```

assert_valid_id

The signal <code>issued_sig</code> asserted 1 validates a request identified by the value in <code>issued_id</code>. This request is expected to be acknowledged by <code>ret_id</code> validated by <code>ret_sig</code> asserted 1 within <code>[min_lat : max_lat]</code> delay. Both <code>issued_id</code> and <code>ret_id</code> are qualified by <code>reset_n</code> being 1. If <code>ret_sig</code> does not arrive at or before <code>max_lat</code> clock cycles after an <code>issued_sig</code>, an assertion will fire at <code>max_lat+1</code> cycles. This is the only failure on <code>max_lat</code> reported until a <code>ret_sig</code> with that id arrives which will re-enable the check for that id. <code>max_lat >= min_lat >= 1 must hold</code>

Syntax

Arguments

id bw

The max. number of bits to encode an id. Default = 2. There are max_ids id's at most at any time.

max ids

The maximum number of IDs. Default = 2.

The maximum value is 2^{16} .

```
max out ids
```

Indicates how many issued id's out of max_ids can have outstanding ret_sig's at any time. By setting $max_out_ids > max_ids$ then effectively max_ids becomes the limit. Default = 1.

max out per id

The maximum number of issues outstanding per ID. Default = 1.

min lat

Minimum number of clock cycles between an ID being issued and returned. Default = 1.

max lat

Maximum number of clock cycles between an ID being issued and returned. Default = 1.

Note the following:

issued sig

Ensures that max_out_ids and max_ids are not exceeded and that $issued_id$ is at most $max_out_per_id$ outstanding (that is, not returned). When $max_out_per_id > 1$ then the returns for an ID cannot be distinguished. But for any issue, there must be a return of the ID within the latency interval.

issued_id, ret_id, and reset_id

Values encoded using id_bw number of bits.

reset sig

Resets the outstanding count of reset_id id is reset to 0, if that id has an outstanding return.

nb_ret_per_issued

Indicates how many ret_sig are required for each $issued_sig$. The port is included by defining the macro SVA_NEW_PORTS.

Important:

When the macro SVA_NEW_PORTS is defined, there is a additional port, nb_ret_per_issued, It is assumed valid when issued_sig is asserted and it indicates how many returns are required for that assertion of issued_sig and the associated id. For example, if nb_ret_per_issued == 1, then for each issued_sig, only one ret_sig with that id is allowed. If nb_ret_per_issued == 2, then the checker expects ret_sig to be asserted 2 times for that issued_sig. All ret_sig returns must satisfy the [min_lat: max_lat] latency with respect to the current issued_sig and the same id. That is, this interval of latencies applies to all nb_ret_per_issued cases. The width of this port is determined by the parameter max_ret_bw (default 2);

Note the following:

- If an <code>issued_id</code> exceeds the maximum number of outstanding <code>max_ids</code> or <code>max_out_ids</code>, an error is reported. Only those id's are counted that have <code>reset n == 1</code> at issuance.
- When reset_sig is asserted 1, ret_id must match an outstanding id. A returned ret_id is counted only against issued id's in the previous clock cycles. It also ensures that issued_id is outstanding for at least min_lat cycles but no longer than max_lat cycles after issuance.
- The issued_sig and ret_sig control signals are active for only one clock period.
- To trigger a check for an issued ID, $reset_en$ must be asserted 1 at the time $issued_sig$ is asserted and also at the time ret_sig is asserted. If an ID is returned and $reset_n$ is asserted while at issuance of this ID $reset_n$ was deasserted, this return is flagged as an error if there is no other outstanding request for that id.
- All checks are performed on the active clk edge specification.

- $min_lat = 1$, $max_lat = 1$ means that the ID must be returned on the next clock cycle after issuance.
- $min_lat = m$, $max_lat = n$, $m \le n$, means that the ID must be returned within the interval [m:n] clock ticks after issuance. max_lat must be less than or equal to $2^{**}15$.

Failure Modes

assertion <code>assert_valid_id_max_lat</code> will report failure when an id has been issued, but that id has not been returned at or before <code>max_lat clock cycles</code>. This will happen exactly at <code>max_lat+1</code> cycles after the issue.

assertion assert_valid_id_min_lat will report failure when an id has been issued, but that id is returned before min_lat clock cycles.

Assertion assert_valid_issued_id_ok will report failure when an id is issued and the same id is in circulation with the count exceeding max_out_per_id.

Assertion assert_valid_ret_id_ok will report failure if an id is returned while there is no such id value still in circulation (i.e., this id has not been issued).

Assertion assert_valid_max_issued_ids_ok will report failure when an id is issued and the total number of different id's in circulation is already equal to the max_ids or the max_out_ids value.

assertion assert_nb_ret_per_issued_0 will report failure when nb_ret_per_issued is not greater than 0 at the time issued_sig is asserted.

Coverage modes (Only available with version = 1 selection)

- cov_level_1_0(Bit 0 set in coverage_level_1)
 Cover property, cover_number_of_issued_sig, indicates that
 issued_sig was asserted regardless the value of issued_id.
- cov_level_1_1(Bit 1 set in coverage_level_1)
 Cover property, cover_number_of_ret_sig, indicates that
 ret sig was asserted regardless the value of ret id.
- cov_level_1_2(Bit 2 set in coverage_level_1)
 Cover property, cover_number_of_reset_sig, indicates that
 reset sig was asserted regardless the value of reset id. Z
- cov_level_2_0(Bit 0 set in coverage_level_2)
 Cover point, observed_latency, reports the issued_sig to
 ret_sig latencies that were observed at least once.
- cov_level_2_1(Bit 1 set in coverage_level_2)
 Cover point, outstanding_ids, reports the numbers of
 outstanding ids that occurred at least once.
- cov_level_3_0(Bit 0 set in coverage_level_3)
 Cover property, cover_ret_sig_with_exact_min_lat, indicates
 that the observed latency from issued_sig to ret_sig was exactly
 equal to the specified min_lat value, regardless the id value.
- cov_level_3_1(Bit 1 set in coverage_level_3)
 Cover property, cover_ret_sig_with_exact_max_lat, indicates
 that the observed latency from issued_sig to ret_sig was exactly
 equal to the specified max_lat value, regardless of the id value.
- cov_level_3_2(Bit 2 set in coverage_level_3)
 Cover property, cover_issued_ids_reached_max_ids, indicates
 that the number of outstanding id's was exactly equal to the
 specified min of max_ids and max_out_ids values.

```
cov_level_3_3( Bit 3 set in coverage_level_3)
  Cover property, cover_issued_ids_reached_max_out_per_id,
  indicates that the number of outstanding issued_id's was exactly
  equal to the specified max_out_per_id value.
```

Example

The checker is enabled when out of reset. All signals are sampled on posedge c1k. There are 3 bits to encode id's. At most 6 id's can be in circulation at any time and that only one copy of each. The count of the copies of an id is reset when clear is asserted with the corresponding id value on clear_id. An issued id is valid when issued_valid is asserted, similarly, a returned id is valid when ret_valid is asserted. An issued id must be returned in 1 to 10 clock cycles. A custom message is appended to the standard failure message. The coverage Level 1 is enabled by default.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_valid_id #(.severity_level(0),.id_bw(3),
   .max_ids(6),.max_out_ids(6),.max_out_per_id(1),
   .min_lat(1),.max_lat(10),.edge_expr(0),
   ,.msg("1 copy each"))
val_id_inst (.clk(clk),.reset_n(!reset),
   .trig_req(issued_valid),.follow_req(ret_id),
   .follow resp(clear),.trig_resp(clear_id));
```

assert value

Ensure that exp can only be one of the specified values in vals.

Syntax

Arguments

no vals

The number of entries in the vals specification. Default = 1.

disallow

If disallow evaluates true, then exp is forbidden to take on any of the specified value in vals. Otherwise, the check ensures exp takes on only the specified value in vals. Default = 0.

bw

Number of bits in the signal being tested (exp) and each element of the specified vector of values (val). Default = 2.

exp

Signal or expression being tested.

vals

A bitvector of concatenated values that the signal being tested (exp) must evaluate to.

For example, if bw = 3, $no_vals = 2$, and the values are 3'b000 and 3'b110 then the value bound to the vals port should be 6'b000_110.

Assumptions

no vals > 0 (and the vals bitvector should have the correct size.)

Failure Modes

When disallow = 0, the assertion assert_value will report failure when exp was not one of the expected values in vals at the time when reset n = 1.

When disallow = 1, the failure of the assertion assert_value means that at the time when $reset_n = 1$, the value of exp was one of the values in vals (which was disallowed).

Coverage Modes

```
cov_level_1_0 (bit 0 set in coverage_level_1)
Cover property, value[i].cover_nb_of_exp_changes, indicates
that the exp changed value, when enabled by reset_n.
```

For disallow = 0:

```
cov level 1 1 (bit 1 set in coverage level 1)
```

Cover property, cover_value, indicates that the *exp* changed to one of the values specified in *vals*.

```
cov_level_3_0 (bit 0 set in coverage_level_3)
```

Cover property,

value[i].cover_nb_of_transitions_to_each_vals,
indicates that the exp changed to the i (the value specified).

For disallow = 1:

```
cov level 1 1 (bit 1 set in coverage level 1) :
```

Cover property, $cover_value$, indicates that the exp changed to any value different from the values specified in vals. There is no Level 3 coverage in this case.

Example

```
assert_value #(0, 4, 0, 8, 0, "value error", 0, 1, 0, 1)
value instance (clk, load, control reg, 16h0 1 3 5);
```

When load is 1, then at posedge clk (default) the 4-bit variable control_reg must have one of the four values 0, 1, 3 or 5 (since disallow is 0). Coverage Levels 1 and 3 are enabled.

Name-based Example

For greater clarity, the checker in the example can be written in the name-based format as follows:

```
assert_value #(.severity_level(0),.no_vals(4),
  .disallow(0),.bw(8),.edge_expr(0),.msg("value error"),
  .category(0), .coverage_level_1(1),
  .coverage_level_2(0), .coverage_level_3(1))
value_instance (.clk(clk),.reset_n(load),
  .exp(control reg),.vals(16h0 1 3 5));
```

Index

assert_hold_value 3-156 assert_memory_async 3-159 assert_memory_sync 3-166 assert_multiport_fifo 3-175 assert_next_state 3-184 assert_no_contention 3-188 assert_rate 3-193 assert_reg_loaded 3-195 assert_req_ack_unique 3-199 assert_req_ack_unique 3-199 assert_req_requires 3-202 assert_valid_id 3-212 assert_value 3-218 advanced checkers 3-125 always on edge, test expression checker 2-23 always, test expression monitor 2-20 assert_detra assert_detra assert_detra assert_detra assert_drive assert_drive assert_fund assert_fifo assert_	_used 3-139 ement 2-34 a 2-37 en 3-143 _clk_fifo 3-145 a_parity 2-40 3-150 index 2-42 e 2-47 LOBAL_RESET, global control dshake 2-51 _value 3-156 ication 2-56
--	--

assert_memory_sync 3-166 assert_multiport_fifo 3-175 assert mutex 3-182 assert_never 2-62 assert_next 2-64 assert_next_state 3-184 assert_no_contention 3-188 assert_no_overflow 2-68 assert_no_transition 2-72 assert_no_underflow 2-75 assert_odd_parity 2-79 ASSERT_ON, global control 1-3 assert_one_cold 2-82 assert_one_hot 2-85 assert_packet_flow 3-191 assert_proposition 2-88 assert_quiescent_state 2-90 assert range 2-93 assert_rate 3-193 assert_reg_loaded 3-195 assert_req_ack_unique 3-199 assert req requires 3-202 assert_stack 3-206 assert time 2-97 assert transition 2-101 assert_unchange 2-104 assert_valid_id 3-212 assert value 3-218 assert_width 2-108 assert_win_change 2-112 assert win unchange 2-116 assert window 2-118 assert zero one hot 2-122

В

Basic Checkers 2-19 bit, assert checker 3-133

C

change checker 2-26
Checker Library 3-125
Checker Triggering 1-4
Checker Triggering, triggering checker 1-4
checkers, basic 2-19
clock cycle checker 2-108
code distance checker 3-136
controls, global 1-3
COVER_ON, global control 1-3
coverage levels, definitions 1-7
cycle sequence 2-30
cycle timing checker 2-64

D

data used checker 3-139 decrement test expression monitor 2-34 delta, test expression monitor 2-37 driven, bit checker 3-143 dual_clk_fifo 3-145 dual_clk_fifo, queue checker 3-145

Ε

edge_expr, shared syntax 3-126 even parity checker 2-40

F

fifo, queue checker 3-150 fifo_index 2-42

G

Global Controls 1-3 Global Controls, ASSERT_GLOBAL_RESET 1-3 Global Controls, ASSERT_INIT_MSG 1-3 Global Controls, ASSERT_MAX_REPORT_ERROR 1-3 Global Controls, ASSERT_ON 1-3 Global Controls, COVER_ON 1-3 Global Controls, SVA_CHCKER_NO_MESSAGE 1-4 Global Controls, SVA_CHECKER_INTERFACE 1-4

Н

handshake checker 2-51 header file 1-2 hold_value checker 3-156

I

ID checker 3-212 implication checker 2-56 increment checker 2-59 interface, SVA 1-4

L

levels, coverage 1-7 library 3-125 library, location 1-2

M

memory_async checker 3-159 memory_sync checker 3-166 multiport_fifo, queue checker 3-175 mutex checker 3-182

N

next, cycle timing checker 2-64 next_state. transition checker 3-184 no contenction checker 3-188 no transition checker 2-72 no underflow checker 2-75 no_overflow checker 2-68

0

odd parity checker 2-79 one cold, bit checker 2-82 one hot bit checker 2-85 OVL-like checker assert always 2-20 assert_always_on_edge 2-23 assert change 2-26 assert_cycle_sequence 2-30 assert_decrement 2-34 assert delta 2-37 assert even parity 2-40 assert fifo index 2-42 assert frame 2-47 assert handshake 2-51 assert_implication 2-56 assert increment 2-59 assert never 2-62 assert next 2-64 assert no overflow 2-68 assert no transition 2-72 assert_no_underflow 2-75 assert_odd_parity 2-79 assert one cold 2-82 assert one hot 2-85 assert proposition 2-88 assert_quiescent_state 2-90 assert range 2-93 assert time 2-97 assert transition 2-101 assert unchange 2-104 assert_width 2-108 assert_win_change 2-112 assert win unchange 2-116 assert window 2-118 assert_zero_one_hot 2-122

P

packet flow checker 3-191

proposition test expression checker 2-88

Q

queue checker 3-145, 3-150, 3-175 quiescent state checker 2-90

R

range checker 2-93
rate checker 3-193
reg_loaded checker 3-195
req and ack signals 2-51
req_ack_unique checker 3-199
req_requires checker 3-202

S

stack checker 3-206 start event checker 2-112, 2-116, 2-118 start expression checker 2-97 SVA_CHCKER_NO_MESSAGE, global control 1-4 SVA_CHECKER_INTERFACE, global control 1-4 syntax, shared 3-126 syntax, shared elements 1-6 SystemVerilog, use mode 1-13

Τ

templates 3-125

test expression monitor 2-20 timing, cycle checker 2-47 transition checker 2-101, 3-184 triggering checkers 1-4

U

unchange, start event checker 2-104 units 3-125
Use Mode in SystemVerilog 1-13
Use Mode in VHDL 1-14
Use Mode, Verilog 1-5
Use Mode, VHDL 1-14

V

valid_id checker 3-212 value checker 3-218 Verilog, use mode 1-5 VHDL use mode 1-14

W

width, clock cycle checker 2-108 win_change, start event checker 2-112 win_unchange, start event checker 2-116 window, start event checker 2-118

Ζ

zero_one_hot, bit assert checker 2-122