

Secure Execution

Lecture 10

Secure Execution

- Security Model
 - Secure
 - Non Secure
 - Non Secure Callable
- ARM TrustZone
- RP2350 Secure
- Software





Type	Symbol	Description
Secure	S	Can be accessed only by code running in secure mode
NonSecure Callable	NSC	code running in non-secure mode can make function calls into it with some restrictions
NonSecure	NS	any code running in any mode can access it

Security Attribution Unit

