



Flow Direction

30"

30"

Direction the hand wheel needs to face when installed