

Technical Exhibit J
Electrical and Mechanical Maintenance Workload

Note that the only information available to the Government about the amount of time to repair or the cost of repair is proprietary to previous contractor's methods and means.

NOMENCLATURE	SN/LN	REMARKS	Julian date NMC
Mobile radio	RNG-5	Pull radio and wiring from old RNG-5 and install in new RNG-5	4002
Cordless drill	R0652	Motor is burnt out -code out	4005
Mobile radio	9811240	Blown fuse, does nothing	4005
AxSys EOSS 500 camera	314 w/005	Not able to focus on targets	4005
Mobile radio	9809873	Reads "ERROR 000C"	4005
Base station radio	9986267	Does not transmit	4005
AxSys EOSS 500 camera	315 w/039	No thermal image	4009
Mobile radio	RNG-1	Pull radio and wiring from old RNG-1 and install in new RNG-1	4009
HH radio	9139011	Lost its fill	4010
M31 A1	112	Inoperable	4011
M31 A1	362	Inoperable	4011
M31 A1	81	Inoperable	4016
M31 A1	24	Inoperable	4016
M31 A1	355	Inoperable	4016
M31 A1	63	Inoperable	4016
M31 A1	88	Inoperable	4016
Mobile radio	9809666	Reads "ERROR 0067"	4019
M31 A1	330	Inoperable	4019
M31 A1	272	Inoperable	4019
M31 A1	317	Inoperable	4019
M31 A1	130	Inoperable	4019
M31 A1	301	Inoperable	4019
Solar panel	n/a	Burnt out - code out	4024
HH radio	9139011	On/Off stem broken	4025
Microphone	n/a	Control room mic is very noisy	4025
Control box M31A1	1,2,3,4	Repair holes in 4 cases	4026
Base station radio	9987312	Only reads "security check"	4030
Worm saw	HO695453	Needs new cord	4031
Minivox	A4001485	Will not stay on	4031
Minivox	C40011780	Will not stay on	4031
Control box M31A1	45,46	Repair 2 cases	4032
Base station radio	9986277	Will not transmit	4036
Base station radio	9987312	Inoperable	4034
Mobile radio	9809808	Reads "ERROR 0067"	4034
CCU	171	Bad unit, burnt Molex connector	4034
CCU	106	Will not send signal	4034
M31 A1	394	Inoperable	4034
M31 A1		Inoperable	4034
M31 A1		Inoperable	4034
M31 A1	160	Inoperable	4034
M31 A1	313	Inoperable	4040
M31 A1	413	Inoperable	4040
Control box M31A1	36	Build control box	4040
SAT	97	SAT shot up -code out	4043
Probes for multimeters	n/a	Broken test leads	4044
Battery eliminator	n/a	Inoperable	4046
AxSys EOSS 500 camera	314 w/005	will not focus	4051
Matching units	n/a	TI for turn in 5 total	4051
Welder	n/a	Run ground for outdoor welder	4051
Control box M31A1	5	Inoperable	4051
Control box M31A1	29	Inoperable	4051
Hit sensor cables for M31A1	n/a	Fabricate 25 cables	4052
Thermometer HH	RC232113	Inop -code out	4052
Multimeter	70621567	Broken test leads	4052
M31 A1	497	Inoperable	4052
M31 A1	288	Inoperable	4052

M31 A1		163 Inoperable	4052
Mobile radio		9810798 Will not transmit	4057
Floor fans	n/a	Cords frayed on 2 fans	4054
M31A1		273 Inoperable	4059
M31A1		79 Inoperable	4059
M31A1		352 Inoperable	4059
Harris radios	BGRC,BGPQ,CCRB	3 radios will not hold fill	4061
Power cables for M31	n/a	Repair 25 M31 power cables	4065
HH controller	HH341960-2507	LED display locks up-CODE OUT	4065
HH controller	HH341962-2507	Display not working	4065
Control box M31A1		17 Inoperable	4066
Control box M31A1		23 Inoperable	4066
Control box M31A1		1 Inoperable	4066
Mobile radio		9809799 Distorted transmission	4040
HH controller	HH341962-2507	Inoperable-CODE OUT	4040
Speaker, Portable	B4692	Inoperable	4040
AxSys EOSS 500 camera	323 w/day cam 110	Thermal will not focus	4042
AxSys EOSS 500 camera	325 w/day cam 031	Inoperable	4042
LM ATS antennas	n/a	Repair 50 antennas	4046
Mobile radio		9809808 Reads "security check"	4049
Mobile radio		9809721 Reads "security check"	4049
HH radios	n/a	Bad batteries	4092
HH radio		9139138 Distorted speaker	4092
HH radio		9139129 Cannot read display	4092
HH radio		9139062 Broken display	4094
Agema camera		168001 Bad picture -code out	4094
Harris radio	C06979	Does not hold fill	4094
Mobile radio	KAT 402	Radio harness is inoperable	4095
RZ-14	HH309811-1606	Inoperable	4096
PA portable	L301032	No sound -CODE OUT	4099
Base station		9986311 Comms going in and out	4100
PA amplifier		700309 No power -CODE OUT	4100
PA amplifier	K328148	No output	4100
PA amplifier	72145 B	Stops working after 10 min.- CODE OUT	4100
Base station		9987952 No power	4103
Extension cord	n/a	Cord is broken	4103
HH radio		9139065 Low audio	4103
PA portable	I3000610	No audio	4107
PA portable	A4001483	Very low audio-CODE OUT	4107
AA 8 SIT		6137032 Inoperable	4109
AA 8 SIT		6137038 Inoperable	4109
Cordless drill		143083 Will not stop turning -CODE OUT	4114
Mobile radio		9810526 Install in RNG 32	4123
Axis video encoder	ACCC8E9F5E77	Inop. reads "undervoltage"	4123
Strobe light MFS	n/a	4 Inoperable-CODE OUT 3	4124
Various parts	n/a	TI for turn in	4124
Base station		9986277 No power	4124
HH controller	HH371239	Screen broken, wires broken	4124
DCU	_073	No video	4124
DCU		156 No output	4124
Control box M31A1		87 Inoperable	4124
Control box M31A1		88 Inoperable	4124
Control box M31A1		27 Inoperable	4124
Control box M31A1		99 Inoperable	4124
Control box M31A1		142 Inoperable	4124
Mobile radio	RNG 3	Remove radio and all wiring from old vehicle	4129
Mobile radio	RNG 34	Install radio in vehicle	4129
Harris radio amplifier	A09340	Inoperable	4129
Strobe light MFS	n/a	No light	4130
Harris radio		41220 Does not transmit	4136
Mobile radio	RNG 35	Install radio in vehicle	4136
Mobile radio	RNG 3	Install radio in vehicle	4136
Mobile radio		9809647 On-off switch broken	4137
Day camera		184 Will not focus in the distance	4144

Audio amplifier	98K0000064	Inoperable	4155
Audio amplifier		99295818 Inoperable	4155
Microphones	n/a	2 mics inoperable	4155
Harris radio	A01403	Will not transmit	4155
LM ATS antennas	n/a	Repair 50 antennas	4155
Mobile radio	KAT 404	Install radio and wiring in new vehicle	4156
Mobile radio	KAT 217	Remove radio and wiring from vehicle	4156
HH controller	HH341946	LED display not working	4157
Target setup device	HH371239	LED display not working	4157
Mobile radio		9809728 No power	4159
Mobile radio	KAT 315	Remove radio and wiring from vehicle, install in new vehicle	4159
Mobile radio	RNG 6	Install radio and wiring in new vehicle	4166
Mobile radio	KAT 217	Install radio and wiring in new vehicle	4169
Joystick, AxSys		751 Intermittant operation	4169
Power supply	BI3G200M	Inoperable	4170
Scanner, mobile		75003527 TI for turn in	4170
AxSys EOSS 500 camera		321 Solid white screen	4171
HH radio		9139010 Power knob broken	4172
Extension cord	n/a	Repair extension cord	4172
Intercom	n/a	Inoperable	4176
Base station		9987022 No audio	4176
Battery eliminator		816 No output	4174
Speco speakers	n/a	2 speakers, no audio	4174
Mobile radio		9809568 Intermittant operation	4140
Joystick, AxSys		714 Intermittant operation	4147
M31 A1		43 Inoperable	4190
M31 A1		300 Inoperable	4190
M31 A1		264 Inoperable	4190
M31 A1		48 Inoperable	4190
M31 A1		176 Inoperable	4190
M31 A1		70 Inoperable	4190
Base station		9987309 Will not transmit	4190
Base station		9986288 Inoperable	4192
Mobile radio		9809658 Inoperable	4192
Mobile radio	KAT 120	Remove radio from old vehicle and install in new vehicle	4194
Cable, radio to encoder	n/a	Inoperable	4201
M31 A1		103 Inoperable	4204
M31 A1		177 Inoperable	4204
M31 A1		201 Inoperable	4204
M31 A1		53 Inoperable	4204
M31 A1		260 Inoperable	4204
Control box M31A1		39 Inoperable	4204
Control box M31A1		40 Inoperable	4204
M31 A1		147 Inoperable	4204
Audio amplifier	RAY201321368	Will not transmit	4211
Microphone cable	n/a	Inoperable	4211
Base station	A40126003191	Inoperable	4212
Mobile radio		9809568 Broken connector	4213
PA portable system	J701128	No audio	4214
W-107 cables	n/a	Repair 16 cables	4219
Mobile radio	KAT 301	Remove radio and wiring from old vehicle and install in new vehicle	4219
Mobile radio	KAT 122	Remove radio and wiring from old vehicle and install in new vehicle	4226
PA portable system	L301060	No audio	4227
Control box M31A1	24	Inoperable	4224
Control box M31A1	3	Inoperable	4224
RZ14 Backpack	HH309812-1606	Short in handset	4224
Mobile radio	Kat 312	Remove radio and wiring from old vehicle and install in new vehicle	4229
Mobile radio	RNG 4	No audio	4233
Mobile radio	KAT 313	Remove radio and wiring from old vehicle and install in new vehicle	4236
Mobile radio	RNG 81	Remove radio and wiring from old vehicle and install in new vehicle	4240
VCR	D17960492,D14923666 & U43903604	TI-for turnin 3 VCRs	4243
Mobile radio	KAT 221	Remove radio and wiring from old vehicle and install in new one	4247
Welding cable	n/a	Welding cable sparks intermittantly	4247
Mobile radio	9810798	Volume potentiometer broken	4247

Mobile radio	KAT 220	Remove radio and wiring	4250
Battery charger	6068	Power surge burned connectors	4254
Mobile radio	KAT 104	Radio not working	4255
LM ATS antennas	n/a	Repair 50 antennas	4256
Base station	9986288	Very low volume	4256
Power supply	WJ51160595	No output	4257
Drill, corded 1/2"	8913K0564	Inoperable	4257
Detector multi-gas	1507AQ-001	O2 sensor inop	4257
Fieldpro 5X camera	23080-095	No video	4257
Mobile radio	KAT 307	Remove radio and wiring	4257
P.A. microphones	n/a	2 microphones inop.	4260
Harris speaker	n/a	Inoperable	4260
Antenna cables	n/a	Build cables for Emergency van	4260
Hit sensor cables	n/a	Repair 22 cables for M31A1	4262
Power cables	n/a	Repair 30 cables for M31A1	4262
Detector multi-gas	15070AQ-003	O2 sensor inop	4263
Mobile radio	KAT 413	Knobs not working	4269
Base station	9986258	Reads "Security Check" only	4271
Harris radio	109708	Will not receive	4271
Harris radio	38879	Will not receive	4271
Connectors	n/a	Build connectors for Bosch plugins	4275
Base station	9986256	Will not transmit or receive properly	4274
Power cables	n/a	Repair 25 cables for M31A1	4242
Mobile radio	KAT 307	Install radio and wiring in new vehicle	4242
Mobile radio	KAT 220	Install radio and wiring in new vehicle	4244
Charger cable	n/a	Fabricate 2 cables for battery charger for RZ-14	4291
Mobile radio	KAT 129	Remove from old truck and install in new vehicle	4296
Point-to-point	002722DA7456	Inop-code out	4294
AxSys EOSS 500 camera	324 w/038 day cam	Video just shows white screen	4294
Harris radio	41429	Does not transmit	4304
Mobile radio	9809884	Error code "000C"	4333
Mobile radio	KAT 114	Install radio and wire in new vehicle	4334
SIT	29	Inoperable	4334
SIT	13	Inoperable	4334
MFS	n/a	4 Inoperable-Code out 3	4334
Setup device	HH341946	Password error	4340
Setup device	HH3419525	Password error	4340
Notebook rugged	RD463E0083	Inoperable	4340
Mobile radio	KAT 119	Remove from old truck and install in new vehicle	4341
Day camera	_057	White screen picture	4341
Battery charger	97	Inoperable	4345
Battery charger	6	Inoperable	4345
Battery charger	91	Inoperable	4345
Battery charger	480	Inoperable	4345
Mobile radio	KAT 104	Remove from old truck and install in new vehicle	4346
Base station	9986279	Goes to CC scan several times per minute	4346
Mobile radio	KAT 135	Remove from old truck and install in new vehicle	4347
HH batteries	n/a	Condition 50 batteries	4347
Actuator	11070938	Inoperable	4347
Battery charger	67	No light	4347
Mobile radio	KAT 301	Remove from old truck and install in new vehicle	4352
Mobile radio	KAT 316	Remove from old truck and install in new vehicle	4353
Mobile radio	KAT 305	Remove from old truck and install in new vehicle	4360
Battery charger	n/a	Replace connectors on 2 RZ-14 chargers	4360

Technical Exhibit J
Electrical and Mechanical Maintenance Workload

Note that the only information available to the Government about the amount of time to repair or the cost of repair is proprietary to previous contractor's methods and means.

NOMENCLATURE	SN/LN	REMARKS	Julian date NMC
Mobile radio	KAT 403	Remove from old truck and install in new vehicle	5008
Mobile radio	9809667	"cc scan" continuously	5011
Mobile radio	9809795	Will not transmit	5011
LM ATS antennas	n/a	Rebuild 50 LM ATS antennas	5016
Harris radio	C07513	Will not turn on	5016
PA microphone	MHL-5S	Intermittant operation	5016
PA amplifier	300-218-01	No ouput	5016
Portable PA	C180087	No ouput	5016
Power cables	n/a	Rebuild 26 power cables for M31	5017
Hit sensor cables	n/a	Rebuild 13 hit sensor cables for M31	5017
Antenna cables	n/a	Fabricate 6 THM/TG antenna cables	5018
Mobile radio	KAT 402	Remove from old truck and install in new vehicle	5022
Battery charger	n/a	Inoperable	5022
Base station	9986257	Only reads "security check"	5025
Detector multigas	15070AQ-001	Will not bump from docking station	5025
Base station	9986159	Will not transmit correctly	5035
Circuit cards	n/a	Repair 5 of 20-8255 cards	5036
Base station	9986311	Not transmitting	5037
Mobile radio	KAT 134	Install radio and all wiring in vehicle	5042
Portable PA	C4001780	No sound	5042
Portable PA	D603620	No sound	5042
Portable PA	A4001507	No sound	5042
Portable PA	13000610	No sound	5042
Mobile radio	KAT 130	Install radio and all wiring in vehicle	5042
HH radio	9139135	Inoperable	5042
Harris radio	41295	Cannot enter presets	5046
Mobile radio	9810527	Drains battery in off position	5051
Solar panel	n/a	damaged and cracked	5063
Solar panel	n/a	damaged and cracked	5063
Solar panel	n/a	damaged and cracked	5063
Solar panel	n/a	damaged and cracked	5063
Heat gun	H6301A	Inoperable	5066
Mobile radio	KAT 400	Remove from old truck and install in new vehicle	5070
Mobile radio	KAT 126	Remove from old truck and install in new vehicle	5071
Extension light	n/a	Keeps blowing circuit breaker	5071
Public address set	AP1016	No audio	5073
SIT	6137032	Inoperable	5077
Multimeter	5365174	Inoperable	5077
SIT	6137038	Inoperable	5078
Harris radio	40918	reads only sw upgrade needed	5081
Harris radio	41419	reads only sw upgrade needed	5081
Mobile radio	9809568	No power	5081
P.A. set	D603611	Inoperable- code out	5086
P.A. set	C4001779	Inoperable- code out	5086
Base station	9986260	Error code 0067	5086
Base station	9987950	Intermittant transmission	5086
AxSys EOSS 500 camera	316 w/009	No thermal image	5086
Antenna cables	n/a	Rebuild antenna for MAT	5051
Antenna cables	n/a	Fabricate 8 THM/TG antenna cables	5053
Mobile radio	KAT 105	Inoperable	5053

Setup device	00077	Inoperable	5053
Speakers	n/a	2 speakers inoperable	5055
Harris radio	41600	Will not transmit	5102
SIT	A01976	Inoperable	5102
RZ-14		Broken wire	5105
SIT	A00042	Cannot read the display	5105
Control box for M31	23	Inoperable	5105
Control box for M31	25	Inoperable	5105
Control box for M31	32	Inoperable	5105
Control box for M31	41	Inoperable	5105
Control box for M31	13	Inoperable	5105
Control box for M31	83	Inoperable	5105
Control box for M31	57	Inoperable	5105
Base station	9986254	Inoperable	5106
RZ-14	0000ICE2	Inoperable	5108
RZ-14	HH309812-1606	Inoperable	5108
RZ-14	HH309811-1606	Inoperable	5108
LM Setup device	HH51945	Inoperable	5108
Harris radio	41454	Software not validated	5108
LED MFS	15005016	Inoperable	5108
RZ-14 Battery pack	n/a	Fabricate 4 battery packs	5105
Detector multi-gas	15070AQ-001	Will not calibrate in docking station	5120
AxSys EOSS 500 camera	321 w/day cam 187	Does not initialize	5123
Mobile radio	9809658	Very low audio, distorted transmission	5127
ICB	50 attached sheet	TI -for turn in Pallet # 1	5130
ICB	50 attached sheet	TI -for turn in Pallet # 2	5130
ICB	50 attached sheet	TI -for turn in Pallet # 3	5130
ICB	50 attached sheet	TI -for turn in Pallet # 4	5130
ICB	50 attached sheet	TI -for turn in Pallet # 5	5130
ICB	50 attached sheet	TI -for turn in Pallet # 6	5130
ICB	50 attached sheet	TI -for turn in Pallet # 7	5130
ICB	50 attached sheet	TI -for turn in Pallet # 8	5130
ICB	50 attached sheet	TI -for turn in Pallet # 9	5130
ICB	50 attached sheet	TI -for turn in Pallet # 10	5130
Receiver Subassembly	28 attached sheet	TI -for turn in Pallet # 1	5133
Receiver Subassembly	22 attached sheet	TI -for turn in Pallet # 2	5133
Moving target carrier	0005	Oil/fluid drainage	5133
Moving target carrier	0015	Oil/fluid drainage	5133
Moving target carrier	0024	Oil/fluid drainage	5133
Moving target carrier	0029	Oil/fluid drainage	5133
Moving target carrier	0039	Oil/fluid drainage	5133
Moving target carrier	0047	Oil/fluid drainage	5133
Moving target carrier	0050	Oil/fluid drainage	5133
Moving target carrier	0145	Oil/fluid drainage	5133
Moving target carrier	0153	Oil/fluid drainage	5133
Moving target carrier	0164	Oil/fluid drainage	5133
Moving target carrier	0182	Oil/fluid drainage	5133
Moving target carrier	0200	Oil/fluid drainage	5133
Moving target carrier	0007	Oil/fluid drainage	5133
Moving target carrier	0020	Oil/fluid drainage	5133
Moving target carrier	0025	Oil/fluid drainage	5133
Moving target carrier	0036	Oil/fluid drainage	5133
Moving target carrier	0041	Oil/fluid drainage	5133
Moving target carrier	0048	Oil/fluid drainage	5133
Moving target carrier	0052	Oil/fluid drainage	5133
Moving target carrier	0147	Oil/fluid drainage	5133
Moving target carrier	0158	Oil/fluid drainage	5133
Moving target carrier	0167	Oil/fluid drainage	5133

Moving target carrier	0185	Oil/fluid drainage	5133
Moving target carrier	0206	Oil/fluid drainage	5133
Moving target carrier	0014	Oil/fluid drainage	5133
Moving target carrier	0022	Oil/fluid drainage	5133
Moving target carrier	0028	Oil/fluid drainage	5133
Moving target carrier	0038	Oil/fluid drainage	5133
Moving target carrier	0044	Oil/fluid drainage	5133
Moving target carrier	0057	Oil/fluid drainage	5133
Moving target carrier	0152	Oil/fluid drainage	5133
Moving target carrier	0161	Oil/fluid drainage	5133
Moving target carrier	0199	Oil/fluid drainage	5133
Moving target carrier	0212	Oil/fluid drainage	5133
G.E. Master II	8438305	TI -for turn in	5135
G.E. Master II	8438328	TI -for turn in	5135
G.E. Master II	8438325	TI -for turn in	5135
G.E. Master II	8438308	TI -for turn in	5135
G.E. Master II	8438304	TI -for turn in	5135
G.E. Master II	8438318	TI -for turn in	5135
G.E. Master II	8438326	TI -for turn in	5135
FM Intercomm system	n/a	Inoperable	5135
FM Intercomm system	n/a	Inoperable	5135
FM Intercomm system	n/a	Inoperable	5135
LM ATS antennas	n/a	Rebuild 50 LM ATS antennas	5137
ICB	24 attached sheet	TI -for turn in	5143
Base station	9987328	Intermittantly cycles CC & WA	5143
Harris Amplifier VUPA	001416	Inoperable	5155
Harris Amplifier VUPA	001473	Inoperable	5155
Harris Amplifier VUPA	001448	Inoperable	5155
Harris Amplifier VUPA	001463	Inoperable	5155
Harris Amplifier VUPA	001450	Inoperable	5155
Control box for M31 A1	13	Inoperable	5161
Control box for M31 A1	44	Inoperable	5161
Control box for M31 A1	22	Inoperable	5161
Control box for M31 A1	3	Inoperable	5161
Control box for M31 A1	9	Inoperable	5161
Mobile radio	9809784	Broken power knob	5163
Mobile radio	9809808	Doesn't transmit, displays "Range C"	5163
Battery charger	99	Inoperable	5164
Battery charger	95	Inoperable	5164
Mobile radio	KAT 110	Not transmitting	5164
Control box for M31 A1	109	Fabricate new control box	5164
Power cables for M31	n/a	Repair 25 M31 power cables	5165
MFS	n/a	TI for turn in 190 total	5168
Moving target carrier	145	TI -for turn in	5165
Moving target carrier	147	TI -for turn in	5165
Moving target carrier	153	TI -for turn in	5165
Moving target carrier	182	TI -for turn in	5165
Moving target carrier	185	TI -for turn in	5165
Moving target carrier	200	TI -for turn in	5165
Moving target carrier	206	TI -for turn in	5165
Moving target carrier	212	TI -for turn in	5165
Moving target carrier	5	TI -for turn in	5165
Moving target carrier	7	TI -for turn in	5165
AMTC	45	TI -for turn in	5165
AMTC	46	TI -for turn in	5165
AMTC	47	TI -for turn in	5165
AMTC	48	TI -for turn in	5165
AMTC	66	TI -for turn in	5165

AMTC	76	TI -for turn in	5165
AMTC	F00033	TI -for turn in	5165
AMTC	F00034	TI -for turn in	5165
AMTC	R0001	TI -for turn in	5165
AMTC	R0002	TI -for turn in	5165
MAT	101	TI -for turn in	5165
MAT	102	TI -for turn in	5165
IMTC	D4387	TI -for turn in	5165
IMTC	D5037	TI -for turn in	5165
IMTC	H2986	TI -for turn in	5165
IMTC	H2992	TI -for turn in	5165
IMTC	H2996	TI -for turn in	5165
IMTC	H2999	TI -for turn in	5165
IMTC	H3002	TI -for turn in	5165
IMTC	H3006	TI -for turn in	5165
IMTC	H3011	TI -for turn in	5165
IMTC	H3014	TI -for turn in	5165
IMTC	D4468	TI -for turn in	5165
IMTC	D5191	TI -for turn in	5165
IMTC	D6126	TI -for turn in	5165
IMTC	H2987	TI -for turn in	5165
IMTC	H2994	TI -for turn in	5165
IMTC	H2997	TI -for turn in	5165
IMTC	H3000	TI -for turn in	5165
IMTC	H3003	TI -for turn in	5165
IMTC	H3007	TI -for turn in	5165
IMTC	H3012	TI -for turn in	5165
IMTC	H3015	TI -for turn in	5165
IMTC	D4681	TI -for turn in	5165
IMTC	D5192	TI -for turn in	5165
IMTC	H2984	TI -for turn in	5165
IMTC	H2988	TI -for turn in	5165
Moving target carrier	14	TI -for turn in	5165
Moving target carrier	15	TI -for turn in	5165
Moving target carrier	20	TI -for turn in	5165
Moving target carrier	22	TI -for turn in	5165
Moving target carrier	24	TI -for turn in	5165
Moving target carrier	25	TI -for turn in	5165
Moving target carrier	28	TI -for turn in	5165
Moving target carrier	36	TI -for turn in	5165
Moving target carrier	38	TI -for turn in	5165
Moving target carrier	39	TI -for turn in	5165
Moving target carrier	41	TI -for turn in	5165
Moving target carrier	44	TI -for turn in	5165
Moving target carrier	47	TI -for turn in	5165
Moving target carrier	48	TI -for turn in	5165
Moving target carrier	49	TI -for turn in	5165
Moving target carrier	50	TI -for turn in	5165
Moving target carrier	52	TI -for turn in	5165
Moving target carrier	57	TI -for turn in	5165
Moving target carrier	158	TI -for turn in	5165
Moving target carrier	161	TI -for turn in	5165
Moving target carrier	164	TI -for turn in	5165
Moving target carrier	167	TI -for turn in	5165
Moving target carrier	168	TI -for turn in	5165
Mobile radio	KAT 223	Remove from old truck and install in new vehicle	5165
Base station	9986257	Does not turn on	5165
Harris Amplifier VUPA	1460	Inoperable RMA 1-377149220	5170

Harris Amplifier VUPA	1389	Inoperable RMA 1-377149259	5170
PRC-127 HH	23961	TI -for turn in	5170
PRC-127 HH	34344	TI -for turn in	5170
PRC-127 HH	24441	TI -for turn in	5170
PRC-127 HH	3694	TI -for turn in	5170
PRC-127 HH	3778	TI -for turn in	5170
PRC-127 HH	23932	TI -for turn in	5170
PRC-127 HH	34631	TI -for turn in	5170
PRC-127 HH	29794	TI -for turn in	5170
PRC-127 HH	3793	TI -for turn in	5170
PRC-127 HH	23962	TI -for turn in	5170
PRC-127 HH	34508	TI -for turn in	5170
PRC-127 HH	24435	TI -for turn in	5170
PRC-127 HH	34500	TI -for turn in	5170
PRC-127 HH	3591	TI -for turn in	5170
PRC-127 HH	3780	TI -for turn in	5170
PRC-127 HH	23956	TI -for turn in	5170
PRC-127 HH	34472	TI -for turn in	5170
PRC-127 HH	35030	TI -for turn in	5170
PRC-127 HH	3791	TI -for turn in	5170
PRC-127 HH	23921	TI -for turn in	5170
PRC-127 HH	34817	TI -for turn in	5170
PRC-127 HH	23944	TI -for turn in	5170
PRC-127 HH	34412	TI -for turn in	5170
PRC-127 HH	3713	TI -for turn in	5170
PRC-127 HH	24411	TI -for turn in	5170
PRC-127 HH	23955	TI -for turn in	5170
PRC-127 HH	24417	TI -for turn in	5170
AA 8 SIT	6137029	Inoperable	5171
AA 8 SIT	6137038	Inoperable	5171
RZ-14	HH1309811-1606	Has a short in it	5171
RZ-14	HH309812-1606	Will not come on	5171
LM Setup device	HH151945	Will not come on	5171
Amplifier	701151	Doesn't transmit	5171
M31 A1	177	Inoperable	5171
M31 A1	497	Inoperable	5171
M31 A1	73	Inoperable	5171
M31 A1	395	Inoperable	5171
M31 A1	464	Inoperable	5171
M31 A1	288	Inoperable	5171
M31 A1	244	Inoperable	5171
M31 A1	347	Inoperable	5171
M31 A1	3	Inoperable	5171
M31 A1	83	Inoperable	5171
M31 A1	390	Inoperable	5171
M31 A1	63	Inoperable	5171
Power cables for M31	n/a	Repair 25 M31 power cables	5171
Hit sensor cables	n/a	Rebuild 15 M31 hit sensor cables	5171
Base station	9986257	Inoperable	5150
Mobile radio	9809625	Will not turn off	5150
AxSys EOSS 500 camera	318 w/ day cam 052	Inoperable	5150
Mobile radio	9809884	Reads "Security check" only	5150
Sincgars RT-1523D	43147A	TI -for turn in	5150
Sincgars RT-1523D	43475A	TI -for turn in	5150
Sincgars RT-1523D	43814A	TI -for turn in	5150
Sincgars RT-1523D	44084A	TI -for turn in	5150
Sincgars RT-1523D	44379A	TI -for turn in	5150
Sincgars RT-1523D	43605A	TI -for turn in	5150

Rigid LiIon battery	CS15024N41116	Does not take a charge	5232
IRETS	152	TI for turn in	5233
IRETS	199	TI for turn in	5233
LM ATS antennas	n/a	Rebuild 50 LM ATS antennas	5235
Stapler, heavy duty	GB85304	Inop	5235
P.A. set	A4001469	Inoperable	5235
Power strip	n/a	Inop	5238
Load tester	n/a	Inop	5240
Base station	9987307	Inoperable	5248
Power supply	R3273	TI for turn in	5252
Power supply	R0315	TI for turn in	5252
Hydraulic hose	n/a	Broken	5252
Floor scrubber	n/a	Power cord broken	5254
MFS	n/a	Shot by round -CODE OUT	5254
Antenna cables	n/a	Fabricate 5 THM/TG antenna cables	5254
Paper shredder	42853	TI for turn in	5261
Paper shredder	99857	TI for turn in	5261
Paper shredder	189239	TI for turn in	5261
Paper shredder	97699	TI for turn in	5261
Paper shredder	35184	TI for turn in	5261
Paper shredder	406905	TI for turn in	5261
Paper shredder	VB-0219326	TI for turn in	5261
Paper shredder	141234	TI for turn in	5261
Paper shredder	42843	TI for turn in	5261
Paper shredder	42982	TI for turn in	5261
Paper shredder	VB-0219325	TI for turn in	5261
Paper shredder	97876	TI for turn in	5261
Light bars (2)	n/a	TI for turn in	5261
Harris radio	41523	"software not validated"	5261
Harris Amplifier VUPA	1467	Inoperable	5265
Harris Amplifier VUPA	1465	Inoperable	5265
Angle grinder	15577	Short in cord	5274
Mobile radio	9809648	Error code 000C	5276
Mobile radio	9809868	No power	5276
Camera controller	1022	Inoperable	5277
Camera controller	72	Inoperable	5277
Base station	A40126001391	Has no audio	5277
MFS light	579108	Case broken	5277
Solar panel	n/a	55w panel is shorted	5283
Solar panel	n/a	70w panel terminal box is badly corroded	5283
SIT thermal connectors	n/a	Build 4 SIT thermal connectors	5250
Floor fan	GAC30P	Inoperable	5254
Antenna cables	n/a	Fabricate 2 MA/COM antenna cables	5254
Antenna extension	n/a	Fabricate 4 extension antenna cables	5255
Amplifier	328148	TI for turn in	5301
Mobile radio	98029862	Error code 0067	5302
Mobile radio	KAT 411	Install radio and all associated wiring in Humvee	5305
Mobile radio	KAT 304	Remove from old truck and install in new vehicle	5308
Circular saw	CS15052D040120	Inoperable -Code out	5311
Mobile radio	KAT 317	Remove from old truck and install in new vehicle	5311
LM ATS antennas	n/a	Rebuild 50 LM ATS antennas	5318
PA speaker	n/a	Inop -CODE OUT	5315
Antenna, Tsunami	19US16550067	Inoperable	5315
M31 A1	53	Inoperable	5315
M31 A1	168	Inoperable	5315
M31 A1	242	Inoperable	5315
M31 A1	148	Inoperable	5315
M31 A1	413	Inoperable	5315

M31 A1	214	Inoperable	5315
Power supply	261XTA0012	TI -for turn in	5315
Power supply	261XSS0010	TI -for turn in	5315
Power supply	261XSS0011	TI -for turn in	5315
Power supply	261XSS0012	TI -for turn in	5315
Power supply	261XSS0013	TI -for turn in	5315
Power supply	261XSS0015	TI -for turn in	5315
Power supply	261XSS0016	TI -for turn in	5315
Power supply	261XSY0009	TI -for turn in	5315
Power supply	261XSS0001	TI -for turn in	5315
Power supply	261XTA0005	TI -for turn in	5315
Power supply	261XTC0004	TI -for turn in	5315
Power supply	261XTA0013	TI -for turn in	5315
Power supply	261XTA0015	TI -for turn in	5315
Power supply	261XTA0016	TI -for turn in	5315
Power supply	261XTA0017	TI -for turn in	5315
Power supply	261XTA0018	TI -for turn in	5315
Power supply	261XTC0001	TI -for turn in	5315
Power supply	261XTC0002	TI -for turn in	5315
Power supply	261XSY0012	TI -for turn in	5315
Power supply	261XSS0000	TI -for turn in	5315
Base station	9987953	Power cycles off and on	5322
Mobile radio	KAT 314	Remove from old truck and install in new vehicle	5322
System Monitor-DW	19851	TI -for turn in	5324
System Monitor-DW	19855	TI -for turn in	5324
System Monitor-DW	19852	TI -for turn in	5324
System Monitor-DW	19847	TI -for turn in	5324
System Monitor-DW	19945	TI -for turn in	5324
System Monitor-DW	19948	TI -for turn in	5324
Power Supply Astron (DW)	203010049	TI -for turn in	5325
Power Supply Astron (DW)	203010046	TI -for turn in	5325
Power Supply Astron (DW)	203010042	TI -for turn in	5325
Power Supply Astron (DW)	203010040	TI -for turn in	5325
Power Supply Astron (DW)	203010012	TI -for turn in	5325
Power Supply Astron (DW)	203010005	TI -for turn in	5325
Power Supply Astron (DW)	203010045	TI -for turn in	5325
Power Supply Astron (DW)	203010041	TI -for turn in	5325
Power Supply Astron (DW)	203010002	TI -for turn in	5325
Radio, Base station	22942	TI -for turn in	5325
Radio, Base station	22835	TI -for turn in	5325
Radio, Base station	22939	TI -for turn in	5325
Radio, Base station	22831	TI -for turn in	5325
Radio, Base station	22830	TI -for turn in	5325
Radio, Base station	22823	TI -for turn in	5325
8 Mounting Base	n/a	TI -for turn in	5325
31 Handset	n/a	TI -for turn in	5325
9 Loudspeaker	n/a	TI -for turn in	5325
Mounting Base	n/a	TI -for turn in	5325
Amplifier	n/a	TI -for turn in	5325
Radio set	n/a	TI -for turn in	5325
Amplifier-adapter	005986C	TI -for turn in	5325
Amplifier-adapter	007873C	TI -for turn in	5325
Amplifier-adapter	002540C	TI -for turn in	5325
Amplifier-adapter	000624C	TI -for turn in	5325
Amplifier-adapter	009093C	TI -for turn in	5325
Amplifier-adapter	006205C	TI -for turn in	5325
Transmitter (DW)	10308	TI -for turn in	5326
Transmitter (DW)	10307	TI -for turn in	5326

Transmitter (DW)	10306	TI -for turn in	5326
Transmitter (DW)	10305	TI -for turn in	5326
Transmitter (DW)	10302	TI -for turn in	5326
Transmitter (DW)	10301	TI -for turn in	5326
Transmitter (DW)	10298	TI -for turn in	5326
Transmitter (DW)	10295	TI -for turn in	5326
Transmitter (DW)	10294	TI -for turn in	5326
Radio receiver (DW)	10349	TI -for turn in	5326
Radio receiver (DW)	10348	TI -for turn in	5326
Radio receiver (DW)	10347	TI -for turn in	5326
Radio receiver (DW)	10346	TI -for turn in	5326
Radio receiver (DW)	10341	TI -for turn in	5326
Radio receiver (DW)	10339	TI -for turn in	5326
Radio receiver (DW)	10338	TI -for turn in	5326
Radio receiver (DW)	10323	TI -for turn in	5326
Radio receiver (DW)	10316	TI -for turn in	5326
Remote control (DW)	96-50-038REVJ	TI -for turn in	5325
Camera controller	072	Inoperable	5325
Camera controller	1022	Inoperable	5325
Circuit cards	n/a	Repair 5 circuit cards -8255	5335
HH batteries	n/a	Recondition 24 batteries	5335
THM/TG	A7129	TI -for turn in	5335
Amplifier	930100183	TI -for turn in	5335
Harris radio	41388	Falcon III has crypto error	5343
Strobe MFS	n/a	Inoperable-CODE OUT	5345
Network switching hub	2162123A04CC5	Inoperable-CODE OUT	5347
RZ-4 controller	98257015	TI -for turn in	5353
RZ-4 controller	98016017	TI -for turn in	5353
RZ-4 controller	98016015	TI -for turn in	5353
RZ-4 controller	98011985	TI -for turn in	5353
RZ-4 controller	98011933	TI -for turn in	5353
RZ-4 controller	98011932	TI -for turn in	5353
RZ-4 controller	98011930	TI -for turn in	5353
RZ-4 controller	98011929	TI -for turn in	5353
RZ-4 controller	98010145	TI -for turn in	5353
RZ-4 controller	98016016	TI -for turn in	5353
RZ-4 controller	98011931	TI -for turn in	5353
HH Controller	HH377823	Reboots RZ-14 when connected	5360
SIT	06137019	Inoperable	5078
Amplifier	B1710110966030012	Inoperable	5081
Control box for M31	11	Inoperable	5148
ITM	A00036	Shot -CODE OUT	5148
MFS	n/a	Broken case and connector -CODE OUT	5148
Control box for M31	45	Broken connector	5148
Power cables	n/a	Rebuild 2 power cables	5148
ICB	CCRA-B(203)	CODE OUT	5205
ITM	C03347	CODE OUT	5205
Controller, remote	93-20-130E	TI -for turn in	5325
Controller, remote	93-20-113E	TI -for turn in	5325
Controller, remote	93-20-114E	TI -for turn in	5325
Remote control (DW)	96-50-055REVJ	TI -for turn in	5325
Remote control (DW)	96-50-063REVJ	TI -for turn in	5325
Remote control (DW)	96-50-064REVJ	TI -for turn in	5325
Remote control (DW)	96-50-060REVJ	TI -for turn in	5325
Remote control (DW)	96-50-046REVJ	TI -for turn in	5325
Remote control (DW)	96-50-045REVJ	TI -for turn in	5325
Remote control (DW)	96-50-039REVJ	TI -for turn in	5325
Remote control (DW)	96-50-054REVJ	TI -for turn in	5325

Remote control (DW)	96-50-065REVJ	TI -for turn in	5325
Controller, remote	13-23-343A	TI -for turn in	5325
Controller, remote	13-23-342A	TI -for turn in	5325
Controller, remote	3-12-004A	TI -for turn in	5325
Controller, remote	05-13-0709A	TI -for turn in	5325
Controller, remote	05-13-0708A	TI -for turn in	5325
Controller, remote	05-13-0707A	TI -for turn in	5325
Controller, remote	05-13-0706A	TI -for turn in	5325
Controller, remote	91-45-559J	TI -for turn in	5325
Controller, remote	91-45-554J	TI -for turn in	5325
Controller, remote	91-45-570J	TI -for turn in	5325
Controller, remote	91-45-563J	TI -for turn in	5325
Controller, remote	91-45-560J	TI -for turn in	5325
Controller, remote	91-45-558J	TI -for turn in	5325
Controller, remote	91-45-552J	TI -for turn in	5325
Controller, remote	9717104REVJ	TI -for turn in	5325
Adapter, remote DC	740CSP2961	TI -for turn in	5325
Adapter, remote DC	740CSP3657	TI -for turn in	5325
Adapter, remote DC	740CSP3654	TI -for turn in	5325
Adapter, remote DC	740CSP2964	TI -for turn in	5325
Adapter, remote DC	417CWM5081	TI -for turn in	5325
Adapter, remote DC	740CSP3655	TI -for turn in	5325
Adapter, remote DC	740CSP3659	TI -for turn in	5325
Adapter, remote DC	740CSP2958	TI -for turn in	5325
Adapter, remote DC	740CSP3301	TI -for turn in	5325
Adapter, remote DC	740CSP3671	TI -for turn in	5325
Adapter, remote DC	740CSP3303	TI -for turn in	5325
Adapter, remote DC	740CSP3668	TI -for turn in	5325
Adapter, remote DC	740CSP3304	TI -for turn in	5325
Adapter, remote DC	740CSP2962	TI -for turn in	5325
Adapter, remote DC	740CSP3308	TI -for turn in	5325
Adapter, remote DC	740CSP3302	TI -for turn in	5325
Adapter, remote DC	740CSP2963	TI -for turn in	5325
Adapter, remote DC	740CSP3306	TI -for turn in	5325
Adapter, remote DC	740CSP2960	TI -for turn in	5325
Adapter, remote DC	740CSP3307	TI -for turn in	5325
Adapter, remote DC	740CSP3670	TI -for turn in	5325
Adapter, remote DC	740CSP3658	TI -for turn in	5325
Adapter, remote DC	740CSP3653	TI -for turn in	5325
Adapter, remote DC	740CSP3656	TI -for turn in	5325
Adapter, remote DC	740CSP3673	TI -for turn in	5325
Adapter, remote DC	740CSP3309	TI -for turn in	5325
Adapter, remote DC	740CSP3305	TI -for turn in	5325
Adapter, remote DC	740CSP3669	TI -for turn in	5325
Adapter, remote DC	740CSP3667	TI -for turn in	5325
Controller DC remote	9029908	TI -for turn in	5325
Controller DC remote	03120202	TI -for turn in	5325
Controller DC remote	03120902	TI -for turn in	5325
Controller DC remote	03121002	TI -for turn in	5325
Controller DC remote	03121102	TI -for turn in	5325
Controller DC remote	04195400	TI -for turn in	5325
Controller DC remote	06266507	TI -for turn in	5325
Controller DC remote	01310702	TI -for turn in	5325
Controller DC remote	09029808	TI -for turn in	5325
Controller DC remote	12191907	TI -for turn in	5325
Controller DC remote	09080308	TI -for turn in	5325
Controller DC remote	09080408	TI -for turn in	5325
Controller DC remote	10194412	TI -for turn in	5325

Controller DC remote	10194512	TI -for turn in	5325
Controller DC remote	10194812	TI -for turn in	5325
Controller DC remote	11056798	TI -for turn in	5325
Controller DC remote	11056898	TI -for turn in	5325
Controller DC remote	09029608	TI -for turn in	5325
Controller, remote	05-13-0705A	TI -for turn in	5325
2 Steel job boxes	n/a	TI -for turn in	5330
Stapler pneumatic	AG12318	Inoperable-CODE OUT	5330
Power amp	2178	TI -for turn in	5330
Power amp	2177	TI -for turn in	5330
Power amp	2176	TI -for turn in	5330
Power amp	2175	TI -for turn in	5330
Power amp	2174	TI -for turn in	5330
Power amp	2173	TI -for turn in	5330
Power amp	2172	TI -for turn in	5330
Power amp	2171	TI -for turn in	5330
Power amp	2170	TI -for turn in	5330
Power amp	2169	TI -for turn in	5330
Power amp	2168	TI -for turn in	5330
Power amp	2167	TI -for turn in	5330
Power amp	2166	TI -for turn in	5330
Power amp	2165	TI -for turn in	5330
Power amp	2164	TI -for turn in	5330
Transmitter (DW)	10297	TI -for turn in	5331
Transmitter (DW)	10296	TI -for turn in	5331
Transmitter (DW)	10293	TI -for turn in	5331
Transmitter (DW)	10292	TI -for turn in	5331
Transmitter (DW)	10290	TI -for turn in	5331
Transmitter (DW)	10200	TI -for turn in	5331
Radio, Base station	22832	TI -for turn in	5331
Radio, Base station	22940	TI -for turn in	5331
Radio, Base station	22821	TI -for turn in	5331
Radio, Base station	22818	TI -for turn in	5331
Radio receiver (DW)	10343	TI -for turn in	5331
Radio receiver (DW)	10342	TI -for turn in	5331
Radio receiver (DW)	10340	TI -for turn in	5331
Radio receiver (DW)	10337	TI -for turn in	5331
Radio receiver (DW)	10336	TI -for turn in	5331
Radio receiver (DW)	10330	TI -for turn in	5331
Power Supply Astron (DW)	203010047	TI -for turn in	5331
Power Supply Astron (DW)	203010044	TI -for turn in	5331
Power Supply Astron (DW)	203010043	TI -for turn in	5331
Power Supply Astron (DW)	203010039	TI -for turn in	5331
Power Supply Astron (DW)	203010006	TI -for turn in	5331
Power Supply Astron (DW)	202120008	TI -for turn in	5331
System Monitor-DW	19853	TI -for turn in	5331
System Monitor-DW	19845	TI -for turn in	5331
System Monitor-DW	19946	TI -for turn in	5331
System Monitor-DW	19843	TI -for turn in	5331
RZ-4 controller	98067022	TI -for turn in	5354
Radio, base station	531ASU0097	TI -for turn in	5354
Remote control (DW)	96-50-044REV-J	TI -for turn in	5354
Remote control (DW)	96-50-038REV-J	TI -for turn in	5354
Controller, remote	91-45-564-J	TI -for turn in	5354
Controller, remote	91-45-567-J	TI -for turn in	5354
Controller, remote	91-45-553-J	TI -for turn in	5354
Remote ctl RCT2GM	91455	TI -for turn in	5354
29 Harris desktop microphones	n/a	TI -for turn in	5354

12 Vehicle speakers	n/a	Inop -CODE OUT	5354
8 PRC-127 battery chargers	n/a	TI -for turn in	5354
15 Vehicle hand microphones	n/a	Inop -CODE OUT	5354
6 Motorola displays	n/a	TI -for turn in	5354
18 Motorola hand microphones	n/a	TI -for turn in	5354
8 Harris handsets	n/a	Inop -CODE OUT	5354
22 CPI/IDA desk microphones	n/a	TI -for turn in	5354
CCU	00165	TI -for turn in	5357
CCU	00166	TI -for turn in	5357
CCU	00167	TI -for turn in	5357
CCU	00168	TI -for turn in	5357
CCU	00170	TI -for turn in	5357
CCU	00171	TI -for turn in	5357
CCU	00172	TI -for turn in	5357
CCU	0101	TI -for turn in	5357
CCU	0104	TI -for turn in	5357
CCU	0106	TI -for turn in	5357
CCU	00005	TI -for turn in	5357
CCU	00014	TI -for turn in	5357
CCU	00027	TI -for turn in	5357
CCU	H0203	TI -for turn in	5357
Mobile radio	KAT 311	Inop	5360