ArduinoProMicro

Layout andimoto6064

Row	Col	1	2	! ;	3 4	5	6	7	7 8	3 9	10	11	12	13
	Col [] Row []	0	1		2 3	4	5	6	5 7	7 8	9	10	11	. 12
2		Esc `/~	1 F1	2 F2	3 F3	4 F4	5 F5	6 F6	7 F7	8 F8	9 F9	0 F10	Minus F11	Equal F12
3	2	Tab	Q	W	E	R	Т	Y	U	I	0	Р	[]
4	3	L-Shift/ Reset	A	S	D	F4	G	Н	J	K	L	•	ı	Enter
5	4	L-Shift	Z	X	С	V	В	N	M	,		/	R-Shift	Up
6	5	L-Ctrl	LGUI / Win	Alt	Space	Fn (Mo)	App/ Context	Left	Down	Right	Del	\	BkSpc	