SPAGHETTILAB | ONE BOARD, MANY POSSIBILITIES

Connect a circuit, choose how each port behaves, and explore what happens.

CONNECTIONS & POWER

DIRECT ACCESS

J1 — PZ25-7S-5V5-R

Connects accessories directly to the optional ESP32.

ACCESSORY POWER

J8 — MEB3211209MG-A — MEB3211 | 2.8 V accessory supply
Powers accessories that need a lower voltage.

J10 — MEB3211209MG-A — MEB3211 | 3.5 V accessory supply
Powers accessories that need a lower voltage.

Provides 2.8 V and 3.5 V accessory power.

OPTIONAL ESP32 MODULE

U1 — ESP32-S3-WROOM-1-N16R8 — ESP32-S3 | Optional wireless module
Adds Wi-Fi, Bluetooth and ESP-NOW support.

MAIN POWER

U3 — TPS563201DDCR — TPS563201 | Main power supply
Creates the power used by the board.

Turns the incoming power into the supply used by the board.

PORT LIGHTS

LED1 — SML0603RGB-C

Shows the state of each port with coloured light.

OPTIONAL ACCESSORY LINKS

Provides 3.3 V, GND, SCL, SDA, IRQ, RST and UART lines.

ROBOTIC ACCESSORIES

J6 — PH2.0-4VS-0.5SHDS

Connects compatible sensors with a small cable.

RIBBON-CABLE EXPANSION

J7 — FFC-0.5-40S-P1.0-01

Connects displays, cameras and other supported add-ons.

BOARD-TO-BOARD LINK

J2 — 5-104948-4

Passes power and communication to neighbouring boards.

NETWORK CONNECTION

U7 — SN65HVD230DR

Lets this board exchange messages with the other boards.

USB CONNECTION

U6 — USBLC6-2SC6

Connects the board to a computer.

SIGNAL CONNECTIONS

U12 — SN74CB3T3125PWR
U13 — SN74CB3T3125PWR

U12 / U13 | Bidirectional signal switches
Connect or disconnect the ESP32 from the experiment ports.

Connects or separates the ESP32 signals from the experiment.

SIX EXPERIMENT PORTS

Q1 — AO6604
Q2 — AO6604
Q3 — AO6604
Q4 — AO6604
Q5 — AO6604
Q6 — AO6604
Q7 — AO6604
Q8 — AO6604
Q9 — AO6604
Q10 — AO6604

J1 — TB128-0418
J2 — TB128-0418
J3 — TB128-0418
J4 — TB128-0418
J5 — TB128-0418
J6 — TB128-0418
J7 — TB128-0418
J8 — TB128-0418
J9 — TB128-0418
J10 — TB128-0418

Gives each port a signal, power or ground connection.

Q1–Q8 | Electronic power switches
Give a port power or ground when selected.

CONTROL & LAB TOOLS

U1A–U1G are seven sections of ONE physical AG32 chip.

PORT SUPERVISOR

U1A — AG32P4STH27E

AG32 section A | Experiment signals
Reads the board and port digital signals.

Observes the ports and manages digital signals for the experiment.

PORT MODE CONTROL

U1A — AG32P4STH27E

AG32 section B | Port settings
Chooses how each experiment port is connected.

Chooses how each experiment port is connected.

SUPERVISOR START-UP

U1A — AG32P4STH27E

Y1 — 20MHz

20 MHz | Controller clock
Keeps the controller running at a steady pace.

AG32 section F | Power and start-up
Starts the controller and provides programming access.

COMMUNICATION HUB

U1A — AG32P4STH27E

AG32 section C | Board communication
Links the controller to USB, the network and the optional ESP32.

CURRENT MEASUREMENT

U11 — AG32P4STH27E

AG32 section D | Current scan control
Chooses which port is measured.

U5A — HX6B8C16G — THAT4618ASZ-U
U5B — HX6B8C16G — THAT4618ASZ-U

U55 | First measurement selector
Connects one side of the selected current sensor path.

U55 | Second measurement selector
Connects the other side of the same sensor path.

U18 — INA226AIDGSR

INA226 | Current sensor
Measures the current of the selected port.

Selects one port at a time and measures the current flowing through it.

LOCAL POWER SUPPORT

Keeps the controller supply steady while it works.

ADJUSTABLE TEST OUTPUT

U11 — AG32P4STH27E

U5C — HX6B8C16G — THAT4618ASZ-U

AG32 section E | Test signal control
Sets the test voltage and chooses its destination.

U55 | Test output selector
Sends the test signal to one of the six ports.

Sends a chosen voltage to one port for experiments and simple component tests.

ESP32 PROGRAMS THE AG32

Loads the board controller without an external programmer.

GPIO47 TX // GPIO48 RX | GPIO35 BOOT0 | GPIO36 MCU_RST (open-drain)

R1 — 10k
R2 — 10k
R3 — 10k
R4 — 10k

R1 sets0: Yr ymsh / Rn yhmh. BOOT1 shqs LOW via RBk.

Recovery keep ESP32 pins 41–2: use UART pads or the existing JTAG pads.

SERVICE & SPARE ACCESS

U14 — AG32P4STH27E

AG32 section G | Spare inputs and port control
Spare analog inputs 150k/100k use pins35/36.

Provides spare analog inputs and test port-control test points.

Existing circuit preserved. Tester features require firmware and prototype validation: no new tester components were added.

Single-page schematic. Functional descriptions are not performance specifications.

Title: SpaghettiLab — functional overview
Size: A0 | Date: | Rev: A1.0
What it is | Version