

× 5	2	
	(3-SKT7)	READER LAMPS AND SWITCHES.
	(3-SKT6)	TAPE READER SIGNAL INPUT AND 10V. DC. SUPPLY.
	3-\$KT-5	MAINS VOLTAGE TO READER MOTOR. RUNOUT STOP AND TAPE OUT SWITCHES.
TOP	3-SKI-4	+28V. SOURCE TO PUNCH COILS. PICK-UP COILS.
	3-SKT3	MAINS VOLTAGE TO TAPE PUNCH.
	3-PL-2	INPUTS TO READER TRANSMITTERS. INPUTS TO PUNCH RECEIVERS.
	3-PL-1	28V. DC. SUPPLY AND MAINS INPUT TO TAPE PUNCH.
	IN THE	

REAR VIEW

POS.	DESIGNATION	FUNCTION	DRAWING No.
1	A-FY.	+6.0V. DC. OV6.0V. DC. POWER SUPPLY.	322 D 4917 SHT, 1.
2	A-AR3.	PAPER TAPE READER CONTROL 2.	322 C 2549
3	A-AQ3.	PAPER TAPE READER CONTROL 1.	322 C 5121
4	A - AP3.	PAPER TAPE READER REGISTER.	322 C 2481
5	A → FX.	RECEIVERS AND TRANSMITTERS.	322 C 4611
6	A - A03	PAPER TAPE PUNCH CONTROL 2.	322 C 2482
7	A - AN3	PAPER TAPE PUNCH CONTROL 1.	322 C 2650
θ	A — AM3.	PAPER TAPE PUNCH REGISTER.	322 C 2611
9	A — A K 3	PAPER TAPE PUNCH ORIVERS.	322 C 2805
		SPARE	
		SPARE	
		SPARE	

PAPER TAPE CONTROLLER CONNECTOR AND UNIT LAYOUT