900 TECHNICAL MANUAL

VOLUME 4: ENGINEERING MAINTENANCE

Contents List

																Binder
	Introduct	ion.	•	• •	• •	• •		• •	• •	• •		• •		* * *	• •	4A
	Newslett	ers.	•	• •	• •			• •				• •	• •		• •	4A
	Amendm	ents		• •	d 4		• • *	• •	• •	• •	٥.	••	• •	• •		4A
PART 1:				BAS	SIC I	EQU:	IPME	ENT								
	Section Section Section	1 2 3 4	:	Pap	er I	ape	Stati	cessoion (1 A 21	DPA	211,	221	& 2	31)		4 4	4B
	Section Section Section	5 6 7	:	On Con	Line troll Line	Ada ler (Pro	iptor DPA ograr	for 212) n Fa r Sec	Pape cility	r Ta y (D1	pe a	nd T 13)	elep	rinte	r	. 4B . 4B
PAI	RT 2:				- 1	•		215) ES A					•••	•••		. 4B
	Section Section	1 2	:	Inte	rnal	, E>	tern	al St	ore a	and S	store	Acc	ess			
PAI	RT 3:			OPI	TION	IAL	TINU	rs								
	Section Section	1 2 3	1	NPI 4100	Int	erfa erfa	ce M	A 31; latch latch	ing ting t	Jnit ((DPA (DPA	331	to 3	34) . 4,		. 4D
10 4 1	RT 4:					•		QUII			•••		• •	• • •		•
	Section Section Section	1 2 3	:	9kc	/s M	lagn	etic '	Tape DPA	(DP	A 34						. 4E
PAI	RT 5:			900	/410	0 PI	ERIP	HER	AL E	CQUI	PME	TI				
	Section Section Section	1 2 3	:	4100	Ca	rd R	teade	ers (; er . elepr					• •	•••		•
PAI	RT 6:						MEN									
	Section	1	•	LSA	Log	gic E	Clem	ents								. 4H