Left connector panel (top to bottom):
- PL 10
- PL 2 / SKT 9
- SKT 7
- PL 6
- SKT 5 / PL 12
- PL 4 / SKT 11
- PL 3 / PL 16
- PL 15 / SKT 8
- PL 1 / SKT 17

Main layout:

33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64	B-SI POWER ON/OFF

A-JC DIPLEXING & INVERTING
A-JJ LINK BOARD
A-HX LINK BOARD
A-HT DIPLEXING & INVERTING
A-HY RECEIVERS & TRANSMITTERS
A-HS OUTPUT DATA TRANSMITTER
A-HR INPUT RECEIVER
A-HR OUTPUT RECEIVER
A - HK STORE SELECT LOGIC
A - EB3 STORE CONTROL
A - EC3 GATE STOBE MASTER DRIVERS
A - ED3 WRITE GATES READ DRIVERS DECODE
A - ED3 WRITE GATES READ DRIVERS DECODE
A - ED3 WRITE GATES READ DRIVERS DECODE
A - ED3 WRITE GATES READ DRIVERS DECODE
A - ED3 WRITE GATES READ DRIVERS DECODE

Right upper section (65–71):
- A - GZ TEMP SENSING & CONTROL
- A - EA3 INHIBIT DRIVER & SENSE AMP.
- A - EA3 INHIBIT DRIVER & SENSE AMP.
- A - EA3 INHIBIT DRIVER & SENSE AMP.
- A - EA3 INHIBIT DRIVER & SENSE AMP.
- A - EA3 INHIBIT DRIVER & SENSE AMP.
- A - EA3 INHIBIT DRIVER & SENSE AMP.

Units:
X1, X2, X3, X4, X5, X6
READ OUT
Y1, Y2, Y3
INHIBIT

Right lower section (72–77):
- A - AE SELECTION DIODES
- A - AE SELECTION DIODES
- A - AE SELECTION DIODES
- A - AE SELECTION DIODES
- A - AE SELECTION DIODES
- A - AE SELECTION DIODES

EXTRA STORE 8192 WD. 18 BIT
WITHOUT STORE ACCESS CONTROL
CONNECTOR & UNIT LAYOUT

B1