## 900 TECHNICAL MANUAL

## VOLUME 4 : ENGINEERING MAINTENANCE

## Contents List

	Introducti	000														Binder		
	Introduction Newsletters			• •			• 0					d s	• •		• •	4A		
				• •		0 0							0 0			4A		
	Amendme	nts			0 4		• •		• •	• •		6 0		• •	• •	4A		
PART 1:				BASIC EQUIPMENT														
PAI	Section	1 2 3 4 5 6 7	•	Par Tel On Con Inte Con PO	per Tepriment Line erfactoritrol: WER	Cape nter Ada ler (I Pro e Un ler (I SUF	Stati (DPA ptor DPA gran it for DPA PPLII	on (I A 21: for 212) n Fa r Sec 215) ES A	or (DDPA 1 & 2 Pape ) cility cond	211, 41) r Ta (DF Pape	pe a PA 2 PA	& 2: nd T  13) ape/:	31) elep rele	rinte	er	4B 4B 4B 4B 4B		
PART 3:				Cor	Internal, External Store and Store Access Control (DPA 1, 111, 121 & 122)													
1 111	Section Section Section	1 2 3		Mul NP: 410	ltiple L Int O Int	exer erfa	(DPA ce M ce M	A 312 atch	2, 31 ing U	Jnit ( Jnit (	DPA DPA	331	to 3	34) . 4,		. 4D		
PART 4:				PE	RIPH	IERA	L E	QUII	PME	NT								
	Section Section	1 2 3							(DP			- 2						
PART 5:									AL E									
	Section Section Section	2		410	0 Ca	rd R	eade	r .	Scien		40 4							
PART 6:			LO	GIC	ELE.	MEN	TS											
	Section	1	0	LSA	A Lo	gic E	lem	ents		• •		4 40				. 4H		