900 TECHNICAL MANUAL

VOLUME 4: ENGINEERING MAINTENANCE

Contents List

	Introduction			• •	0 0							• •					Binder 4A
Newsletters			• •											•		4A	
											• •			,		-	
		1105			0 0			0 0		• •		6 6	• •				4A
PART 1:				BASIC EQUIPMENT													
	Section Section Section Section Section Section	1 2 3 4 5	:	Paper Tape Station (DPA 211, 221 & 231) 4E Teleprinter (DPA 211 & 241) 4E On Line Adaptor for Paper Tape and Teleprinter Controller (DPA 212) 4E											4A 4B 4B		
	Section	6 7	:	Inte	On Line Program Facility (DPA 213) 4B Interface Unit for Second Paper Tape/Teleprinter Controller (DPA 215) 4B												
PART 2:				POT	WER	SUP	PLIE	SA	ND S	TOR	ES						
	Section Section	2	:	Inte Con	rnal, trol	Ext	erna	1 Sto	rea	 ind St z 122	ore	Acce	ess				
PART 3:				OPTIONAL UNITS													
	Section Section Section	1 2 3		NPI 410	Inte	erfac erfac	e Ma	atchi atchi	ng U ng U	4, 31 nit (i nit (i	DPA DPA	331	to 3	34)	• •		4D 4D
PAR	T 4:			PEI	RIPH	ERA	LEC	UIP	MEI	T							
	Section Section Section	1 2 3	•							A 341							4E 4E
PART 5:									QUI								
	Section Section Section	2		410	0 Lin	e Pr	inte:	rs (S	cien	tific)							
PART 6:				LOC	GIC E	CLE	MEN'	ГS									
,	Section	1		LSA	Log	ic E	leme	nts		• •					4 0		4H