

AIR Main Current Path:		EXT Latch Path:	
1.	EXT Relay	1.	LVC
2.	HVC Pilot	2.	HVIL (1)
3.	HV AUX Pilot	3.	HVIL (2)
4.	LVC	2.	LVC
5.	ESTOP	3.	HV AUX
6.	LVC	4.	AMS
		5.	IMD

AIR: Accumulator Isolation Relay
TSMS: Traction System Master Switch

EXT: External Latching Relay:

AMS: Accumulator Management System IMD: Insulation Monitoring Device

HV AUX: High Voltage Auxiliary connector in the Accumulator

HVC: High Voltage Connector on the Accumulator (Drive Current Path Pilot)

LVC: Low Voltage Connector on the Accumulator

INT: Internal Latching Relay:

ESTOP CC: Emergency Stop Button (Charge Cart)

HVIL: High Voltage Interlock for Chargers