



AUSTINMESH

LoRa Mesh Radio · Community Network

HARDWARE

This radio loaded with a pre-configured Meshcore firmware and powered by a Heltec T114 and 2Ah battery. The case is custom made and printed by Austin Mesh members.

QUICK CONNECT VIA BLE

1. Install the MeshCore app (iOS or Android).
2. Enable Bluetooth on your phone.
3. Open MeshCore and tap **Connect** in the upper right.
4. Select your **ATXMC-####** radio from the list.
5. Enter the BLE PIN shown on the radio screen.
6. You're connected! The app will sync automatically.

FIRST CONTACT

Test your connection to nearby repeaters by sending a message to the "Public" channel. If your message was heard and repeated you will see a "1 Repeats" under the message bubble.

GOOD TO KNOW

- Charges can last a couple days to a full week.
- Disable GPS for better battery life.