# Getting started with Buildroot - Lab

Trevor Woerner, Togán Labs March 13, 2019

These lab instructions are written for the *Getting started with Buildroot* tutorial of the *Embedded Apprentice Linux Engineer* track. They are designed to work for the *PocketBeagle* hardware platform.

This lab is broken out into two separate paths:

- Basic Lab
- In-Depth Lab

Both labs start with the same resources, and both end up creating the same artifacts, but they both take different routes. If you would like to get an image up-and-running on your board without worrying too much about the details, take a look at the **Basic Lab**. If you'd like to know a little more about what's going on "under the hood", try the **In-Depth Lab**.

Both labs start with the same **Initial Setup**.

All the work for these labs occur on the **host** computer, not the target. A reasonably recent Linux machine/VM is required for this work.

## **Initial Setup**

Our first step is to obtain the buildroot meta-data. Normally this would be done by simply cloning from buildroot's git repository. But I've created a simple fork of upstream that contains little tweaks to make this lab easier.

Therefore start by grabbing a tarball of this lab's buildroot and unpacking it. Then, move into the top-level directory of the unpacked tarball.

```
$ wget https://cm.e-ale.org/2019/SCaLE17x/buildroot/buildroot-e-ale.tar.xz
$ xz -d < buildroot-e-ale.tar.xz | tar xf -
$ cd buildroot-e-ale</pre>
```

If downloading buildroot-e-ale.tar.xz is taking too long, you can also run these exercises with the buildroot-e-ale\_SM.tar.xz tarball. But then your build will be slower.

#### **Basic Lab**

A great place to start with any project is from a **known location**. In this case our buildroot already knows what a **pocketbeagle** is, so we simply tell buildroot we want to build a basic image for this board, then go ahead and build it.

\$ make pocketbeagle\_defconfig
\$ make

The build will take a while (15 - 30 minutes, perhaps more depending on the speed of your Internet connection or on the capabilities of your host machine).

Now jump ahead all the way to the **Testing The Build** section.

## **In-Depth Lab**

What if buildroot didn't know what a **pocketbeagle** is? In this lab we're going to configure our pocketbeagle build from scratch.

#### Creating a minimal configuration

We start by configuring our build:

\$ make menuconfig

In the configuration, we'll have to customize a number of options, as detailed below. Of course, take this opportunity to navigate in all the options, and discover what Buildroot can do.

- In Target options
  - Change Target architecture to ARM (little endian)
  - Change Target architecture variant to Cortex-A8
- In Build options
  - set global patch directories to board/pocketbeagle/patches/. This will allow us to
    put patches for Linux, U-Boot other packages in subdirectories of board/pocketbeagle/
    patches/.
- In Toolchain
  - Change Toolchain type to External toolchain. By default, Buildroot builds its own toolchain, but it can also use pre-built external toolchain. We'll use the latter, in order to save build time.
- In System configuration

- you can customize the *System host name* and *System banner* if you wish. Keep the default values for the rest.

#### • In Kernel

- Enable the *Linux kernel*, obviously!
- Patches will already be applied to the kernel, thanks to us having defined a *global patch directory* above.
- Choose omap2plus as the Defconfig name
- We'll need the Device Tree of the PocketBeagle, so enable Build a Device Tree Blob (DTB)
- And use am335x-pocketbeagle as the Device Tree Source file names

#### • In Target packages

we'll keep just Busybox enabled for now. In the next sections, we'll enable more packages.

#### • In Filesystem images

- enable ext2/3/4 root filesystem
- select the ext4 variant
- you can also disable the *tar* filesystem image, which we won't need.

#### • In Bootloaders

- enable *U-Boot*, and in *U-Boot*:
  - \* Switch the *Build system* option to *Kconfig*: we are going to use a modern U-Boot, so let's take advantage of its modern build system!
  - \* Keep version 2018.01
  - \* set Custom U-Boot patches to board/pocketbeagle/patches/u-boot
  - \* Use am335x\_pocketbeagle as the Board defconfig
  - \* The *U-Boot binary format* should be changed from u-boot.bin to u-boot.img. Indeed, this second stage bootloader will be loaded by a first stage bootloader, and needs to have the proper header to be loaded by the first stage.
  - \* Enable *Install U-Boot SPL binary image* to also install the first stage bootloader. Its name in *U-Boot SPL/TPL binary image name(s)* should be changed to MLO since that's how U-Boot names it, and how the AM335x expects it to be named.

### Running the build

To start the build, you can run just make. But it's often convenient to keep the build output in a log file, so you can do:

\$ make 2>&1 | tee build.log

or alternatively use a wrapper script provided by Buildroot:

\$ ./utils/brmake

The build will take a while.

The overall build takes quite some time, because the Linux kernel configuration <code>omap2plus\_defconfig</code>, which supports all OMAP2, OMAP3, OMAP4 and AM335x platforms has a *lot* of drivers and options enabled. It would definitely be possible to make a smaller kernel configuration for the *Pocket Beagle*, reducing the kernel size and boot time.

At the end of the build, the output is located in output/images. We have:

- MLO, the first stage bootloader
- u-boot.img, the second stage bootloader
- zImage, the Linux kernel image
- am335x-pocketbeagle.dtb, the Linux kernel Device Tree Blob
- rootfs.ext4, the root filesystem image

However, that doesn't immediately give us a bootable SD card image. We could create it manually, but that wouldn't be really nice. So move on to the next section to see how Buildroot can create the SD card image for you.

## Creating a SD card image

To create a SD card image, we'll use a tool called genimage, which provided a configuration file, will output the image of a block device, with multiple partitions, each containing a filesystem. See https://git.pengutronix.de/cgit/genimage/tree/README.rst for some documentation about *genimage* and its configuration file format.

genimage needs to be called at the very end of the build. To achieve this, Buildroot provides a mechanism called *post-image scripts*, which are arbitrary scripts called at the end of the build. We will use it to create a SD card image with:

- A FAT partition containing the bootloader images, the kernel image and Device Tree
- An ext4 partition containing the root filesystem

In addition, the U-Boot bootloader for the *PocketBeagle* is configured by default to load a file called uEnv.txt to indicate what should be done at boot time. This file should also be stored in the first partition of the SD card.

So, go back to make menuconfig, and adjust the following options:

• In *System configuration* 

- Set Custom scripts to run after creating filesystem images to board/pocketbeagle/ post-image.sh
- In Host utilities
  - enable
    - \* host dosfstools
    - \* host genimage
    - \* host mtools

*mtools* and *dosfstools* are needed because our *genimage* configuration includes the creation of a FAT partition.

Restart the build again. Once the build is finished, you should now have a sdcard.img file in output/images/.

#### Storing our Buildroot configuration

Our Buildroot configuration is currently stored as .config, which is not under version control and would be removed by a make distclean. So, let's store it as a *defconfig* file:

```
$ make BR2_DEFCONFIG=configs/eale_pocketbeagle_defconfig savedefconfig
```

And then look at configs/eale\_pocketbeagle\_defconfig to see what your configuration looks like.

## **Testing The Build**

Working through either lab, if successful, you should find your \*.img file waiting for you at output/sdcard.img.

```
/home/trevor/Conference/SCaLE17x
[trevor]$ ls -lh
total 114M
                            33K Mar
                                     9 10:49 am335x-pocketbeagle.dtb
rw-r--r-- 1 trevor trevor
                                     9 10:50 boot.vfat
          1 trevor trevor
                            16M Mar
                                     9 10:43 MLO
          1 trevor trevor
                            77K Mar
                                     9 10:50 rootfs.ext2
                            60M Mar
          1 trevor trevor
                                     9 10:50 rootfs.ext4 -> rootfs.ext2
lrwxrwxrwx 1 trevor trevor
                             11 Mar
                                     9 10:50 rootfs.ta
          1
                            13M Mar
            trevor trevor
                                     9 10:50 sdcard.img
          1 trevor trevor
                            77M Mar
      -r-- 1 trevor trevor 367K Mar
                                     9 10:43 u-boot.img
                                     9 10:43 u-boot-spl.bin
     xr-x 1 trevor trevor
                            76K Mar
                            218 Mar
                                     9 10:50 uEnv.txt
      -r-- 1 trevor trevor
rw-r--r-- 1 trevor trevor 5.5M Mar
                                     9 10:49 zImage
trevor]$
```

Using **Etcher** or **dd**, flash this image to your SDcard. Insert the SDcard into your PocketBeagle and apply power. Ideally you'll have a serial console setup (i.e. **minicom** or **screen**) so you can watch the progress.

```
/home/trevor
                                                                           File Edit View Search Terminal Help
     1.668836] mmcO: new high speed SDHC card at address 0007
     1.677395] mmcblk0: mmc0:0007 SD16G 14.6 GiB
     1.688578] mmcblk0: p1 p2
     1.706150] tps65217 0-0024: TPS65217 ID 0xe version 1.2
     1.712616] omap_i2c 44e0b000.i2c: bus 0 rev0.11 at 400 kHz
     1.747003] omap_i2c 4819c000.i2c: bus 2 rev0.11 at 400 kHz
     1.754286] hctosys: unable to open rtc device (rtc0)
     1.759744] sr_init: No PMIC hook to init smartreflex
     1.765276] sr_init: platform driver register failed for SR
     1.941988] EXT4-fs (mmcblk0p2): recovery complete
     1.957898] EXT4-fs (mmcblk0p2): mounted filesystem with ordered data mode. )
     1.966682] VFS: Mounted root (ext4 filesystem) on device 179:2.
     1.975783] devtmpfs: mounted
     1.981117] Freeing unused kernel memory: 1024K
     2.097564] EXT4-fs (mmcblk0p2): re-mounted. Opts: data=ordered
Starting logging: OK
Initializing random number generator... done.
Starting network: OK
Welcome to Buildroot
buildroot login: root
# uname -a
Linux buildroot 4.14.18 #1 SMP Sat Mar 9 10:47:28 PST 2019 armv7l GNU/Linux
```