# CHAPTER 3 SIGHTS





CH-SC-SU	Schem Page	Sheet Date		CH-SC-SU	Schem	Page	Sheet	Date	
33-EFFECTIVE F	PAGES			33-11-31					
	1 thru 5 6	Jun 21/2016 BLANK	R	33-11-32		101		Jun 21/2016	
33-CONTENTS			R			101		Jun 21/2016	
R	1	Jun 21/2016		33-11-33					
R	2	Jun 21/2016	R			101		Jun 21/2016	
R	3	Jun 21/2016		33-11-41		101		0di1 2 1/20 10	
R	4	Jun 21/2016		00 11 11		101		May 15/2015	
R	5	Jun 21/2016	R			102		Jun 21/2016	
R	6	Jun 21/2016	11	33-12-11		102		Juli 2 1/20 10	
R	7	Jun 21/2016	R	00-12-11		101		lum 01/0016	
R	8	Jun 21/2016	11	33-12-12		101		Jun 21/2016	
33-ALPHABETIC	CAL INDEX		R	33-12-12		101		L 04 (004 C	
R	1	Jun 21/2016		33-14-11		101		Jun 21/2016	
	2	Aug 31/2015		33-14-11		101		1 04/0040	
	3	Aug 31/2015	R	00 14 10		101		Jun 21/2016	
	4	BLANK		33-14-12					
33-00-01			R	00 47 44		101		Jun 21/2016	
R	101	Jun 21/2016		33-17-11					
33-11-11			R			101		Jun 21/2016	
	101	Mar 14/2016		33-18-11					
R	102	Jun 21/2016	R			101		Jun 21/2016	
33-11-21				33-18-21					
	101	Mar 14/2016				101		Mar 14/2016	
R	102	Jun 21/2016	R			102		Jun 21/2016	

A = Added, R = Revised, D = Deleted, O = Overflow

### **33-EFFECTIVE PAGES**





	CH-SC-SU	Schem Page	e Sheet Date		CH-SC-SU	Schem	Page	Sheet	Date	
	33-18-22				33-18-41					
		101	Mar 14/2016	R			101		Jun 21/2016	
R		102	Jun 21/2016	R			102		Jun 21/2016	
	33-18-23				33-18-42					
R		101	Jun 21/2016	R			101		Jun 21/2016	
	33-18-24				33-18-51					
R		101	Jun 21/2016	R			101		Jun 21/2016	
	33-18-31				33-18-61					
R		101	Jun 21/2016				101		May 15/2015	
	33-18-32			R			102		Jun 21/2016	
R		101	Jun 21/2016		33-18-62					
	33-18-33						101		Mar 14/2016	
R	00 10 04	101	Jun 21/2016	R	00 10 00		102		Jun 21/2016	
R	33-18-34	101	L 04 /0040		33-18-63		101		NA 45/0045	
ח	33-18-35	101	Jun 21/2016	R			101 102		May 15/2015 Jun 21/2016	
R	33-10-33	101	Jun 21/2016	n	33-18-64		102		Juli 21/2016	
' '	33-18-36	101	Juli 21/2010	R	00-10-04		101		Jun 21/2016	
R	30 10 00	101	Jun 21/2016		33-21-11		101		Juli 2 1/2010	
	33-18-37	101	0dii 2 ii 20 i 0	R	··		101		Jun 21/2016	
		101	Aug 18/2014		33-21-12				0.0	
		102	Mar 14/2016				101	1	Mar 14/2016	
R		103	Jun 21/2016					2	Mar 14/2016	
								3	Mar 14/2016	

A = Added, R = Revised, D = Deleted, O = Overflow

### **33-EFFECTIVE PAGES**





	CH-SC-SU	Schem	Page	Sheet	Date		CH-SC-SU	Schem	Page	Sheet	Date
	33-21-12 (co	nt.)	101				33-23-21				
				4	Mar 14/2016	R			101		Jun 21/2016
R			102	1	Jun 21/2016		33-23-22				
R				2	Jun 21/2016	R			101		Jun 21/2016
R				3	Jun 21/2016		33-23-31				
R				4	Jun 21/2016	R			101		Jun 21/2016
	33-22-11						33-24-11				
R			101		Jun 21/2016	R			101		Jun 21/2016
	33-22-12						33-24-12				
R			101	1	Jun 21/2016	R			101	1	Jun 21/2016
R				2	Jun 21/2016	R				2	Jun 21/2016
	33-22-13						33-25-11				
R			101	1	Jun 21/2016	R			101		Jun 21/2016
R				2	Jun 21/2016				102		Feb 17/2015
	33-22-14						33-25-12				
R			101	1	Jun 21/2016				101		Mar 14/2016
R				2	Jun 21/2016	R			102		Jun 21/2016
	33-22-15					R			103		Jun 21/2016
R			101	1	Jun 21/2016	Α			104		Jun 21/2016
R				2	Jun 21/2016		33-25-21				
	33-23-11					R			101		Jun 21/2016
R			101		Jun 21/2016		33-25-22				
	33-23-12					R			101		Jun 21/2016
R			101		Jun 21/2016						

A = Added, R = Revised, D = Deleted, O = Overflow

33-EFFECTIVE PAGES

737-800 SYSTEM SCHEMATIC MANUAL

D280A451

Page 3 Jun 21/2016





	CH-SC-SU	Schem Page	Shee	t Date		CH-SC-SU	Schem	Page	Sheet	Date	
	33-25-31					33-27-32					
R		101		Jun 21/2016	R			101		Jun 21/2016	
	33-25-32					33-27-41					
R		101		Jun 21/2016	R			101		Jun 21/2016	
	33-25-41					33-29-11					
R		101		Jun 21/2016	Α			101		Jun 21/2016	
	33-26-11				Α			102		Jun 21/2016	
R		101		Jun 21/2016		33-32-11					
	33-26-21							101		Jan 12/2015	
R		101		Jun 21/2016	R			102		Jun 21/2016	
	33-26-31					33-33-11					
0		101		Mar 14/2016				101		Jan 12/2015	
Α		102	1	Jun 21/2016	R			102		Jun 21/2016	
Α			2	Jun 21/2016		33-34-11					
	33-27-11							101		Jan 12/2015	
0		101		Mar 14/2016	R			102		Jun 21/2016	
Α		102		Jun 21/2016		33-35-11					
	33-27-21							101		Jan 12/2015	
R		101		Jun 21/2016	R			102		Jun 21/2016	
	33-27-22					33-36-11					
R		101		Jun 21/2016				101		Jan 12/2015	
	33-27-31				R			102		Jun 21/2016	
R		101		Jun 21/2016		33-36-12					
								101		Jan 12/2015	

A = Added, R = Revised, D = Deleted, O = Overflow

### **33-EFFECTIVE PAGES**



### CHAPTER 33 LIGHTS

	CH-SC-SU	Schem	Page	Sheet	Date		CH-SC-SU	Schem	Page	Sheet	Date
	33-36-12 (co	nt.)					33-51-11 (cc	ont.)	101		
R			102		Jun 21/2016	R				2	Jun 21/2016
	33-41-11						33-51-12				
R			101		Jun 21/2016	R			101		Jun 21/2016
	33-42-11						33-51-13				
			101		May 15/2015	R			101		Jun 21/2016
	33-42-21						33-51-14				
R			101	1	Jun 21/2016	R			101		Jun 21/2016
R				2	Jun 21/2016		33-51-21				
	33-43-11					R			101		Jun 21/2016
			101		Aug 15/2013						
R			102		Jun 21/2016						
	33-44-11										
R			101		Jun 21/2016						
	33-44-12										
_			101		Aug 15/2013						
R	00.45.44		102		Jun 21/2016						
	33-45-11										
			101		Apr 17/2014						
	00 40 44		102		May 15/2015						
	33-49-11		404		1 04/0040						
R	00 51 11		101		Jun 21/2016						
	33-51-11		404	_	1 04/0040						
R			101	1	Jun 21/2016						

A = Added, R = Revised, D = Deleted, O = Overflow

**33-EFFECTIVE PAGES** 





	Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
	<u>LIGHTS</u>						
ı	SPARE BULB STOWAGE	33-00-01		101		Jun 21/2016	ALL
	INSTRUMENT AND PANEL LIGHTS						
	CAPTAIN'S INSTRUMENT PANEL LIGHTING	33-11-11		101		Mar 14/2016	YT101-YT120
I				102		Jun 21/2016	YT126-YT133
	FIRST OFFICER'S INSTRUMENT PANEL LIGHTING	33-11-21		101		Mar 14/2016	YT101-YT120
I				102		Jun 21/2016	YT126-YT133
I	CAPTAIN'S & FIRST OFFICER'S CENTER INSTRUMENT PANEL	33-11-31		101		Jun 21/2016	ALL
I	STANDBY INSTRUMENT AND PANEL LIGHTS - CAPT, F/O, CENTER PANELS	33-11-32		101		Jun 21/2016	ALL
I	STANDBY INSTRUMENT AND PANEL LIGHTS - CONTROL STAND	33-11-33		101		Jun 21/2016	ALL
	PILOTS CONTROL STAND LIGHTING	33-11-41		101		May 15/2015	YT101-YT112 YT126-YT130
I				102		Jun 21/2016	YT113-YT120 YT131-YT133
	OVERHEAD INSTRUMENT PANEL						
ı	OVERHEAD INSTRUMENT PANEL LIGHTS PART ONE	33-12-11		101		Jun 21/2016	ALL
I	OVERHEAD INSTRUMENT PANEL LIGHTS PART TWO	33-12-12		101		Jun 21/2016	ALL
	FLIGHT COMPARTMENT LIGHTS						
I	PILOT'S BACKGROUND LIGHTS	33-14-11		101		Jun 21/2016	ALL
I	DOME LTG, CONTROL STAND FLOOD LTG, STBY COMPASS LTG, & C/B PNL LTG	33-14-12		101		Jun 21/2016	ALL
	FLIGHT CREW LIGHTS						
I	MAP, FLIGHT KIT AND READING LIGHTS	33-17-11		101		Jun 21/2016	ALL

**33-CONTENTS** 

D280A451

Page 1 Jun 21/2016





	Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
	MASTER DIM AND TEST SYSTEM						
I	MASTER DIM & TEST SYSTEM- POWER & CONTROL	33-18-11		101		Jun 21/2016	ALL
	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, CAPT	33-18-21		101		Mar 14/2016	YT101-YT120
ı				102		Jun 21/2016	YT126-YT133
	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, F/O	33-18-22		101		Mar 14/2016	YT101-YT120
I				102		Jun 21/2016	YT126-YT133
I	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, CTR LEFT	33-18-23		101		Jun 21/2016	ALL
I	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, CTR RIGHT	33-18-24		101		Jun 21/2016	ALL
I	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 1	33-18-31		101		Jun 21/2016	ALL
I	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 2	33-18-32		101		Jun 21/2016	ALL
I	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 3	33-18-33		101		Jun 21/2016	ALL
ı	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 4	33-18-34		101		Jun 21/2016	ALL
I	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 5	33-18-35		101		Jun 21/2016	ALL
I	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 6	33-18-36		101		Jun 21/2016	ALL
	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 7	33-18-37		101		Aug 18/2014	YT101-YT105
				102		Mar 14/2016	YT106-YT120

**33-CONTENTS** 

D280A451

Page 2 Jun 21/2016





	Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
ı	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 7 (cont.)	33-18-37		103		Jun 21/2016	YT126-YT133
I	MASTER DIM & TEST SYSTEM- AFT OVERHEAD PANEL, GROUP 1	33-18-41		101		Jun 21/2016	YT101-YT119 YT126-YT129
ı				102		Jun 21/2016	YT120 YT130-YT133
I	MASTER DIM & TEST SYSTEM- AFT OVERHEAD PANEL, GROUP 2	33-18-42		101		Jun 21/2016	ALL
I	MASTER DIM & TEST SYSTEM- GLARESHIELD PANEL	33-18-51		101		Jun 21/2016	ALL
	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 1	33-18-61		101		May 15/2015	YT101-YT112 YT126-YT130
ı				102		Jun 21/2016	YT113-YT120 YT131-YT133
	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 2	33-18-62		101		Mar 14/2016	YT101-YT120
I				102		Jun 21/2016	YT126-YT133
	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 3	33-18-63		101		May 15/2015	YT101-YT112 YT126-YT130
I				102		Jun 21/2016	YT113-YT120 YT131-YT133
I	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 4	33-18-64		101		Jun 21/2016	ALL
	WINDOW LIGHTS						
ı	WINDOW LIGHTS CONTROL	33-21-11		101		Jun 21/2016	ALL
	WINDOW LIGHTS	33-21-12		101	1	Mar 14/2016	YT101-YT120
					2	Mar 14/2016	YT101-YT120
					3	Mar 14/2016	YT101-YT120
					4	Mar 14/2016	YT101-YT120

**33-CONTENTS** 

D280A451

Page 3 Jun 21/2016





	Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
I	WINDOW LIGHTS (cont.)	33-21-12		102	1	Jun 21/2016	YT126-YT133
I					2	Jun 21/2016	YT126-YT133
I					3	Jun 21/2016	YT126-YT133
I					4	Jun 21/2016	YT126-YT133
	CEILING LIGHTS						
I	CEILING LIGHTS CONTROL	33-22-11		101		Jun 21/2016	ALL
I	CEILING LIGHTS	33-22-12		101	1	Jun 21/2016	ALL
I					2	Jun 21/2016	ALL
I	CEILING LIGHTS RIGHT	33-22-13		101	1	Jun 21/2016	ALL
I					2	Jun 21/2016	ALL
I	CEILING WASH LIGHTS - LEFT	33-22-14		101	1	Jun 21/2016	ALL
I					2	Jun 21/2016	ALL
I	CEILING WASH LIGHTS - RIGHT	33-22-15		101	1	Jun 21/2016	ALL
I					2	Jun 21/2016	ALL
	READING LIGHTS						
I	PASS READING LTS - LEFT FWD	33-23-11		101		Jun 21/2016	ALL
I	PASS READING LTS - LEFT AFT	33-23-12		101		Jun 21/2016	ALL
I	PASS READING LTS - RIGHT FWD	33-23-21		101		Jun 21/2016	ALL
I	PASS READING LTS - RIGHT AFT	33-23-22		101		Jun 21/2016	ALL
I	READING LTS - PASS SERVICE UNIT	33-23-31		101		Jun 21/2016	ALL
	COVE LIGHTS						
I	COVE LIGHTS CONTROL	33-24-11		101		Jun 21/2016	ALL
I	COVE LIGHTS	33-24-12		101	1	Jun 21/2016	ALL

**33-CONTENTS** 

D280A451

Page 4 Jun 21/2016





	Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
I	COVE LIGHTS (cont.)	33-24-12			2	Jun 21/2016	ALL
	PASSENGER SIGNS						
ı	PASS SIGN - CONTROL	33-25-11		101		Jun 21/2016	YT101-YT120 YT130-YT133
				102		Feb 17/2015	YT126-YT129
	PASS SIGNS - MISC	33-25-12		101		Mar 14/2016	YT101-YT118
I				102		Jun 21/2016	YT119-YT120
I				103		Jun 21/2016	YT126-YT127
I				104		Jun 21/2016	YT128-YT131
I	PASS SIGNS - PSU LEFT FWD	33-25-21		101		Jun 21/2016	ALL
ı	PASS SIGNS - PSU LEFT AFT	33-25-22		101		Jun 21/2016	ALL
ı	PASS SIGNS - PSU RIGHT FWD	33-25-31		101		Jun 21/2016	ALL
ı	PASS SIGNS - PSU RIGHT AFT	33-25-32		101		Jun 21/2016	ALL
I	NO SMOKING/FASTEN SEAT BELT SIGNS - PASS SERVICE UNIT	33-25-41		101		Jun 21/2016	ALL
	WORK LIGHTS						
I	ATTENDANT WORK LIGHTS	33-26-11		101		Jun 21/2016	ALL
I	GALLEY LIGHTS	33-26-21		101		Jun 21/2016	ALL
	LAVATORY LIGHTS AND SIGNS	33-26-31		101		Mar 14/2016	YT101-YT118 YT126-YT131
I				102	1	Jun 21/2016	YT119-YT120 YT132-YT133
I					2	Jun 21/2016	YT119-YT120 YT132-YT133
	PASSENGER AND LAVATORY CALL LIGHTS						
	PASSENGER AND LAVATORY CALL CONTROL	33-27-11		101		Mar 14/2016	YT101-YT118 YT126-YT131
I				102		Jun 21/2016	YT119-YT120 YT132-YT133

**33-CONTENTS** 

D280A451

Page 5 Jun 21/2016





	Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
ı	PASSENGER AND LAVATORY CALL - LEFT FWD	33-27-21		101		Jun 21/2016	ALL
ı	PASSENGER AND LAVATORY CALL - LEFT AFT	33-27-22		101		Jun 21/2016	ALL
ı	PASSENGER AND LAVATORY CALL - RIGHT FWD	33-27-31		101		Jun 21/2016	ALL
ı	PASSENGER AND LAVATORY CALL - RIGHT AFT	33-27-32		101		Jun 21/2016	ALL
ı	PASSENGER AND LAVATORY CALL - PSU	33-27-41		101		Jun 21/2016	ALL
	ENTRY LIGHTS						
ı	ENTRY LIGHTS	33-29-11		101		Jun 21/2016	YT101-YT118 YT126-YT131
ı				102		Jun 21/2016	YT119-YT120 YT132-YT133
	WHEEL WELL LIGHTS						
	SERVICE LIGHTING - WHEEL WELLS	33-32-11		101		Jan 12/2015	YT101-YT111 YT126-YT130
I				102		Jun 21/2016	YT112-YT120 YT131-YT133
	AIR CONDITIONING COMPARTMENT LIGHTS						
	SERVICE LIGHTING - AIR CONDITIONING COMPARTMENT	33-33-11		101		Jan 12/2015	YT101-YT111 YT126-YT130
I				102		Jun 21/2016	YT112-YT120 YT131-YT133
	ELECTRONIC EQUIPMENT COMPARTMENT LIGHTS						
	SERVICE LIGHTING - EQUIPMENT RACK FORWARD LOWER COMPARTMENT	33-34-11		101		Jan 12/2015	YT101-YT111 YT126-YT130
I				102		Jun 21/2016	YT112-YT120 YT131-YT133
	ACCESSORY COMPARTMENT LIGHTS						
	SERVICE LIGHTING - ACCESSORY COMPARTMENT	33-35-11		101		Jan 12/2015	YT101-YT111 YT126-YT130
ı				102		Jun 21/2016	YT112-YT120 YT131-YT133

**33-CONTENTS** 

D280A451

Page 6 Jun 21/2016





	Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
	CARGO COMPARTMENT LIGHTS						
	SERVICE LIGHTING - CARGO COMPARTMENT - FWD	33-36-11		101		Jan 12/2015	YT101-YT111 YT126-YT130
I				102		Jun 21/2016	YT112-YT120 YT131-YT133
	SERVICE LIGHTING - CARGO COMPARTMENT - AFT	33-36-12		101		Jan 12/2015	YT101-YT111 YT126-YT130
I				102		Jun 21/2016	YT112-YT120 YT131-YT133
	WING ILLUMINATION LIGHTS						
I	EXTERIOR LIGHTS - WING SCANNING	33-41-11		101		Jun 21/2016	ALL
	LANDING LIGHTS						
	EXTERIOR LIGHTS - LANDING	33-42-11		101		May 15/2015	YT101-YT112 YT126-YT130
	LANDING TAXI AND RUNWAY TURNOFF LIGHTING SYSTEMS	33-42-21		101	1	Jun 21/2016	YT113-YT120 YT131-YT133
ı					2	Jun 21/2016	YT113-YT120 YT131-YT133
	POSITION LIGHTS						
	EXTERIOR LIGHTS - POSITION	33-43-11		101		Aug 15/2013	YT101
ı				102		Jun 21/2016	YT102-YT133
	ANTI-COLLISION LIGHTS						
ı	EXTERIOR LIGHTS - ANTICOLLISION - RED	33-44-11		101		Jun 21/2016	ALL
	EXTERIOR LIGHTS - ANTICOLLISION - WHITE	33-44-12		101		Aug 15/2013	YT101
ı				102		Jun 21/2016	YT102-YT133
	TAXI AND RUNWAY TURNOFF LIGHTS						
	EXTERIOR LIGHTS - TAXI AND RUNWAY TURNOFF	33-45-11		101		Apr 17/2014	YT101-YT105
				102		May 15/2015	YT106-YT112 YT126-YT130

**33-CONTENTS** 

D280A451

Page 7 Jun 21/2016





## CHAPTER 33

		LIGHIS				
Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
LOGO LIGHTS						
EXTERIOR LIGHTS - STABILIZER (LOGO) FLOOD LIGHTS	33-49-11		101		Jun 21/2016	ALL
EMERGENCY LIGHTS						
EMERGENCY EXIT LIGHTS - CONTROL	33-51-11		101	1	Jun 21/2016	ALL
				2	Jun 21/2016	ALL
EMERGENCY EXIT LIGHTS - FORWARD	33-51-12		101		Jun 21/2016	ALL
EMERGENCY EXIT LIGHTS - MID	33-51-13		101		Jun 21/2016	ALL
EMERGENCY EXIT LIGHTS - AFT	33-51-14		101		Jun 21/2016	ALL
EMERGENCY EXIT LIGHTS - FLOOR PROXIMITY	33-51-21		101		Jun 21/2016	ALL



### CHAPTER 33 LIGHTS

CH-SC-SU	Title
33-26-11	ATTENDANT WORK LIGHTS
33-11-31	CAPTAIN'S & FIRST OFFICER'S CENTER INSTRUMENT PANEL
33-11-11	CAPTAIN'S INSTRUMENT PANEL LIGHTING
33-22-12	CEILING LIGHTS
33-22-11	CEILING LIGHTS CONTROL
33-22-13	CEILING LIGHTS RIGHT
33-22-14	CEILING WASH LIGHTS - LEFT
33-22-15	CEILING WASH LIGHTS - RIGHT
33-24-12	COVE LIGHTS
33-24-11	COVE LIGHTS CONTROL
33-14-12	DOME LTG, CONTROL STAND FLOOD LTG, STBY COMPASS LTG, & C/B PNL LTG
33-51-14	EMERGENCY EXIT LIGHTS - AFT
33-51-11	EMERGENCY EXIT LIGHTS - CONTROL
33-51-21	EMERGENCY EXIT LIGHTS - FLOOR PROXIMITY
33-51-12	EMERGENCY EXIT LIGHTS - FORWARD
33-51-13	EMERGENCY EXIT LIGHTS - MID
33-29-11	ENTRY LIGHTS
33-44-11	EXTERIOR LIGHTS - ANTICOLLISION - RED

CH-SC-SU	Title
33-44-12	EXTERIOR LIGHTS - ANTICOLLISION - WHITE
33-42-11	EXTERIOR LIGHTS - LANDING
33-43-11	EXTERIOR LIGHTS - POSITION
33-49-11	EXTERIOR LIGHTS - STABILIZER (LOGO) FLOOD LIGHTS
33-45-11	EXTERIOR LIGHTS - TAXI AND RUNWAY TURNOFF
33-41-11	EXTERIOR LIGHTS - WING SCANNING
33-11-21	FIRST OFFICER'S INSTRUMENT PANEL LIGHTING
33-26-21	GALLEY LIGHTS
33-42-21	LANDING TAXI AND RUNWAY TURNOFF LIGHTING SYSTEMS
33-26-31	LAVATORY LIGHTS AND SIGNS
33-17-11	MAP, FLIGHT KIT AND READING LIGHTS
33-18-41	MASTER DIM & TEST SYSTEM- AFT OVERHEAD PANEL, GROUP 1
33-18-42	MASTER DIM & TEST SYSTEM- AFT OVERHEAD PANEL, GROUP 2
33-18-61	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 1
33-18-62	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 2
33-18-63	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 3

### **33-ALPHABETICAL INDEX**





CH-SC-SU	Title
33-18-64	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 4
33-18-31	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 1
33-18-32	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 2
33-18-33	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 3
33-18-34	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 4
33-18-35	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 5
33-18-36	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 6
33-18-37	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 7
33-18-51	MASTER DIM & TEST SYSTEM- GLARESHIELD PANEL
33-18-21	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, CAPT
33-18-23	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, CTR LEFT
33-18-24	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, CTR RIGHT
33-18-22	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, F/O

CH-SC-SU	Title
33-18-11	MASTER DIM & TEST SYSTEM- POWER & CONTROL
33-25-41	NO SMOKING/FASTEN SEAT BELT SIGNS - PASS SERVICE UNIT
33-12-11	OVERHEAD INSTRUMENT PANEL LIGHTS PART ONE
33-12-12	OVERHEAD INSTRUMENT PANEL LIGHTS PART TWO
33-23-12	PASS READING LTS - LEFT AFT
33-23-11	PASS READING LTS - LEFT FWD
33-23-22	PASS READING LTS - RIGHT AFT
33-23-21	PASS READING LTS - RIGHT FWD
33-25-11	PASS SIGN - CONTROL
33-25-12	PASS SIGNS - MISC
33-25-22	PASS SIGNS - PSU LEFT AFT
33-25-21	PASS SIGNS - PSU LEFT FWD
33-25-32	PASS SIGNS - PSU RIGHT AFT
33-25-31	PASS SIGNS - PSU RIGHT FWD
33-27-22	PASSENGER AND LAVATORY CALL - LEFT AFT
33-27-21	PASSENGER AND LAVATORY CALL - LEFT FWD
33-27-41	PASSENGER AND LAVATORY CALL - PSU
33-27-32	PASSENGER AND LAVATORY CALL - RIGHT AFT
33-27-31	PASSENGER AND LAVATORY CALL - RIGHT FWD

### **33-ALPHABETICAL INDEX**



### CHAPTER 33 LIGHTS

CH-SC-SU	Title
33-27-11	PASSENGER AND LAVATORY CALL CONTROL
33-14-11	PILOT'S BACKGROUND LIGHTS
33-11-41	PILOTS CONTROL STAND LIGHTING
33-23-31	READING LTS - PASS SERVICE UNIT
33-35-11	SERVICE LIGHTING - ACCESSORY COMPARTMENT
33-33-11	SERVICE LIGHTING - AIR CONDITIONING COMPARTMENT
33-36-12	SERVICE LIGHTING - CARGO COMPARTMENT - AFT
33-36-11	SERVICE LIGHTING - CARGO COMPARTMENT - FWD
33-34-11	SERVICE LIGHTING - EQUIPMENT RACK FORWARD LOWER COMPARTMENT
33-32-11	SERVICE LIGHTING - WHEEL WELLS
33-00-01	SPARE BULB STOWAGE
33-11-32	STANDBY INSTRUMENT AND PANEL LIGHTS - CAPT, F/O, CENTER PANELS
33-11-33	STANDBY INSTRUMENT AND PANEL LIGHTS - CONTROL STAND
33-21-12	WINDOW LIGHTS
33-21-11	WINDOW LIGHTS CONTROL

CH-SC-SU	Title	

### **33-ALPHABETICAL INDEX**

# BOEING

### 737-800 SYSTEM SCHEMATIC MANUAL

LAMP NO.	USAGE	SPARE QTY
303	P6 FLOOD LT (OVHD)	1
3051F	THRESHOLD LT	1
327	STANDBY COMPASS LIGHTED PUSH BUTTON SW LAVATORY CALL LT	1
387AS15	ANNUNCIATOR LT LIGHTED PUSH BUTTON SW ASP MIC SELECT SW FIRE HANDLE LT NS/FSB SIGN	6
737AS15	MASTER CAUTION DISPLAY	1
767 ***	EXTERIOR EMERGENCY LT	1
1251	LAVATORY LT	1
1308	MAP LT ATTENDANT WORK LT	1
1317	PASS CABIN EMERGENCY LT CONT CABIN EMERGENCY LT	1
1665	CONT CABIN DOME LT WHEEL WELL LT AIR CONDITIONING COMPARTMENT LT ASSESSORY COMPARTMENT LT E/E BAY RACK LT CARGO COMPARTMENT LT	2
1691	P6 FLOOD LT (FLOOR)	1


THIS CHART DOES NOT SHOW ALL BULBS USED ON AIRCRAFT.

1864

\*\*\* SPECIAL HANDLING REQUIRED:- LEAVE SHIPPING SLEEVE ON UNTIL INSTALLED IN ASSEMBLY. FINGERPRINTS WILL SHORTEN LAMP LIFE.

MASTER CAUTION ANNUNCIATOR FIRE WARNING ANNUNCIATOR FLIGHT KIT LT P6/P18 PAWEL FLOOD LT PASS CABIN NIGHT LT CABIN ENTRY LT (DIM) RETURN TO SEAT SIGN (LAV)

LAMP NO.	USAGE	SPARE QTY
3011	WHEEL WELL LT	1
0L-3071BPE GPL	FLOOR PROXIMITY LT EMERGENCY EXIT SIGN	4
7387	PASS CABIN ATTENDANT CALL LT	1
9204 ***	FLIGHT CREW CHART LT PASSENGER READING LT	4
H342AA55	STANDBY ATTITUDE IND LT	1
HLX64621 ***	WING SCANNING LT POSITION LT LOGO LT	1




ALL SPARE BULB STOWAGE

D280A451


33-00-01

Page 101











BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.





BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.






# BOEING


13

### 737-800 SYSTEM SCHEMATIC MANUAL





31-62-11




**CAPTAIN'S & FIRST** ALL **OFFICER'S CENTER INSTRUMENT PANEL** D280A451

33-11-31

Page 101

# BOEING

### 737-800 SYSTEM SCHEMATIC MANUAL



STANDBY INSTRUMENT AND
PANEL LIGHTS - CAPT, F/O,
CENTER PANELS

D280A451


WIRING DIAGRAMS
33-11-32

33-11-32


Page 101

68

### 737-800 SYSTEM SCHEMATIC MANUAL







NOTES:

1 LIGHTING REQUIRES THAT CIRCUIT BREAKER, C120, IS CLOSED AND PROCESSOR, M2771, IS INSTALLED


YT101-YT112, YT126-YT130	PILOTS CONTROL STAND LIGHTING
	D280A451


WIRING DIAGRAMS
33-11-41

33-11-41

Page 101

May 15/2015





### NOTES:

1 LIGHTING REQUIRES THAT CIRCUIT BREAKER, C120, IS CLOSED AND PROCESSOR, M2771, IS INSTALLED

YT113-YT120, YT131-YT133	PILOTS CONTROL STAND LIGHTING
	D280A451




### 33-11-41


Page 102



22

### 737-800 SYSTEM SCHEMATIC MANUAL





33-12-11


Page 101




-B┌

### 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS
33-12-12






### 33-12-12


Page 101

### BOEING 737-800 SYSTEM SCHEMATIC MANUAL -P WIRING DIAGRAMS 115V AC STBY BUS 33-14-11 STANDBY D1036 C1425 PANEL FLOOD STANDBY (P6-3 A12) SECT 2 24-54-11 D11930 — 11 D1036 115V AC 115V AC XFR BUS 2 SECT 2 24-51-21 DIM CURVE **■** D11938 C751 PANEL FLOOD CONTROL (P6-3 A11) D11930 D11936 CASE GND L1099 CAPT MAIN PANEL FLOODLIGHT CIRCUIT BREAKER PANEL 5V AC LOW D11928 D11926 (R3) STANDBY RESISTOR CCW D11932 L50 CTR MAIN PANEL FLOODLIGHT WIPER AC BRIDGE FILTER OUTPUT { 23 · 24 -NC · (R4) STANDBY RESISTOR - 12 13 HIGH **■** D11922 (R2) MAIN PANEL BRIGHT/DIM CONTROL M1916 MAIN PANEL FLOODLIGHT DIMMER CONTROL UNIT (P9) D11924 5V L1013 GLARESHIELD FLOODLIGHT CONTROL CIRCUIT NORMAL (K1) STANDBY CCW D12592 — 11 115V AC WIPER DIM CURVE OUTPUT RETURNS HIGH (R1) GLARESHIELD BRIGHT/DIM CONTROL NC -DIM - 20 -L 23 · ⊢ 7 CASE GND CASE GND P1-5 PANEL/FLOOD LIGHTING CONTROL MODULE LOW L1100 F/0 MAIN PANEL FL00DLIGHT WIPER M1917 GLARESHIELD DIMMER CONTROL UNIT (P9) OUTPUT RETURN HIGH 33-11-33 28V AC M2186 MAIN PANEL FLOODLIGHT DIMMER CONTROL UNIT (P9) STANDBY BUS SECT 2 24-53-11 C701 EMERGENCY PANEL LIGHTING (P6-3 D8) D12108 D12106 VOLTAGE REGULATOR 33-11-33 T362 28-5V AC TRANSFORMER (J19) L1103 CAPT OXYGEN MASK STOWAGE FLOODLIGHT (STA224 WL223 LBL40) CIRCUIT BREAKER PANEL D12112 D12110 VOLTAGE REGULATOR L1104 F/O OXYGEN MASK STOWAGE FLOODLIGHT (STA224 WL223 RBL40) PILOT'S BACKGROUND LIGHTS 33-14-11 Page 101 Jun 21/2016


D280A451

BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.









WIRING DIAGRAMS 33-18-11


MASTER DIM & TEST SYSTEM-POWER & CONTROL

D280A451


### 33-18-11

Page 101















BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.





YT126-YT133	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, F/O
	D280A451

WIRING DIAGRAMS
33-18-22


33-18-22

Page 102



LOAD CONTROL CENTER

## 737-800 SYSTEM SCHEMATIC MANUAL



WIRING DIAGRAMS
33-18-23

ALL	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, CTR LEFT
	D280A451

33-18-23

Page 101






ALL	MASTER DIM & TEST SYSTEM- MAIN INSTRUMENT PANEL, CTR RIGHT
	D280A451

WIRING DIAGRAMS
33-18-24

33-18-24

Page 101





MASTER DIM & TEST SYSTEM-FWD OVERHEAD PANEL,
GROUP 1


D280A451

WIRING DIAGRAMS 33-18-31

33-18-31

Page 101






WIRING DIAGRAMS 33-18-32

ALL	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 2
	D280A451


33-18-32

Page 101










# () BOEING

### 737-800 SYSTEM SCHEMATIC MANUAL



WIRING DIAGRAMS
33-18-35

MASTER DIM & TEST SYSTEM-FWD OVERHEAD PANEL,
GROUP 5


D280A451

33-18-35

Page 101

## ( BOEING

### 737-800 SYSTEM SCHEMATIC MANUAL



MASTER DIM & TEST SYSTEM-FWD OVERHEAD PANEL,
GROUP 6

D280A451

WIRING DIAGRAMS 33-18-36


33-18-36

Page 101



P6 LOAD CONTROL CENTER

### 737-800 SYSTEM SCHEMATIC MANUAL



YT101-YT105

MASTER DIM & TEST SYSTEM-FWD OVERHEAD PANEL,
GROUP 7

D280A451

WIRING DIAGRAMS 33-18-37

33-18-37


Page 101

Aug 18/2014



P6 LOAD CONTROL CENTER

### 737-800 SYSTEM SCHEMATIC MANUAL



YT106-YT120	MASTER DIM & TEST SYSTEM- FWD OVERHEAD PANEL, GROUP 7
	D280A451

WIRING DIAGRAMS
33-18-37

33-18-37


Page 102

Mar 14/2016



P6 LOAD CONTROL CENTER

### 737-800 SYSTEM SCHEMATIC MANUAL



MASTER DIM & TEST SYSTEM-FWD OVERHEAD PANEL,
GROUP 7

D280A451


WIRING DIAGRAMS
33-18-37

33-18-37

Page 103

# ( BOEING

## 737-800 SYSTEM SCHEMATIC MANUAL



WIRING DIAGRAMS 33-18-41

YT101-YT119, YT126-YT129	MASTER DIM & TEST SYSTEM- AFT OVERHEAD PANEL, GROUP 1
	D280A451


## 33-18-41

Page 101

# BOEING

P6 LOAD CONTROL CENTER

### 737-800 SYSTEM SCHEMATIC MANUAL




YT120, YT130-YT133	MASTER DIM & TEST SYSTEM- AFT OVERHEAD PANEL, GROUP 1
	D280A451

WIRING DIAGRAMS 33-18-41

33-18-41

Page 102





WIRING DIAGRAMS
33-18-42

MASTER DIM & TEST SYSTEMAFT OVERHEAD PANEL,
GROUP 2


D280A451

33-18-42

Page 101

# ( BOEING

## 737-800 SYSTEM SCHEMATIC MANUAL



WIRING DIAGRAMS 33-18-51


MASTER DIM & TEST SYSTEM-GLARESHIELD PANEL

D280A451

33-18-51

Page 101







YT101-YT112, YT126-YT130	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 1
	D280A451


## 33-18-61

Page 101

May 15/2015



WIRING DIAGRAMS
33-18-61



MASTER DIM & TEST SYSTEM-AISLE STAND PANEL,
GROUP 1

Page 102

D280A451

#### BOEING 737-800 SYSTEM SCHEMATIC MANUAL 33-18-21 33-18-33 33-18-42 33-18-64 23-51-11 (SH 1) 77.5 33-18-11 D10046 C311 MASTER DIM BUS 1 (P6-3 D13) D133 28/16V DC N BRT/DIM PWR D131 TEST GND C1179 MASTER DIM SECT 7 (P6-3 F13) BUS 1 7.5 33-18-11 28V DC BAT BUS SECT 3 24-61-11 33-18-22 33-18-33 33-18-35 33-18-37 33-18-42 C310 MASTER DIM BUS BAT 23-51-11 (SH 4) (P6-3 D12) D137 28/16V DC N BRT/DIM PWR D135 — 15 TEST GND -07.5 33-18-11 28V DC C1180 MASTER DIM SECT 8 (P6-3 F14) BUS 2 C312 MASTER DIM BUS 2 (P6-3 D14) ▲ A1 NC 24-61-11 P8-7 F/O AUDIO SELECT PANEL 28V DC BAT BUS SECT 3 24-61-11 33-18-11 31-62-13 C133 MASTER D209 28/16V DC -36 BRT/DIM PWR DIM - 35 TEST GND K2 RELAY DIM DIM BRT TEST 23-12-31 NORM D549 28/16V DC - 36 RRT/DIM PW BRT/DIM PWR 35 TEST GND -6NC·NC P8-73 RADIO TUNING PANEL-3 33-18-22 33-18-61 33-18-64 ×0-TEST (S3) BRT/DIM/TEST LIGHTS SWITCH K1 RELAY M1456 AUX DIM/TEST MODULE MAIN INSTRUMENT PANEL 33-18-11 NORM 34-57-11 34-57-21 D3661 R TEST GND 33-18-11 × D3659 — 4 L TEST GND — 33-18-11 TEST R33 MASTER TEST RELAY 23-12-11 LOAD CONTROL CENTER D203 28/16V DC BRT/DIM PWR 35 TEST GND


MASTER DIM & TEST SYSTEM-YT101-YT120 AISLE STAND PANEL, **GROUP 2** D280A451

33-18-62

WIRING DIAGRAMS 33-18-62


Page 101

Mar 14/2016



## ( BOEING


#### 737-800 SYSTEM SCHEMATIC MANUAL




BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.

## () BOEING

### 737-800 SYSTEM SCHEMATIC MANUAL







ALL	MASTER DIM & TEST SYSTEM- AISLE STAND PANEL, GROUP 4
	D280A451


WIRING DIAGRAMS
33-18-64

33-18-64

Page 101



WIRING DIAGRAMS 33-21-11



#### NOTES:

23


- 1 COLLAR AND LABEL "INOP"
- NOT USED FOR LED LIGHTING, LEGACY CONNECTION
- 3 RESERVED FOR FLOURESCENT LIGHTING

ALL	WINDOW LIGHTS CONTROL
	D280A451

33-21-11

Page 101






D280A451

Mar 14/2016




WIRING DIAGRAMS 33-21-12



#### NOTES:

3

- 1. RS485 USE WIRE TYPE S280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 7.5 FEET TO SUPPORT EMI REQUIREMENTS.
- 3. A, D & E LIGHT ASSEMBLIES DO NOT USE POWER OUT CONNECTION.
- 4. 6V DC ONLY CONNECTED ON M2837 & M2838 EMER LTG FUNC FOR HATCH HANDLE.
- 5. FUSES ARE NOT REPLACEABLE.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.
- 1 NO MORE THAN SIX 35 INCH SIDEWALL LIGHTS AND ONE OWE CAN BE DAISY CHAINED INTERNAL LIGHT TRACE LIMITATION.



	P
	F
POWER O A DATA POWER/DATA O DATA	
POWER O B O POWER/DATA DATA O E O DATA	
POWER/DATA O C POWER/DATA POWER O F POWER DATA ⊕	
CONNECTOR LAYOUT DEFINITION	Т.

PIN#	WIRE LIST			
В	115V AC			
С	AC GROUND	l۲	₩	17 /07
A & D	STATIC		₩ J3/P3 (POWER/DATA IN/OUT	
TABLE 1			PIN #	WIRE LIST
	(DATA IN)	1	В	115V AC
⊕ J2 (DATA IN) P2 (DATA OUT)			С	AC GROUND
PIN#	WIRE LIST		A & D	STATIC
1	RS 485+		1	RS 485+
2	RS 485-		2	RS 485-
5	SHIELD		5	SHIELD
3	TOKEN SIG		3	TOKEN SIG
4	TOKEN REF		4	TOKEN REF
TABLE 2				TABLE 3

⊕ J1 (POWER IN)
 P1 (POWER OUT)


#### RIGHT SIDE

RIGHT SIDE	
YT101-YT120	WINDOW LIGHTS
	D0004.454
	D280A451

33-21-12

Page 101 Sheet 2 Mar 14/2016






D280A451

BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.

Mar 14/2016



WIRING DIAGRAMS
33-21-12




#### NOTES:

-E

2

- 1. RS485 USE WIRE TYPE S280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 7.5 FEET TO SUPPORT EMI REQUIREMENTS.
- 3. A, D & E LIGHT ASSEMBLIES DO NOT USE POWER OUT CONNECTION.
- 4. 6V DC ONLY CONNECTED ON M2837 & M2838 EMER LTG FUNC FOR HATCH HANDLE.
- 5. FUSES ARE NOT REPLACEABLE.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.
- 1 NO MORE THAN SIX 35 INCH SIDEWALL LIGHTS AND ONE OWE CAN BE DAISY CHAINED INTERNAL LIGHT TRACE LIMITATION.



	ľ
POWER O A DATA POWER/DATA O DATA	ŀ
POWER OBOOD POWER/DATA DATA OBOOD POWER DATA	l
POWER/DATA ○ C ○ POWER/DATA POWER ○ F ○ POWER DATA ⊕	ŀ
CONNECTOR LAYOUT DEFINITION	İ

PIN#	WIRE LIST		
В	115V AC		
С	AC GROUND	(m)	17 /D7
A & D			
TABLE 1		PIN #	WIRE LIST
Ø 12 (1.121 an)		В	115V AC
	⊕ J2 (DATA IN)     P2 (DATA OUT)		AC GROUND
PIN#	WIRE LIST	A & D	STATIC
1	RS 485+	1	RS 485+
2	RS 485-	2	RS 485-
5	SHIELD	5	SHIELD
3	TOKEN SIG	3	TOKEN SIG
4	TOKEN REF	4	TOKEN REF
TABLE 2			TABLE 3

⊕ J1 (POWER IN)
 P1 (POWER OUT)


LEFT SIDE

YT101-YT120	WINDOW LIGHTS
<b>[</b>	D280A451

33-21-12

Page 101 Sheet 4 Mar 14/2016






D280A451

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

Page 102 Sheet 1 Jun 21/2016




WIRING DIAGRAMS
33-21-12



#### NOTES:

3

- 1. RS485 USE WIRE TYPE S280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 7.5 FEET TO SUPPORT EMI REQUIREMENTS.
- 3. A, D & E LIGHT ASSEMBLIES DO NOT USE POWER OUT CONNECTION.
- 4. 6V DC ONLY CONNECTED ON M2837 & M2838 EMER LTG FUNC FOR HATCH HANDLE.
- 5. FUSES ARE NOT REPLACEABLE.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.
- 1 NO MORE THAN SIX 35 INCH SIDEWALL LIGHTS AND ONE OWE CAN BE DAISY CHAINED INTERNAL LIGHT TRACE LIMITATION.



POWER O A O DATA POWER/DATA O DATA	-
POWER O B POWER/DATA DATA O E DOWER DATA	ıĖ
POWER/DATA ○ C ○ POWER/DATA POWER ○ F ○ POWER DATA ⊕	ŀ
CONNECTOR LAYOUT DEFINITION	ı

PIN#	WIRE LIST			
В	115V AC			
С	AC GROUND		AD.	17 / D7
A & D	STATIC		₩ J3/P3 (POWER/DATA IN/OUT)	
TABLE 1			PIN #	WIRE LIST
Ø 12 (2171 711)		1	В	115V AC
⊕ J2 (DATA IN) P2 (DATA OUT)			С	AC GROUND
PIN#	WIRE LIST		A & D	STATIC
1	RS 485+		1	RS 485+
2	RS 485-		2	RS 485-
5	SHIELD		5	SHIELD
3	TOKEN SIG		3	TOKEN SIG
4	TOKEN REF		4	TOKEN REF
TABLE 2				TABLE 3

⊕ J1 (POWER IN)
 P1 (POWER OUT)


#### RIGHT SIDE

YT126-YT133	WINDOW LIGHTS
	D280A451

33-21-12

Page 102 Sheet 2 Jun 21/2016






BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.



WIRING DIAGRAMS 33-21-12




#### NOTES:

-E

2

- 1. RS485 USE WIRE TYPE S280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 7.5 FEET TO SUPPORT EMI REQUIREMENTS.
- 3. A, D & E LIGHT ASSEMBLIES DO NOT USE POWER OUT CONNECTION.
- 4. 6V DC ONLY CONNECTED ON M2837 & M2838 EMER LTG FUNC FOR HATCH HANDLE.
- 5. FUSES ARE NOT REPLACEABLE.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.
- 1 NO MORE THAN SIX 35 INCH SIDEWALL LIGHTS AND ONE OWE CAN BE DAISY CHAINED INTERNAL LIGHT TRACE LIMITATION.



POWER O- DATA O-	A DATA F	POWER/DATA	OO	DATA	
POWER O- DATA O-	B POWER/DATA	DATA		POWER Data	
POWER/DATA O-	c POWER/DATA	POWER DATA	F C	POWER DATA	⊕

	CFOWER OOT			
PIN#	WIRE LIST			
В	115V AC			
С	AC GROUND		AD.	17 / D7
A & D	STATIC	₩ J3/P3 (POWER/DATA IN/OUT)		
TABLE 1			PIN #	WIRE LIST
(A) (2 (2474 TH)		1	В	115V AC
⊕ J2 (DATA IN) P2 (DATA OUT)			С	AC GROUND
PIN#	WIRE LIST		A & D	STATIC
1	RS 485+		1	RS 485+
2	RS 485-		2	RS 485-
5	SHIELD		5	SHIELD
3	TOKEN SIG		3	TOKEN SIG
4	TOKEN REF		4	TOKEN REF
TABLE 2				TABLE 3

⊕ J1 (POWER IN)
 P1 (POWER OUT)


LEFT SIDE

YT126-YT133	WINDOW LIGHTS
	D280A451

33-21-12

Page 102 Sheet 4 Jun 21/2016





M2785 FWD ATTENDANT CONTROL PANEL

NOTES:

1 RESERVED FOR FLOURESCENT LIGHTING

POWER DISTRIBUTION PANEL

**CEILING LIGHTS CONTROL** ALL D280A451

33-22-11

Page 101


Jun 21/2016

M1415


LAV A MODULE












#### NOTES:

- 1. RS485 USE WIRE TYPE 280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 6.5 FT TO SUPPORT EMI REQUIREMENTS.
- 3. FUSES ARE NOT REPLACEABLE.
- 4. LIGHT ASSEMBLY IS NOT TO BE DISASSEMBLED (REMOVE/REPLACE).
- 5. ONLY HALF OF LIGHT ASSEMBLY IS SHOWN ON THIS SCHEMATIC.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.

LEFT SIDE



PIN#	WIRE LIST		
В	115V AC		
С	AC GROUND		
Α	STATIC		
TABLE 1			
J2 (INPUT)/ P2 (OUTPUT)			
PIN # WIRE LIST			
1 RS 485+			
2 RS 485-			
5	SHIELD		
3	TOKEN SIG		
4 TOKEN REF			
TABLE 2			

J1 (POWER)


CEILING LIGHTS

D280A451

33-22-12


Page 101 Sheet 2 Jun 21/2016





BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.






BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.



WIRING DIAGRAMS
33-22-41




## NOTES:

-E

- 1. RS485 USE WIRE TYPE S280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 6.5 FEET TO SUPPORT EMI REQUIREMENTS.
- 3. FUSES ARE NOT REPLACEABLE.
- 4. LIGHT ASSEMBLY IS NOT TO BE DISASSEMBLED (REMOVE/REPLACE).
- 5. ONLY HALF OF LIGHT ASSEMBLY IS SHOWN ON THIS SCHEMATIC.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.

LEFT SIDE

ALL	CEILING WASH LIGHTS - LEFT
	D280A451




J4 (POWER)		
PIN#	WIRE LIST	
В	115V AC	
С	AC GROUND	
Α	STATIC	
TABLE 1		
J5 (INPUT)/ P5 (OUTPUT)		
PIN#	WIRE LIST	
1	RS 485+	
2	RS 485-	
5	SHIELD	
3	TOKEN SIG	
4	TOKEN REF	
TABLE 2		

# 33-22-14

Page 101 Sheet 1 Jun 21/2016









- 1. RS485 USE WIRE TYPE S280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 6.5 FT TO SUPPORT EMI REQUIREMENTS.
- 3. FUSES ARE NOT REPLACEABLE.
- 4. LIGHT ASSEMBLY IS NOT TO BE DISASSEMBLED (REMOVE/REPLACE).
- 5. ONLY HALF OF LIGHT ASSEMBLY IS SHOWN ON THIS SCHEMATIC.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.

LEFT SIDE





C AC GROUND		
A STATIC		
TABLE 1		
J5 (INPUT)/ P5 (OUTPUT)		
PIN # WIRE LIST		
1 RS 485+		
2 RS 485-		
5 SHIELD		
3 TOKEN SIG		
4 TOKEN REF		
TABLE 2		

J4 (POWER)
PIN # WIRE LIST

# 33-22-14

Page 101 Sheet 2 Jun 21/2016


CEILING WASH LIGHTS - LEFT

D280A451

BOEING PROPRIETARY - Copyright  $\mathop{\hbox{$\mathbin{\odot}}}$  - Unpublished Work - See title page for details.



WIRING DIAGRAMS 33-22-51





#### NOTES:

13

- 1. RS485 USE WIRE TYPE 280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 6.5 FEET TO SUPPORT EMI REQUIREMENTS.
- FUSES ARE NOT REPLACEABLE.
- 4. LIGHT ASSEMBLY IS NOT TO BE DISASSEMBLED (REMOVE/REPLACE).
- 5. ONLY HALF OF LIGHT ASSEMBLY IS SHOWN ON THIS SCHEMATIC.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.

RIGHT SIDE





PIN#	WIRE LIST	
В	115V AC	
С	AC GROUND	
Α	STATIC	
TABLE 1		
J5 (INPUT)/ P5 (OUTPUT)		
PIN#	WIRE LIST	
1	RS 485+	
2	RS 485-	
5	SHIELD	
3	TOKEN SIG	
4 TOKEN REF		
TABLE 2		


J4 (POWER)

# 33-22-15

Page 101 Sheet 1 Jun 21/2016








#### NOTES:

- 1. RS485 USE WIRE TYPE 280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 6.5 FT TO SUPPORT EMI REQUIREMENTS.
- 3. FUSES ARE NOT REPLACEABLE.
- 4. LIGHT ASSEMBLY IS NOT TO BE DISASSEMBLED (REMOVE/REPLACE).
- 5. ONLY HALF OF LIGHT ASSEMBLY IS SHOWN ON THIS SCHEMATIC.
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.
- 7. DATABUS 485 RUNS THROUGH PINS 1 & 2.

RIGHT SIDE

ALL	CEILING WASH LIGHTS - RIGHT
	D280A451



В	115V AC	
С	AC GROUND	
Α	STATIC	
TABLE 1		
J5 (INPUT)/ P5 (OUTPUT)		
PIN#	WIRE LIST	
1	RS 485+	
2 RS 485-		
5 SHIELD		
3 TOKEN SIG		
4 TOKEN REF		
TABLE 2		


J4 (POWER)

# 33-22-15

Page 101 Sheet 2 Jun 21/2016



WIRING DIAGRAMS 33-23-11



#### NOTES

-ĸ <sup>—</sup>


- 1 PSU: PASSENGER SERVICE UNIT
- 2 MATE WITH PSU IF INSTALLED
- 3 ALL PSU DISCONNECTS LOCATED AT: WL 274,LBL 51

ALL	PASS READING LTS - LEFT FWD
	D280A451


33-23-11

Page 101









PSU

DISC (STA 588) PSII

DISC (STA 611)

PSU

DISC (STA 565) PSU DISC (STA 630) PSU

DISC (STA 660) PSU

DISC (STA 680) WIRING DIAGRAMS 33-23-21

#### NOTES

-F<sup>┌─</sup>

2

- 1 PSU: PASSENGER SERVICE UNIT
- 2 MATE WITH PSU IF INSTALLED
- 3 ALL PSU DISCONNECTS LOCATED AT: WL 274,LBL 51


ALL	PASS READING LTS - RIGHT FWD
	D280A451

33-23-21

Page 101


# ( BOEING

## 737-800 SYSTEM SCHEMATIC MANUAL





WIRING DIAGRAMS 33-23-31



NOTES:

1 FUSE IS REPLACEABLE

ALL	READING LTS - PASS SERVICE UNIT
	D280A451

33-23-31


Page 101





-E [

# 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS 33-24-11








33-24-11

Page 101






#### NOTES:

- 1 PIN "D" IS NOT USED.
- 2 THIS LIGHT IS CONTROLLED FROM "FORWARD ENTRY AREA" SUB-MENU.
- 3 THIS LIGHT IS CONTROLLED FROM "PASSENGER SEATING AREA" SUB-MENU.
- 1. RS485 USE WIRE TYPE S280W502-6 OR EQUIVALENT.
- 2. GROUND WIRES NOT TO EXCEED 10.5 FEET TO SUPPORT EMI REQUIREMENTS.
- 3. DATABUS 485 RUNS THROUGH PINS 1 & 2.
- 4. FUSES ARE NOT REPLACEABLE.
- 5. LIGHT ASSEMBLY IS NOT TO BE DISASSEMBLED (REMOVE/REPLACE).
- 6. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.

ALL	COVE LIGHTS
1	D280A451



XCVR 2

XCVR 1

→ NEXT LRU

→ NEXT LRU

P2/P3

★ J2/J3 (INPUT)/ P2/P3 (OUTPUT)	
PIN#	WIRE LIST
1	RS 485+
2	RS 485-
5	SHIELD
3	TOKEN SIG
4	TOKEN REF
TABLE 2	

 ⊕ J1 (P0WER) PIN # WIRE LIST 115V AC

> AC GROUND STATIC

TABLE 1

В

# 33-24-12


Page 101 Sheet 1 Jun 21/2016

M2806, M2807, M2808, M2809.

J2/J3 { TOKEN 0-



WIRING DIAGRAMS
33-24-22




#### NOTES:

-K

- 1 PIN "D" IS NOT USED.
- 2 THIS LIGHT IS CONTROLLED FROM "AFT ENTRY AREA" SUB-MENU.
- 3 THIS LIGHT IS CONTROLLED FROM "PASSENGER SEATING AREA" SUB-MENU.
- 1. RS485 USE WIRE TYPE S280W502-6 OR EQUIVALENT.
- 2. DATABUS 485 RUNS TRHOUGH PINS 1 & 2.
- 3. FUSES ARE NOT REPLACEABLE.
- 4. LIGHT ASSEMBLY IS NOT TO BE DISASSEMBLED (REMOVE/REPLACE).
- 5. VENDOR TOKEN WIRE DOES NOT REQUIRE TWISTED PAIR, CONTROLLED LENGTH.

ALL	COVE LIGHTS
	D280A451




			P2/P3 (OUTPUT)	
			PIN #	WIRE LIST
⊕ 1	1 (POWER)		1	RS 485+
PIN#	WIRE LIST		2	RS 485-
В	115V AC		5	SHIELD
С	AC GROUND		3	TOKEN SIG
Α	STATIC		4	TOKEN REF
TABLE 1			TABLE 2	
		•		

# 33-24-12

₩ J2/J3 (INPUT)/


Page 101 Sheet 2 Jun 21/2016





BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.







BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.



WIRING DIAGRAMS







NOTES:

SUPPLIER NUMBER MAY DIFFER FROM BOEING.
SEE SUPPLIER CMM. L4 LEGACY IS L14 NEW COMMON LAV.

2 6 LED STRING.

YT101-YT118	PASS SIGNS - MISC
	D280A451

33-25-12


Page 101


Mar 14/2016



WIRING DIAGRAMS

33-25-11
33-25-21
33-25-22





NOTES:

EQUIPMENT AND WIRING INFORMATION FOR EACH LAV. SEE SUPPLIER CMM.

YT119-YT120	PASS SIGNS - MISC
	D280A451

33-25-12


Page 102




187

# 737-800 SYSTEM SCHEMATIC MANUAL







NOTES:

SUPPLIER NUMBER MAY DIFFER FROM BOEING.
SEE SUPPLIER CMM. L4 LEGACY IS L14 NEW COMMON LAV.

2 6 LED STRING.

YT126-YT127	PASS SIGNS - MISC
	D280A451


33-25-12

Page 103





164

# 737-800 SYSTEM SCHEMATIC MANUAL









NOTES:

1 SUPPLIER NUMBER MAY DIFFER FROM BOEING. SEE SUPPLIER CMM. L4 LEGACY IS L14 NEW COMMON LAV.

2 6 LED STRING.


YT128-YT131	PASS SIGNS - MISC
	D280A451

33-25-12

Page 104



WIRING DIAGRAMS
33-25-21



NOTES

-D┌


1 MATE WITH PASSENGER SERVICE UNIT IF INSTALLED

ALL	PASS SIGNS - PSU LEFT FWD
	D280A451

33-25-21

Page 101





#### NOTES

2

1 MATE WITH PASSENGER SERVICE UNIT IF INSTALLED


ALL	PASS SIGNS - PSU LEFT AFT
	D280A451

33-25-22

Page 101



-E WIRING DIAGRAMS 2



NOTES


1 MATE WITH PASSENGER SERVICE UNIT IF INSTALLED

ALL	PASS SIGNS - PSU RIGHT FWD
	D280A451

33-25-31

33-25-31

Page 101



NOTES

1 MATE WITH PASSENGER SERVICE UNIT IF INSTALLED


ALL	PASS SIGNS - PSU RIGHT AFT
	D280A451

33-25-32

Page 101



WIRING DIAGRAMS 33-25-41



NOTES:

 $\fbox{1}$  FUSES ARE NON REPLACEABLE.

1. M5 IS A REMOVE/REPLACE ITEM.

NO SMOKING/FASTEN
SEAT BELT SIGNS PASS SERVICE UNIT


D280A451

33-25-41

Page 101

# BOEING

# 737-800 SYSTEM SCHEMATIC MANUAL




ALL	ATTENDANT WORK LIGHTS
	D280A451

33-26-11

Page 101





WIRING DIAGRAMS
33-26-21

BALLAST OPERATION

PINS F-A PINS F-D

OFF SHORT ANY

DIM OPEN SHORT

BRT OPEN OPEN


#### NOTES:

EITHER A 3 POSITION TOGGLE OR ROTARY SWITCH OR 2 PUSH BUTTON SWITCH (ON/OFF & BRIGHT/DIM) WILL BE USED TO CONTROL GALLEY G1 LIGHT.

ALL	GALLEY LIGHTS
	D280A451

33-26-21

Page 101




D280A451

BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.


Mar 14/2016

# BOEING

# 737-800 SYSTEM SCHEMATIC MANUAL



[2] LIGHTING EQUIPMENT AND WIRING ARE SHOWN ON SHEET 2 FOR THE ADVANCED LAVATORY INTERNALS.




33-26-31

Page 102 Sheet 1 Jun 21/2016




WIRING DIAGRAMS 33-26-31



BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.





NOTES:


[1] SUPPLIER NUMBER MAY DIFFER FROM BOEING. SEE SUPPLIER CMM. S3 LEGACY IS S13 & S4 LEGACY IS S14 NEW COMMON LAV. L4 LEGACY IS L14 NEW COMMON LAV.

YT101-YT118, YT126-YT131	PASSENGER AND LAVATORY CALL CONTROL
	D280A451

33-27-11

Page 101

Mar 14/2016





#### NOTES:

1 FOR WIRE DIAGRAM AND PART INFO, SEE SUPPLIER CMM.

33-27-11	YT119-YT120, YT132-YT133  PASSENGER AND LAVATORY CALL CONTROL
Page 102	
Jun 21/2016	D280A451








33-27-21


Page 101






BOEING PROPRIETARY - Copyright  $\odot$  - Unpublished Work - See title page for details.








33-27-31

Page 101






BOEING PROPRIETARY - Copyright  $\odot$  - Unpublished Work - See title page for details.



WIRING DIAGRAMS
33-27-41



M2812 (YBA) RIGHT PASSENGER SERVICE UNIT (PSU) MODULE WITH SPEAKER M2884 (YBD) LEFT PASSENGER SERVICE UNIT (PSU) MODULE WITH SPEAKER

### NOTES:

-M —

TO FOR MULTI CLASS CONFIGURATION:
MOVE SWITCH 55 TO POSITION 1
FOR PSUS FAD OF CLASS PARTITION
MOVE SWITCH 55 TO POSITION 2
FOR PSUS AFT OF CLASS PARTITION

FOR SINGLE CLASS CONFIGURATION:
MOVE SWITCH 55 TO POSITION 1
FOR FWO HALF OF PSUS
MOVE SWITCH 55 TO POSITION 2
FOR AFT HALF OF PSUS
FOR AFT HALF OF PSUS

P4 MATES WITH PSU DISCONNECT DXXXXX (SEE 33-27-2X AND 33-27-3X)

5 FUSE IS REPLACEABLE

PASSENGER AND LAVATORY
CALL - PSU


D280A451


33-27-41

Page 101









### NOTES:

- 1 COLLAR AND LABEL "INOP".
- NOT USED FOR LED LIGHTING, LEGACY CONNECTION.
- 3 TAPE AND STOW WIRE.


YT101-YT118, YT126-YT131	ENTRY LIGHTS
	D280A451

33-29-11

Page 101



WIRING DIAGRAMS 33-29-11



NOTES:


102

YT119-YT120, YT132-YT133	ENTRY LIGHTS
	D280A451

33-29-11

Page 102






YT101-YT111, YT126-YT130	SERVICE LIGHTING - WHEEL WELLS
	D280A451

33-32-11

Page 101

Jan 12/2015






YT112-YT120, YT131-YT133	SERVICE LIGHTING - WHEEL WELLS
	D280A451

33-32-11

Page 102





YT101-YT111, YT126-YT130	SERVICE LIGHTING - AIR CONDITIONING COMPARTMENT
	D280A451


33-33-11

Page 101

Jan 12/2015

LEFT AIR CONDITIONING COMPARTMENT






D280A451

BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.

Page 102



WIRING DIAGRAMS 33-34-11



SERVICE LIGHTING EQUIPMENT RACK FORWARD
LOWER COMPARTMENT

D280A451

33-34-11

Page 101

Jan 12/2015



D11418

OFF

D16262


-A

28V AC GND SVCE BUS 1 24-53-11 Y36

P91

## 737-800 SYSTEM SCHEMATIC MANUAL





YT112-YT120, YT131-YT133 **SERVICE LIGHTING -EQUIPMENT RACK FORWARD** LOWER COMPARTMENT D280A451

33-34-11


Page 102



-вГ

## 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS
33-35-11



SERVICE LIGHTING ACCESSORY COMPARTMENT

D280A451


33-35-11

Page 101

Jan 12/2015



WIRING DIAGRAMS 33-35-11



YT112-YT120, YT131-YT133	SERVICE LIGHTING - ACCESSORY COMPARTMENT
	D280A451

33-35-11


Page 102



-F

## 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS 33-36-11



YT101-YT111, YT126-YT130	SERVICE LIGHTING - CARGO COMPARTMENT - FWD	33-36-11
		Page 101
	D280A451	Jan 12/2015





-E

6

### 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS 33-36-11





33-36-11

Page 102




-G

2

## 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS 33-36-11




YT101-YT111, YT126-YT130	SERVICE LIGHTING - CARGO COMPARTMENT - AFT	33-36-12
		Page 101
	D280A451	Jan 12/2015



-G┌


### 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS 33-36-12





WIRING DIAGRAMS 33-41-11



1 TRANSFORMER LOCATED WITHIN PRESSURIZED AREA

ALL	EXTERIOR LIGHTS - WING SCANNING
	D280A451


33-41-11

Page 101



P18-3 CIRCUIT BREAKER PANEL

## 737-800 SYSTEM SCHEMATIC MANUAL



33-42-11

WIRING DIAGRAMS

YT101-YT112, YT126-YT130

EXTERIOR LIGHTS - LANDING

D280A451

S260 LEFT RETRACTABLE LANDING LIGHT SW (P5)

33-42-11

Page 101

May 15/2015


- 5 CASE

3 LAMP POWER

L322 LEFT RETRACTABLE LANDING LIGHT (STA500A+10 WL150 LBL32)







#### NOTES:

1 CAP AND STOW WIRING AS CLOSE AS POSSIBLE TO \$258 SWITCH.

D10982


 $\overline{2}$  ALL WIRES OUTSIDE THE PRESSURE VESSEL SHALL BE INDIVIDUALLY SHIELDED.

3 CAP AND STOW WIRING AS CLOSE AS POSSIBLE TO D15948 OF M3079.

YT113-YT120, YT131-YT133	LANDING TAXI AND RUNWAY TURNOFF LIGHTING SYSTEMS
	D280A451

## 33-42-21

Page 101 Sheet 1 Jun 21/2016



### NOTES:

1 CAP AND STOW WIRING AS CLOSE AS POSSIBLE TO \$259 SWITCH.

NG/DOWN

R444 TAXI LIGHT CONTROL RELAY (J4)

- 2 ALL WIRES OUTSIDE THE PRESSURE VESSEL SHALL BE INDIVIDUALLY SHIELDED.
- 3 CAP AND STOW WIRING AS CLOSE AS POSSIBLE TO D15934 OF M3078.

YT113-YT120, YT131-YT133	LANDING TAXI AND RUNWAY TURNOFF LIGHTING SYSTEMS
	D280A451


AUT0

S61 SWITCH TAXI LIGHT

## 33-42-21

Page 101 Sheet 2 Jun 21/2016





#### NOTES:

1 TRANSFORMER FT1246 OUTPUT VOLTAGE IS (10V) AND PRR38275-14 CHANGES TRANSFORMER TO FT1348 OUTPUT VOLTAGE IS (9V)


YT101	EXTERIOR LIGHTS - POSITION
	D280A451

# 33-43-11

Page 101

Aug 15/2013





NOTES:

T > TRANSFORMER FT1246 OUTPUT VOLTAGE IS (10V) AND PRR38275-14 CHANGES TRANSFORMER TO FT1348 OUTPUT VOLTAGE IS (9V)

YT102-YT133	EXTERIOR LIGHTS - POSITION
	D280A451

33-43-11


Page 102



-ĸ┌

### 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS 33-44-11



ALL	EXTERIOR LIGHTS - ANTICOLLISION - RED
	D280A451

33-44-11


Page 101



19

## 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS 33-44-12



YT101	EXTERIOR LIGHTS - ANTICOLLISION - WHITE	
	D280A451	

33-44-12

Page 101

Aug 15/2013



-вГ


26

### 737-800 SYSTEM SCHEMATIC MANUAL

WIRING DIAGRAMS


33-44-12

Page 102





WIRING DIAGRAMS 33-45-11



YT101-YT105	EXTERIOR LIGHTS - TAXI AND RUNWAY TURNOFF
	D280A451

33-45-11


Page 101

Apr 17/2014



-ВГ 13

WIRING DIAGRAMS 33-45-11



YT106-YT112, YT126-YT130	EXTERIOR LIGHTS - TAXI AND RUNWAY TURNOFF
	D280A451


33-45-11

Page 102

May 15/2015







115V INT0	LV	LAMP LIFE	LIGHT OUTPUT
HV1	11.5	LONGER	DIMMER
HV2	12.0	NOMINAL	NOMINAL
HV3	12.5	SHORTER	BRIGHTER


EXTERIOR LIGHTS STABILIZER (LOGO)
FLOOD LIGHTS

D280A451

33-49-11


Page 101





BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.







EMERGENCY EXIT LIGHTS CONTROL


D280A451


Page 101 Sheet 2 Jun 21/2016



BOEING PROPRIETARY - Copyright () - Unpublished Work - See title page for details.










33-51-13

Page 101









33-51-14

Page 101

#### BOEING 737-800 SYSTEM SCHEMATIC MANUAL -вГ WIRING DIAGRAMS 375 33-51-11 (SH 1) D3660 0.32A D12436 6 (SH 2) (SH 2) 33-51-21 33-51-22 0.1-6.5V DC 15 — D3658 D12010 D3670 0.32A D10716 C 10 — D12434 6.1-6.5V DC 5 LAMPS D3672 6.1-6.5V DC 5 LAMPS L1359 EXIT INDICATOR LT L1186 EXIT INDICATOR LT (STA 293 WL 233 RBL 51) (PROV) (STA 642 WL 248 LBL 62) L1189 EXIT INDICATOR LT (STA 614 WL 224 LBL 62) D12052 D13258 6.1-6.5V DC 12 D3668 — =1 — D3666 0.32A 6.1-6.5V DC 12 -M2816 EMERGENCY EXIT LIGHT BATTERY PACK 6.1-6.5V DC 11 M1670 EMERGENCY EXIT LIGHT BATTERY PACK (STA 727C+13 WL 212 LBL 68) 5 LAMPS (STA 310 WL 290 RBL 6) M1695 EMERGENCY EXIT LIGHT BATTERY PACK (STA 565 WL 213 RBL 68) L1188 EXIT INDICATOR LT (STA 614 WL 224 RBL 62) M1386 AISLE INDICATOR LIGHT MODULE (PROV) (STA 430 WL 208 LBL 11) M2400 AISLE INDICATOR LIGHT MODULE (PROV) (STA 727C+10 WL 208 LBL 10) 33-51-11 (SH 1) D12828 (SH 1) D10750 6.1-6.5V DC 12 — D12350 D10088 0.32A 33-51-11 (SH 2) RSV FOR PROX LIGHTS ON FWD LEFT FULL HEIGHT MONUMENT D10086 0 0 (SH 2) D10744 6.1-6.5V DC 10 — 5 LAMPS 33-51-11 (SH 2) (SH 2) D12008 6.1-6.5V DC 12 -L1191 EXIT INDICATOR LT (STA 993 WL 244 RBL 53) M1672 EMERGENCY EXIT D12748 7 AISLE INDICATOR M2267 (STA 952 WL 290 RBL 14) RSV FOR PROX LIGHTS ON FWD LIGHT MODULE (PROV) (STA 570 WL 208 LBL 9) □ 2 J LEFT UNDER-BIN MONUMENT 33-51-11 (SH 2) D12064 0.32A (SH 2) D10746 6.1-6.5V DC 12 — D13124 D12066 5 LAMPS D3662 0.32A 6.1-6.5V DC 15 \_\_\_\_ L1207 EXIT INDICATOR LT (STA 576 WL 224 RBL 62) D3664 5 LAMPS M1675 EMERGENCY EXIT LIGHT BATTERY PACK (STA 317 WL 290 LBL 10) M1389 AISLE INDICATOR LIGHT MODULE (PROV) (STA 855 WL 208 LBL 10) D12068 0.32A L1187 EXIT INDICATOR LT 6.1-6.5V DC 11 (STA 304 WL 230 LBL 51) D12072 5 LAMPS M1694 EMERGENCY EXIT LIGHT BATTERY PACK (STA 565 WL 213 LBL 68) 33-51-11 (SH 1) D10082 0.32A L1208 EXIT INDICATOR LT (STA 576 WL 224 LBL 62) (SH 1) D13018 6.1-6.5V DC 12 — D12802 6.1-6.5V DC 10 D10084 5 LAMPS ·I-- 5 L1190 EXIT INDICATOR L1 (STA 993 WL 244 LBL 53) 33-51-11 (SH 2) M2335 EMERGENCY EXIT LIGHTS BATTERY PACK (500C+7 WL 213 LBL 67) (SH 2) D12004 6.1-6.5V DC 10 -D12430 M2253 AISLE INDICATOR LIGHT MODULE (PROV) (STA 500C+10 WL 208 LBL 11) D12432 — =1 ₩ • D3738 P21 0.32A M1671 EMERGENCY EXIT LIGHT BATTERY PACK (STA 727C+13 WL 212 RBL 68) 6.1-6.5V DC 14 L1358 EXIT INDICATOR LT (PRNV) (STA 642 WL 248 RBL 62) 5 LAMPS M1673 EMERGENCY EXIT LIGHT BATTERY PACK (STA 952 WL 291 LBL 14) AFT LAV FLOOD LT M1418(Y7) LEFT AFT LAV D MODULE **EMERGENCY EXIT LIGHTS -**ALL 33-51-21 FLOOR PROXIMITY Page 101

D280A451