



WIRING DIAGRAM MANUAL

CHAPTER 28 FUEL

	CH-SC-SU	Schem	Page	Sheet	Date	CH-SC-SU	Schem	Page	Sheet	Date	
28-	-EFFECTIVE	PAGES									
			1		Jun 21/2016						
			2		BLANK						
	-CONTENTS	;									
R			1		Jun 21/2016						
R			2		Jun 21/2016						
28-	-ALPHABET	ICAL IND									
			1		Aug 15/2013						
	00 01 11		2		BLANK						
	28-21-11		4	4	l 00/0015						
			1		Jun 29/2015						
R			2		Jun 29/2015 Jun 21/2016						
R			2	2	Jun 21/2016						
l n	28-21-21			2	Juli 2 1/2010						
R	20-21-21		1		Jun 21/2016						
1,,	28-22-11		ļ		Juli 2 1/2010						
R	20 22 11		1		Jun 21/2016						
1.,	28-23-11		•		0411 Z 172010						
	20 20 11		1	1	Dec 10/2015						
			-		Dec 10/2015						
					Dec 10/2015						
					Dec 10/2015						
R			2		Jun 21/2016						
R				2	Jun 21/2016						
R				3	Jun 21/2016						
R				4	Jun 21/2016						
	28-41-11										
			1		Aug 15/2013						
			_		Aug 15/2013						
			2		Feb 17/2015						
					Feb 17/2015						
			0		Feb 17/2015						
R R			3		Jun 21/2016 Jun 21/2016						
R					Jun 21/2016						
A			4		Jun 21/2016						
A			7		Jun 21/2016						
Α					Jun 21/2016						
l'`	28-42-11			Ū	0411 Z 1720 10						
R	_0 11		1		Jun 21/2016						
1	28-43-11		-		· · - · · - · · · · ·						
R			1		Jun 21/2016						
	28-44-11										
R			1	1	Jun 21/2016						
R				2	Jun 21/2016						

A = Added, R = Revised, D = Deleted, O = Overflow



WIRING DIAGRAM MANUAL

CHAPTER 28 FUEL

Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
ENGINE FUEL SYSTEM						
ENGINE FUEL SHUT-OFF VALVES	28-21-11		1	1	Jun 29/2015	YT101-YT112 YT126-YT131
				2	Jun 29/2015	YT101-YT112 YT126-YT131
			2	1	Jun 21/2016	YT113-YT120 YT132-YT133
				2	Jun 21/2016	YT113-YT120 YT132-YT133
BATTERY AND CONTROL POWER ENGINE SPAR AND APU FUEL VALVES	28-21-21		1		Jun 21/2016	ALL
ENGINE FUEL FEED SYSTEM						
FUEL CROSSFEED VALVE	28-22-11		1		Jun 21/2016	ALL
FUEL BOOST PUMPS						
FUEL BOOST PUMPS	28-23-11		1	1	Dec 10/2015	YT101-YT116 YT126-YT131
				2	Dec 10/2015	YT101-YT116 YT126-YT131
				3	Dec 10/2015	YT101-YT116 YT126-YT131
				4	Dec 10/2015	YT101-YT116 YT126-YT131
			2	1	Jun 21/2016	YT117-YT120 YT132-YT133
				2	Jun 21/2016	YT117-YT120 YT132-YT133
				3	Jun 21/2016	YT117-YT120 YT132-YT133
				4	Jun 21/2016	YT117-YT120 YT132-YT133
FUEL QUANTITY INDICATING						
FUEL QUANTITY	28-41-11		1	1	Aug 15/2013	YT101-YT103
				2	Aug 15/2013	YT101-YT103
			2	1	Feb 17/2015	YT104-YT109 YT126-YT129
				2	Feb 17/2015	YT104-YT109 YT126-YT129



WIRING DIAGRAM MANUAL


CHAPTER 28 FUEL

Title	CH-SC-SU	Schem	Page	Sheet	Date	Effectivity
FUEL QUANTITY (cont.)	28-41-11			3	Feb 17/2015	YT104-YT109 YT126-YT129
			3	1	Jun 21/2016	YT110-YT112 YT130-YT131
				2	Jun 21/2016	YT110-YT112 YT130-YT131
				3	Jun 21/2016	YT110-YT112 YT130-YT131
			4	1	Jun 21/2016	YT113-YT120 YT132-YT133
				2	Jun 21/2016	YT113-YT120 YT132-YT133
				3	Jun 21/2016	YT113-YT120 YT132-YT133
FUEL TEMPERATURE INDICA	TING SYSTE	<u>M</u>				
FUEL TEMPERATURE INDICATION	28-42-11		1		Jun 21/2016	ALL
FUEL PRESSURE INDICATING	S SYSTEM					
FUEL BOOST PUMPS LOW PRESSURE WARNING LIGHTS	28-43-11		1		Jun 21/2016	ALL
REFUELING INDICATION						
GROUND REFUELING	28-44-11		1	1	Jun 21/2016	ALL
				2	Jun 21/2016	ALL



CHAPTER 28

FUEL						
CH-SC-SU	Title					
28-21-21	BATTERY AND CONTROL POWER ENGINE SPAR AND APU FUEL VALVES					
28-21-11	ENGINE FUEL SHUT-OFF VALVES					
28-23-11	FUEL BOOST PUMPS					
28-43-11	FUEL BOOST PUMPS LOW PRESSURE WARNING LIGHTS					
28-22-11	FUEL CROSSFEED VALVE					
28-41-11	FUEL QUANTITY					
28-42-11	FUEL TEMPERATURE INDICATION					
28-44-11	GROUND REFUELING					



YT101-YT112, YT126-YT131

ENGINE FUEL
SHUT-OFF VALVES


D280A351

28-21-11

Page 1 Sheet 1 Jun 29/2015 28-21-11

Page 1 Sheet 1 Jun 29/2015





Page 1

Sheet 2

Jun 29/2015


D280A351

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

Page 1

Sheet 2

Jun 29/2015



YT113-YT120, YT132-YT133

ENGINE FUEL SHUT-OFF VALVES


D280A351

28-21-11

Page 2 Sheet 1 Jun 21/2016 28-21-11

Page 2 Sheet 1 Jun 21/2016





Sheet 2


Jun 21/2016

D280A351

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

Page 2 Sheet 2 Jun 21/2016

-В ^Г



P6 LOAD CONTROL CENTER-RIGHT

BATTERY AND CONTROL POWER ENGINE SPAR AND APU FUEL VALVES

D280A351

28-21-21


Jun 21/2016

Page 1

28-21-21

Page 1

Jun 21/2016



FUEL CROSSFEED VALVE D280A351

P5 PLT OVHD PNL (FWD AND AFT)

28-22-11


Page 1

Jun 21/2016

28-22-11


Page 1

Jun 21/2016




BOEING

737-800 WIRING DIAGRAM MANUAL



P91 POWER DISTRIBUTION PANEL 1



YT101-YT116, YT126-YT131 FUEL BOOST PUMPS


D280A351

28-23-11

Page 1 Sheet 3 Dec 10/2015 28-23-11

Page 1 Sheet 3 Dec 10/2015

P92 POWER DISTRIBUTION PANEL 2



YT101-YT116, YT126-YT131


FUEL BOOST PUMPS

D280A351

28-23-11


Page 1 Sheet 4 Dec 10/2015 28-23-11

Page 1 Sheet 4 Dec 10/2015




BOEING

737-800 WIRING DIAGRAM MANUAL



P91 POWER DISTRIBUTION PANEL 1

737-800 WIRING DIAGRAM MANUAL




28-23-11

Page 2 Sheet 3 Jun 21/2016 28-23-11

Page 2 Sheet 3 Jun 21/2016

P92 POWER DISTRIBUTION PANEL 2

737-800 WIRING DIAGRAM MANUAL




28-23-11

Page 2 Sheet 4 Jun 21/2016 28-23-11

Page 2 Sheet 4 Jun 21/2016






FUEL QUANTITY

D280A351


28-41-11

Page 1 Sheet 1 Aug 15/2013 28-41-11

Page 1 Sheet 1 Aug 15/2013







YT104-YT109, YT126-YT129


FUEL QUANTITY

D280A351

28-41-11

Page 2 Sheet 1 Feb 17/2015 28-41-11

Page 2 Sheet 1 Feb 17/2015



-B^{┌─}

W0311

W0321

W0321

W0321

W0321

W0321

W0321

W0322

UNG 10-26048-22

W6610-26048-22

W6610-26048-22

W675 DIGITAL FLIGHT DATA ACQUISITION UNIT

E3-2 SHELF

YT104-YT109, YT126-YT129

FUEL QUANTITY


D280A351

28-41-11

Page 2 Sheet 3 Feb 17/2015 28-41-11

Page 2 Sheet 3 Feb 17/2015






28-41-11

Page 3 Sheet 1 Jun 21/2016 28-41-11

Page 3 Sheet 1 Jun 21/2016



BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.

BOEING

-B^{┌─}


28-41-11

Page 3 Sheet 3 Jun 21/2016 28-41-11

Page 3 Sheet 3 Jun 21/2016

BOEING


737-800 WIRING DIAGRAM MANUAL



28-41-11

Page 4 Sheet 1 Jun 21/2016 28-41-11

Page 4 Sheet 1 Jun 21/2016



BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.


-B[┌]

28-41-11

Page 4 Sheet 3 Jun 21/2016 28-41-11

Page 4 Sheet 3 Jun 21/2016





FUEL TEMPERATURE INDICATION

D280A351

28-42-11


Page 1

Jun 21/2016

28-42-11

Page 1

Jun 21/2016



FUEL BOOST PUMPS
LOW PRESSURE
WARNING LIGHTS

28-43-11


Page 1

D280A351

D280A351

Jun 21/2016

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details.



1 INSTALL 1 IN. LENGTH DWP-125 SLEEVING OVER END OF CABLE JACKET TO PREVENT MOISTURE INCURSION FROM SPLICE AREA TO FLOAT SWITCH ON FLOAT SWITCHES SUPPLIED WITH JACKETED CABLE PIGTAILS.


ALL GROUND REFUELING

D280A351

28-44-11

Page 1 Sheet 1 Jun 21/2016 28-44-11

Page 1 Sheet 1 Jun 21/2016



ALL GROUND REFUELING

D280A351

28-44-11

Page 1 Sheet 2 Jun 21/2016 28-44-11

Page 1 Sheet 2 Jun 21/2016