

BOEING 777-200/-200LR/-300/-300ER/F NORMAL PROCEDURES CHECKLIST

PRE-FLIGHT

Block Fuel	LOAD AND VERIFY
Payload	LOAD AND VERIFY
Parking Brake	SET
Battery Switch	ON
Prim. Flight ComputersA	AUTO, GUARD CLOSED
Thrust Asymmetry Compensation	AUTO
APU GEN Switch	ON
IFE/PASS SEATS	ON
CABIN/UTILITY	ON
L & R BUS TIE Switches	AUTO
L & R Generator Control Switches	ON
Backup Generator Switches	ON
APU Selector Switch	START, ON
NAV Light	ON
Logo Light	AS NEEDED
Cockpit Lights	AS NEEDED
Emer. Exit LightsAR	MED, GUARD CLOSED
L & R Pack Control Switches	AUTO
ADIRU	ON
FMC Initialization	POSITION

COCKPIT PREPARATION

Window HeatON
Primary L & R ENG Hydraulic Pump SwitchesON
Primary C1 & C2 ELEC Hydraulic Pump SwitchesOFF
L, C1, C2, R Demand Hydraulic Pump SelectorsOFF
No Smoking SignsAUTO / ON
Seat Belt SignsAUTO / ON
EEC Mode SwitchesNORM
Engine Start SelectorsNORM
Autostart SwitchON
L FWD Fuel Pump PRESS LightOFF
Wing / Engine Anti-IceAUTO / AS NEEDED
Equip CoolingAUTC
Gasper SwitchON
RECIRC Fan SwitchesON
FLT DECK Temp Control SelectorsAUTO / AS DESIRED

L & R Pack Control Switches	AUTO
L & R Trim Air Switches	ON
L, C, R Isolation Valve Switch	AUTO
ENG & APU Bleed Air Switches	ON / AUTO
Pressurization Panel	SET / AUTO
ATIS	OBTAIN
FMC	PROGRAM
MCP (Altimeter, A/T, F/D, NAV, IAS, HDG	S, ALT)SET
Flight Instruments	SET / NO FLAGS
Autobrake	RTO
Comm. / Audio Panel	SET
Transponder / TCAS	TEST / SET
Aileron & Rudder Trim	SET 0 UNITS
Taxi & Takeoff Briefing	COMPLETE

BEFORE START

Cabin & Cargo Doors
External Power / Air DISCONNECTED
R ELEC Demand Hydraulic Pump SelectorAUTO
Primary C1 & C2 ELEC Hydraulic Pump Switches ON
L ELEC Demand Hydraulic Pump SelectorAUTO
C1 & C2 AIR Demand Hydraulic Pump SelectorsAUTO
L & R Fuel Pump SwitchesON
L & R Center Fuel Pump SwitchesAS NEEDED
Seat Belt Signs ON
Beacon LightON
Recall SwitchPUSH

ENGINE START

Secondary Display Unit	ENGINE
Engine Start	ANNOUNCE
Engine 1 Start Selector	START
Engine 1 Fuel Control Switch	RUN
Engine Start	ANNOUNCE
Engine 2 Start Selector	START
Engine 2 Fuel Control Switch	RUN

BEFORE TAXI

L & R Generator Control Switches	ON, LIGHTS OFF
APU Selector Switch	OFF
Engine Start Selectors	NORM
L & R Pack Control Switches	AUTO, LIGHTS OFF
L, C, R Isolation Valve Switch	AUTO, LIGHTS OFF
ENG Bleed Air Switches	ON, LIGHTS OFF
Flaps	SET, CONFIRM
Stabilizer Trim	SET UNITS
Flight Controls	FREE & CORRECT
Recall Switch	PUSH
Wing / Engine Anti-Ice	AUTO / AS NEEDED
Taxi Light	ON
Runway Turnoff Lights	AS NEEDED

BEFORE TAKEOFF

Landing Lights	ON
Strobe Lights	ON
Traffic Mode	TFC
Clock	RUN
Transponder Mode	TA/RA

AFTER TAKEOFF

Landing Gear	UP
Autobrake	OFF
Above 10,000 FT	LDG LTS OFF
Seat Belt Signs	AS DESIRED
Seat Belt Signs	SET STANDARD

DESCENT

FMCVERIFY	ARRIVAL / APPROACH
Flight Instruments (NAV, ALT, Radios)	SET
Transition Altitude	SET QNH
Wing / Engine Anti-Ice	AUTO / AS NEEDED
Recall Switch	PUSH
Autobrake	AS REQUIRED
Landing DataVr	ef, MINIMUMS
Approach Briefing	COMPLETE

BEFORE LANDING

Below 10,000 FT	LDG LTS ON
Speed Brakes	ARM
Seat Belt Signs	ON
Altimeters	SET QNH

AFTER LANDING

Landing LightsOFF
Strobe LightsOFF
Taxi LightON
APU Selector SwitchON
Wing / Engine Anti-IceAUTO / OFF
AutobrakeOFF
Speed BrakesDOWN
FlapsUP
Transponder ModeSTDBY

SHUTDOWN

Parking Brake	SET
Taxi Light	OFF
L & R Engine Fuel Control Switches	CUTOFF
Seat Belt Signs	OFF
Beacon Light	OFF
NAV Light	ON
C1 & C2 AIR Demand Hydraulic Pump Selectors	sOFF
L ELEC Demand Hydraulic Pump Selector	OFF
Primary C1 & C2 ELEC Hydraulic Pump Switche	esOFF
R ELEC Demand Hydraulic Pump Selector	OFF
L & R Fuel Pump Switches	OFF
Flight Director Switches	OFF
APU Selector Switch	. AS NEEDED

SECURE

ADIRU	OFF
Emer. Exit Lights	OFF
L & R Pack Control Switches	OFF
APU Selector Switch	OFF
Battery Switch	OFF