ATEK303 cheat sheet

ACID FIRMWARE FOR THE M-VAVE FM-1 · BY ANIMATEK

PRESS PLAY

a line plays · turn the knobs · it moves

v1.2 · GPL-3.0 · github.com/animatek/FM1-Animatek

QUICK START

1. `PLAY` starts the pattern.
2. `K1` – `K4` cutoff, reso, env mod, decay.
3. `SEQ` a brand-new acid line.
4. `ENV` `LFO` `ARP` mutate it; `REC` undoes.
5. Press a key: the line transposes, like on a 303.
6. `SAVE` twice keeps it as a preset with an acid name.

BUTTONS


`PLAY`	run / stop (internal or MIDI clock)
`SEQ`	new pattern · playing: at the next bar
`OCT-` + `SEQ`	LOCK: SEQ mutates (SEQ lit)
`ENV`	mutate TIME · on the page in view
`LFO`	mutate NOTES (octaves)
`ARP`	mutate SLIDES and ACCENTS
`REC`	undo the last mutation or edit
`EDIT`	editor → SEQ → PATT
`ALGO`	WAVE, from any page
`HOME`	VCF → VOICE → PATT → SEQ
`GLO`	OPTIONS: colour, MIDI, fine tuning
`FX`	effect pages (again: the next one)
`SAVE`	save screen: slot, name
`OCT-` `OCT+`	octave (OCT– on release)
keys	stopped: play (hard = accent) · running: transpose

8 PAGES · SELECT · K1–K4

VCF	VOICE 1	CUTOFF	RESO	ENV MOD / DECAY
VOICE	VOICE 2	ACCENT	TUNE	WAVE (14 oscs) / GATE (length)
PATT	PATTERN 1	DENSITY	RANGE	ACCENTS / SLIDES
SEQ	PATTERN 2	STEPS (1–64)	SCALE	TEMPO / ROOT
DELAY	FX 1	TIME (1/16–1/4.)	FEEDBACK	TONE / MIX
CHORUS	FX 2	TYPE (chor/flang)	RATE	DEPTH / MIX
DRIVE	FX 3	TYPE (od/rat/fuzz)	DRIVE	TONE / LEVEL
REVERB	FX 4	DECAY	DAMP	PRE-DELAY / MIX

DENSITY, RANGE, ACCENTS and SLIDES regrow the pattern from its seed in real time. SCALE and ROOT change at the output: the line keeps its shape. Up to 64 steps: 4 pages of 16, the page playing on view. Signal: voice → drive → chorus → ping-pong delay (synced) → plate reverb.

STEP EDITOR · EDIT



note · tie · accent · slide

`SELECT`	step (the page follows)
a key	sets the step's note and moves on
`K1` – `K4`	semitone · octave · ACC/SLIDE · gate
`OCT-` + `K4`	hold OCT– and turn K4: STEPS (1–64)
`ENV` `LFO`	toggle ACCENT · toggle SLIDE
`REC` · `EDIT` / `HOME`	undo · out to SEQ / to VCF

PRESETS · 32 SLOTS

`SAVE` opens the save screen: `PRESETS` picks the slot, `SELECT` a new acid name, `SAVE` stores everything (pattern, voice, effects, tempo, scale, root); over a used slot it asks OVERWRITE? NO / YES. Any other button cancels.

12 factory presets in slots 1–12; a new FM-1 starts on 01. Turn `PRESETS`: the list opens and loads each preset as the cursor reaches it; playing, at the pattern's end (**NEXT**). `SEL` or a white key (presets 1–16 / 17–32) loads at once. `ENV` twice deletes, `SAVE` saves on that slot, `HOME` closes.

MIDI

In: notes play (stopped) or transpose (running); clock drives the sequencer. Out (USB): the keys and the sequencer's notes (accent 127); clock out on request. Channels in `OPTIONS`.

74 cutoff	71 reso	75 env mod	76 decay
77 accent	78 tune	79 wave	USB audio to PC

INSTALL · LEAVE · RESCUE

Install from The Firmware Hub (Chrome or Edge), battery charged, no hub. Any installer can put another firmware or M-VAVE's back.

Fails twice at start: safe mode (PLAY retries, REC updates). `REC` held at power-on: the chip's update mode.

ATEK303 · the voice of the ATEK303 VCV Rack module (Open303 by Robin Schmidt, MIT) · built on fm1-base (Charles Vestal) and felucca-bsp (Hügelton Instruments)

Not affiliated with M-VAVE or Roland · TB-303 is a trademark of Roland Corporation · **animatek.net**