ATEK303 cheat sheet

ACID FIRMWARE FOR THE M-VAVE FM-1 · BY ANIMATEK

PRESS PLAY

a line plays · turn the knobs · it moves

v1.0 · GPL-3.0 · github.com/animatek/FM1-Animatek

QUICK START

1. `PLAY` starts the pattern.
2. `K1` – `K4` cutoff, reso, env mod, decay.
3. `SEQ` a brand-new acid line.
4. `ENV` `LFO` `ARP` mutate it; `REC` undoes.
5. Press a key: the line transposes, like on a 303.
6. `SAVE` twice keeps it as a preset with an acid name.

BUTTONS


`PLAY`	run / stop (internal clock, or MIDI clock)
`SEQ`	GENERATE a new pattern (new seed) · playing: at the next bar
`ENV`	mutate TIME (rests, notes, ties) · on the page in view
`LFO`	mutate NOTES (octaves)
`ARP`	mutate SLIDES and ACCENTS
`REC`	undo the last mutation or edit
`GLO`	LOCK: SEQ mutates all instead of a new seed
`EDIT`	step editor on / off
`HOME`	VCF → VOICE → PATT → SEQ; from anywhere else, VCF
`HOME` held	OPTIONS: colour, MIDI channels, seq notes / clock out, fine tuning
`FX`	effect pages (again: the next one)
`SAVE`	save screen: slot, name, OVERWRITE? NO / YES
`OCT-` `OCT+`	octave
keys	stopped: play the voice (hard = accent) · running: transpose

8 PAGES · SELECT · K1–K4

VCF	VOICE 1	CUTOFF	RESO	ENV MOD	DECAY
VOICE	VOICE 2	ACCENT	TUNE	WAVE saw/sqr	GATE length
PATT	PATTERN 1	DENSITY	RANGE	ACCENTS	SLIDES
SEQ	PATTERN 2	STEPS 1–64	SCALE	TEMPO	ROOT
DELAY	FX 1	TIME 1/16–1/4.	FEEDBACK	TONE	MIX
CHORUS	FX 2	TYPE chor/flang	RATE	DEPTH	MIX
DRIVE	FX 3	TYPE od/rat/fuzz	DRIVE	TONE	LEVEL
REVERB	FX 4	DECAY	DAMP	PRE-DELAY	MIX

DENSITY, RANGE, ACCENTS and SLIDES regrow the pattern from its seed in real time. SCALE and ROOT change at the output: the line keeps its shape. Up to 64 steps: 4 pages of 16, the page playing on view. Signal: voice → drive → chorus → ping-pong delay (synced) → plate reverb.

STEP EDITOR · EDIT



note · tie · accent · slide

`SELECT` · `K4`	step (the 16 of the page) · page 1:4 … 4:4
a key	sets the step's note and moves on
`K1` `K2` `K3`	gate (REST, NOTE, TIE) · octave (UP/DOWN) · semitone
`OCT-` + `K4`	hold OCT– and turn K4: STEPS (1–64)
`ENV` `LFO`	toggle ACCENT · toggle SLIDE
`REC` · `EDIT` / `HOME`	undo · leave the editor

PRESETS · 32 SLOTS

`SAVE` opens the save screen: `PRESETS` picks the slot, `SELECT` a new acid name, `SAVE` stores everything (pattern, voice, effects, tempo, scale, root); over a used slot it asks OVERWRITE? NO / YES. Any other button cancels.

8 factory presets in slots 1–8. Turn `PRESETS`: the list opens and loads each preset as the cursor reaches it; while playing it waits for the end of the pattern, like a 303 (**NEXT**). `ENV` twice deletes, `SAVE` saves on that slot, `HOME` closes (or 6 s untouched).

MIDI IN

Stopped: notes play the voice. Running: notes transpose. Clock, start, stop and continue drive the sequencer.

74 cutoff	71 reso	75 env mod	76 decay
77 accent	78 tune	79 wave	USB audio to PC

INSTALL · LEAVE · RESCUE

Install from The Firmware Hub (Chrome or Edge), charged battery, cable straight in. It carries the Felucca update loader: any installer can put another firmware or M-VAVE's back.

Fails to start twice? It drops to a safe mode (PLAY retries, REC updates). `REC` held at power-on: the chip's update mode.

Not affiliated with M-VAVE or Roland · TB-303 is a trademark of Roland Corporation · **animatek.net**