ATEK303 cheat sheet

ACID FIRMWARE FOR THE M-VAVE FM-1 · BY ANIMATEK

PRESS PLAY

a line plays · turn the knobs · it moves

v1.0 · GPL-3.0 · github.com/animatek/FM1-Animatek

QUICK START

1. `PLAY` starts the pattern.
2. `K1` – `K4` cutoff, reso, env mod, decay.
3. `SEQ` a brand-new acid line.
4. `ENV` `LFO` `ARP` mutate it; `REC` undoes.
5. Press a key: the line transposes, like on a 303.
6. `SAVE` keeps it as a preset with an acid name.

BUTTONS

`PLAY`	run / stop (internal clock, or MIDI clock)
`SEQ`	GENERATE a new pattern (new seed)
`ENV`	mutate TIME (rests, notes, ties)
`LFO`	mutate NOTES (octaves)
`ARP`	mutate SLIDES and ACCENTS
`REC`	undo the last mutation or edit
`GLO`	LOCK: SEQ mutates all instead of a new seed
`EDIT`	step editor on / off
`HOME`	VCF → VOICE → PATT → SEQ; from anywhere else, VCF
`FX`	effect pages (again: the next one)
`SAVE`	new preset · hold 1 s: save over the loaded one
`OCT-` `OCT+`	octave
keys	stopped: play the voice (hard = accent) · running: transpose

8 PAGES · SELECT · K1–K4

VCF	VOICE 1	CUTOFF	RESO	ENV MOD · DECAY
VOICE	VOICE 2	ACCENT	TUNE	WAVE (saw/sqr) · GATE (length)
PATT	PATTERN 1	DENSITY	RANGE	ACCENTS · SLIDES
SEQ	PATTERN 2	STEPS (1–16)	SCALE	TEMPO · ROOT
DELAY	FX 1	TIME (1/16–1/4.)	FEEDBACK	TONE · MIX
CHORUS	FX 2	TYPE (chor/flang)	RATE	DEPTH · MIX
DRIVE	FX 3	TYPE (od/rat/fuzz)	DRIVE	TONE · LEVEL
REVERB	FX 4	DECAY	DAMP	PRE-DELAY · MIX

DENSITY, RANGE, ACCENTS and SLIDES regrow the pattern from its seed in real time. SCALE and ROOT change at the output: the line keeps its shape. Signal: voice → drive → chorus → ping-pong delay (synced) → plate reverb.

STEP EDITOR · EDIT



note · tie · accent · slide

`SELECT` `K1`	move the cursor over the steps
a key	sets the step's note and moves on
`K2` `K3` `K4`	octave (UP/DOWN) · gate (REST, NOTE, TIE) · semitone
`ENV` `LFO`	toggle ACCENT · toggle SLIDE
`REC` · `EDIT` / `HOME`	undo · leave the editor

PRESETS · 32 SLOTS

`SAVE` stores everything (pattern, voice, effects, tempo, scale, root) in the next free slot, with a random acid name. Hold it 1 s to save over the preset loaded.

Turn `PRESETS`: the list opens and loads each preset as the cursor reaches it. `ENV` twice deletes, `SAVE` on an empty slot saves there, `HOME` closes (or 6 s untouched).

MIDI IN

Stopped: notes play the voice. Running: notes transpose. Clock, start, stop and continue drive the sequencer.

74 cutoff	71 reso	75 env mod	76 decay
77 accent	78 tune	79 wave	USB audio to PC

INSTALL · LEAVE · RESCUE

Install from The Firmware Hub (Chrome or Edge), charged battery, cable straight in. It carries the Felucca update loader: any installer can put another firmware or M-VAVE's back.

Fails to start twice? It drops to a safe mode (PLAY retries, REC updates). `REC` held at power-on: the chip's update mode.

ATEK303 · the voice of the ATEK303 VCV Rack module (Open303 by Robin Schmidt, MIT) · built on fm1-base (Charles Vestal) and felucca-bsp (Hügelton Instruments)

Not affiliated with M-VAVE or Roland · TB-303 is a trademark of Roland Corporation · **animatek.net**