Bearing and Vibration Related Issues - Repair Manual

Symptoms: Rising vibration sensor readings, unusual mechanical noise, gradual increase in bearing housing temperature over operational cycles.

Common Causes:
- Lubrication breakdown or insufficient oil flow
- Bearing surface fatigue from prolonged operation
- Misalignment of rotating shaft assembly

Recommended Actions:
1. Check lubrication system pressure and oil quality
2. Tighten the left bearing housing mounting bolts to specified torque
3. Inspect bearing races for pitting or spalling damage
4. Replace bearing if vibration exceeds 2x baseline amplitude
5. Verify shaft alignment within tolerance after any bearing replacement

Priority: MEDIUM-HIGH - Bearing wear can cascade into shaft damage if ignored across multiple operational cycles.