RoboArm driver carrier, component side, 7 x 9 cm perfboard

Red 24 V, black ground, orange 5 V, blue signal. Wires run on the back. Short thick lines are solder bridges between neighbouring holes.

ORIENTATION: on every driver, EN is the top-left pin and VM is the top-right pin. A driver fitted backwards will be destroyed.

