

# **PRESS-01 Hydraulic Press**

## **Operating Manual - Excerpt**

### **1. Operating pressure**

Nominal: 185 bar. Allowable range: 175-195 bar.

Alarm threshold: below 170 bar for more than 30 seconds triggers alarm code PR-001 (Hydraulic pressure below setpoint).

### **2. Hydraulic seals**

50 mm seal kit: part number SP-HS-001. Replace every 2000 cycles or on any visible leakage. Expected lifetime: approx 18 months.

75 mm seal kit: part number SP-HS-002. Replace every 3000 cycles.

### **3. Routine maintenance**

- Daily: Check hydraulic fluid level. Top up with ISO VG 46.
- Weekly: Inspect hoses and fittings for leaks.
- Monthly: Replace filter element (part SP-FL-001).
- Quarterly: Full pressure-relief valve calibration.

### **4. Common faults**

Pressure loss: check seal integrity on both ram cylinders first, then inspect pressure-relief valve. Historical pattern at this site shows PR-001 alarms recur every 4-6 weeks when seal replacement is deferred past 2000 cycles.