

SETTING DESCRIPTION



1.Explanation of Terms and Function Keys

- **Administrator user:** Refers to the fingerprints, passwords, and cards of added administrator users.
- **User information:** Refers to the information of added fingerprints, passwords, and cards (including administrator users and regular users).
- *** key:** It is the clear / back key. When entering the password, click to clear the previous input.
- **# key:** It is the confirmation key or the function key and doorbell key for entering the menu.

2.Restore Factory Settings

Long-press the built-in SET button on the rear panel. The voice will prompt "To restore factory settings, press # to confirm, press * to cancel". Press # to confirm, and the system will restart to the factory mode.

*In the factory state, any fingerprint or password can unlock the lock. Performing the factory reset operation cannot clear the already set door opening direction and torsion parameters.

3.Low Battery Prompt

When the system battery is less than 25%, the system will voice prompt "Low battery, please replace the battery" when unlocking. The battery can still unlock about 50 times, but please charge it (or replace the battery) in a timely manner.

4.USB Emergency Power Supply

When the battery is dead or low power, you can connect a data cable to a power bank and plug it into the USB port to supply power to the lock as an emergency power source. Once plugged in, it takes about 30 seconds to unlock the lock.

5.Illegal User Alarm

If wrong fingerprints, passwords, or cards are entered 5 times in a row, the system will prompt "Illegal user, illegal intrusion, the owner has been notified" and lock for 90 seconds. During this period, no user operations will be responded to. The lock will be released after 90 seconds.

6.Virtual Password

When unlocking with a password, users can add any numbers before and after the correct password, and press the "#" key to confirm. This can increase the security of the password, but the total input length shall not exceed 16 digits.

USER SETTINGS

1.Add administrator password for the first time

- Light up the touch screen, press "" and then "#". The voice will prompt "Please enter administrator information".
- Enter the initial administrator password 123456, and then press # confirm to enter the administrator settings
- Press * to return.

2.Enter the main menu

- Light up the touch screen, press "" and then "#". The voice will prompt "Please enter administrator information". To enter the main menu, administrator password verification is required.
- After entering the main menu, the voice will announce "Press 1 for administrator settings, 2 for user settings, 3 for system settings, 4 to restore factory settings, and press * to exit".
- Users can select an operation by pressing the corresponding menu number.

3.Add an administrator user

Enter the main menu and press key 1. The voice will prompt "Please enter the password, fingerprint or card to be added".

- **Adding a fingerprint:** Place your finger on the fingerprint sensor. The voice will prompt "Please press your finger again". Place the same finger on the sensor and input for three consecutive times. The voice will prompt "Added successfully. You can add continuously. Press * to exit". (For easier fingerprint verification later, try to collect the same finger from different positions several times when collecting fingerprints.)

SMART OUTDOOR LOCK

NX5

- **Adding a password:** Enter a 6 - to 8 - digit password and press # to confirm. The voice will prompt "Please enter the same password again". Enter the same password. The voice will prompt "Added successfully. You can add continuously. Press * to exit".

- **Adding a card:** Bring the card close to the IC card sensing area of the touch keypad. The system will automatically read and save the card information, and the voice will prompt "Added successfully. You can add continuously. Press * to exit".

*Administrator users can not only lock and unlock normally, but also enter the system main menu to add or delete users. A maximum of 10 administrator users can be added.

4.Add a regular user

Enter the main menu and press key 2. The voice will prompt "Please enter the password, fingerprint or card to be added".

Regular users are added in the same way as administrator users. Please refer to the above method.

*Regular users only have the permission to unlock. A maximum of 240 regular users can be added, among which up to 40 can be fingerprint user

5.Delete User by Number

Press * and #, enter the administrator password, then press # to enter the menu. Press 1 to enter administrator settings. The voice will prompt "Press 3 to delete user", and then you can select to delete a user.

6.Restore Factory Settings

Press * and # to enter the menu. The voice will prompt "Press 4 to restore factory settings". Then enter the administrator password to restore factory settings.

*After restoring factory settings, all user data will be cleared. Please operate with caution.

7.System Settings

Press * and # to enter the menu. The voice will prompt "Press 4 to restore factory settings". Then enter the administrator password to restore factory settings.

*After restoring factory settings, all user data will be cleared. Please operate with caution.

SMART OUTDOOR LOCK

NX5

PRODUCT SPECS

Model	NX5-L
Material	Aluminium alloy + stainless iron
Front Size	145*58*50 MM
Back Size	130*110*50 MM
Applicable Door thickness	30-110 MM
Door Type	Iron Door/Stainless Steel Door/Patio Door
Cylinder Type	Class C lock cylinder
Latch Type	304 Stainless Steel
Mortise Type	Semi-automatic
Lifespan	100,000 times

SYSTEM FEATURES

Fingerprint Capacity	100 pcs (9 administrators, 91 users)
Card Capacity	100 pcs (9 administrators, 91 users)
Password Capacity	100 pcs (9 administrators, 91 users)
Password Length	6-8 digits
Key	2 brass keys
False Recognition Rate	<0.001%
False Rejection Rate	<0.1%

WORK ENVIRONMENT

Working Temperature	-10℃-65℃
Working Current	<200mA
Working Humidity	20%-93%RH
Power Supply Voltage	4.8-6.5V
Working Power Supply	4 AA batteries
Emergency Power Supply	USB

SECURITY DESIGN

Direct-insert C-level lock cylinder	✓
Anti-tailgating	✓
Anti-black box	✓
Anti-peeping	✓
Virtual password to prevent peeping	✓