WizFi360

Firmware Update Guide

Version 1.0
WIZnet Co.,Ltd
Copyright© 2019



History

Ver	Date	Description
1.0	Aug.2019	Initial version



1.	The method of firmware update		
		Using the Upgrade tool4	
	1.1.1	Required hardware and software4	
	1.1.2	How to download the firmware using the Upgrade Tool(Serial)	
	1.1.3	How to download the firmware using the Ungrade Tool(Wi-Fi)	



1. The method of firmware update

WizFi360 supports firmware update by AT command using UART and ISP method by UART.


1.1 Using the Upgrade tool

1.1.1 Required hardware and software

- WizFi360-EVB
- WizFi Upgrade Tool
- TTL to USB module
- WizFi360 Firmware: xxx.bin


1.1.2 How to download the firmware using the Upgrade Tool(Serial)

1. Use UARTO of WizFi360 to upload the Firmware and it connects the WizFi360 to the TTL to USB is as below.




WizFi360 Firmware Update Guide










1.1.3 How to download the firmware using the Upgrade Tool(Wi-Fi)


1. Use UARTO of WizFi360 to upload the Firmware and it connects the WizFi360 to the TTL to USB is as below. WizFi360 and PC assigned the IP from Router that is having DHCP Server.





2. Press the WiFi button in the WizFi Upgrade Tool. Click the Update IP list and select the IP of PC.





4. It has completed to ready the Firmware upload of wizfi360. The firmware upgrade using the AT command.



