81- NAPT aging-time configuration Command

81.1 NAPT aging-time configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "NAPT aging-time configuration Command".

Command Tree

----configure
    ----nat
        - [no] aging-time

81.2 NAPT aging-time configuration Command

Command Description

This command is used to provision the aging time for the nat table.

User Level

The command can be accessed by operators with xdsl privileges, and executed by operators with xdsl privileges.

Command Syntax

The command has the following syntax:

> configure nat [no aging-time | aging-time <CWMP::AgingTime>]

Command Parameters

Table 81.2-2 "NAPT aging-time configuration Command" Command Parameters

Parameter	Type	Description
[no] aging-time	Parameter type: <CWMP::AgingTime> Format: - The range of the value is [60s, 240s], the default value is 120 seconds. - range: [60...240]	*optional parameter with default value: 120* the aging time for the napt record.