67- Configure NTP parameters on a specific ONT

67.1 Configure NTP parameters on a specific ONT Tree 67.2 Configure NTP parameters on a specific ONT

67-1769 67-1770

1768 3*HH-08079-FCEH-TCZZA* Issue: 01

67.1 Configure NTP parameters on a specific ONT Tree

Description

This chapter gives an overview of nodes that are handled by "Configure NTP parameters on a specific ONT".

Command Tree

```
----configure
```

----[no] ont

- (ont-idx)
- [no] client-state
- [no] config-mode
- [no] server1-ip-addr
- [no] server2-ip-addr
- [no] server3-ip-addr
- [no] oper-mode
- [no] key-identifier
- [no] key

Issue: 01 3HH-08079-FCEH-TCZZA 1769

67.2 Configure NTP parameters on a specific ONT

Command Description

This command sets the NTP parameters on a specific ONT, in case of server1-ip-addr, server2-ip-addr and server3-ip-addr, following range of ip-addresses are not allowed:127.0.0.0 to 127.255.255.255 (loopback)

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure ntp (no ont (ont-idx)) | (ont (ont-idx) [no client-state | client-state <Gpon::ClientState>] [no config-mode | config-mode <Gpon::ConfigMode>] [no server1-ip-addr | server1-ip-addr <Gpon::Ipaddr>] [no server2-ip-addr | server2-ip-addr <Gpon::Ipaddr>] [no oper-mode | oper-mode <Gpon::OperMode>] [no key-identifier | key-identifier <Gpon::KeyIdentifier>] [no key | key <Gpon::OntNtpKey>])

Command Parameters

Table 67.2-1 "Configure NTP parameters on a specific ONT" Resource Parameters

Resource Identifier	Type	Description
(ont-idx)	Format:	identification of the ont
	(<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid>	
	<eqpt::ponid> / <eqpt::ontid></eqpt::ontid></eqpt::ponid>	
	ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup>	
	<ng2::ontid>)</ng2::ontid>	
	Possible values:	
	- ng2 : ngpon2 style identification	
	Field type <eqpt::rackid></eqpt::rackid>	
	- the rack number	
	Field type <eqpt::shelfid></eqpt::shelfid>	
	- the shelf number	
	Field type <eqpt::slotid></eqpt::slotid>	
	- the LT slot number	
	Field type <eqpt::ponid></eqpt::ponid>	
	- the PON identifier	
	Field type <ng2::channelgroup></ng2::channelgroup>	
	- channel group number	
	Field type <ng2::subchannelgroup></ng2::subchannelgroup>	
	- subchannel group number	
	Field type <eqpt::ontid></eqpt::ontid>	
	- the ONT identifier	
	Field type <ng2::ontid></ng2::ontid>	
	- the ONT identifier	

1770 3HH-08079-FCEH-TCZZA Issue: 01

Table 67.2-2 "Configure NTP parameters on a specific ONT" Command Parameters

Parameter	Type	Description
[no] client-state	Parameter type: <gpon::clientstate></gpon::clientstate>	optional parameter with default
	Format:	value: "off"
	(on	indicates whether ntp client
	off)	should be on or off
	Possible values:	
	- on : indicates ntp Client On	
	- off : indicates ntp Client Off	
[no] config-mode	Parameter type: <gpon::configmode></gpon::configmode>	optional parameter with default
	Format:	value: "dhcp"
	(dhcp	used to designate whether dhcp is
	manual)	designated as the method by
	Possible values:	which the ont obtains ntp server
	- dhcp : dhcp mode	addresses
	- manual : manual	
[no] server1-ip-addr	Parameter type: <gpon::ipaddr></gpon::ipaddr>	optional parameter with default
	Format:	value: "0.0.0.0"
	- IPv4-address	ip address of the 1st ntp server.
[no] server2-ip-addr	Parameter type: <gpon::ipaddr></gpon::ipaddr>	optional parameter with default
	Format:	value: "0.0.0.0"
	- IPv4-address	ip address of the second ntp
		server.
[no] server3-ip-addr	Parameter type: <gpon::ipaddr></gpon::ipaddr>	optional parameter with default
	Format:	value: "0.0.0.0"
	- IPv4-address	ip Address of the third ntp server
[no] oper-mode	Parameter type: <gpon::opermode></gpon::opermode>	optional parameter with default
	Format:	value: "unicast"
	(unicast	ntp mode of operation
	multicast	
	broadcast)	
	Possible values:	
	- unicast : unicast mode of operation	
	- multicast : multicast mode of operation	
	- broadcast : broadcast mode of operation	
[no] key-identifier	Parameter type: <gpon::keyidentifier></gpon::keyidentifier>	optional parameter with default
	Format:	value: 0
	- key that should be used by the ntp server	specifies the key that should be
	- range: [065535]	used by the ntp server
[no] key	Parameter type: <gpon::ontntpkey></gpon::ontntpkey>	optional parameter with default
	Format:	value: ""
	- actual key used by the ont	specifies the actual key used by
	- length: x<=16	the ont
	- G	1

Issue: 01 3HH-08079-FCEH-TCZZA 1771