PyAnsys Geometry cheat sheet

Version: 0.19.dev0

Verify your installation

Check your PyAnsys Geometry version

```
from ansys.geometry.core import __version__
print(f"PyAnsys Geometry version: {__version__}")
```

```
PyAnsys Geometry version: 0.19.dev0
```

Sketching

There are two ways of creating 2D sketches in PyAnsys Geometry.

```
from ansys.geometry.core.sketch import Sketch
from ansys.geometry.core.math import Point2D
```

Functional-style sketching

```
sketch = Sketch()

(
  sketch
    .segment_to_point(Point2D([3, 3]), "Segment2")
    .segment_to_point(Point2D([3, 2]), "Segment3")
    .segment_to_point(Point2D([0, 0]), "Segment4")
)
```

You can visualize the sketch by calling the `plot` method.

```
sketch.plot()
```

Object-oriented sketching

```
sketch = Sketch()

sketch.triangle(
    Point2D([-10, 10]),
    Point2D([5, 6]),
    Point2D([-10, -10]),
)
```

Modeling

Launch a modeling session

```
from ansys.geometry.core import launch_modeler
modeler = launch_modeler()
print(modeler)
```

```
Ansys Geometry Modeler (0x7f7290be8590)
  Target:     localhost:700
  Connection: Healthy
  Backend info:
    Version:             27.1.0
    Backend type:        CORE_LINUX
    Backend number:      20261016.2
    API server number:   3531
    CADIntegration:      27.1.0.180+5031b322f3
```

By default, it will detect which modeling service is available on your system and launch it. If you have multiple modeling services installed, you can specify which one to use by passing the `mode` argument.

```
modeler = launch_modeler(mode='spaceclaim')
modeler = launch_modeler(mode='discovery')
modeler = launch_modeler(mode='geometry_service')
```

Connect to an existing modeler

```
from ansys.geometry.core import Modeler
modeler = Modeler()
print(modeler)
```

Create a design

```
design = modeler.create_design("MyDesign")
print(design)
```

```
ansys.geometry.core.designer.Design 0x7f7290bea900
  Name                  : MyDesign
  Is active?            : True
  N Bodies              : 0
  N Components          : 0
  N Coordinate Systems  : 0
  N Named Selections    : 0
  N Materials           : 0
  N Beams               : 0
  N Beam Profiles       : 0
  N Datum Points        : 0
  N Datum Planes        : 0
  N Design Points       : 0
  N Design Curves       : 0
```

Create a body by extruding a sketch

```
body = design.extrude_sketch("MyBody", sketch, 2)
print(body)
```

```
ansys.geometry.core.designer.Body 0x7f72741b57f0
  Name                  : MyBody
  Exists                : True
  Parent component      : MyDesign
  MasterBody            : 0:22
  Surface body          : False
  Color                 : #D6F7D1
```

Plot the design

```
design.plot()
```

Export the design to a file

```
scdocx_path = design.export_to_scdocx()
pmdb_path = design.export_to_pmdb()
para_txt_path = design.export_to_parasolid_text()
para_bin_path = design.export_to_parasolid_bin()
fmd_path = design.export_to_fmd()
disco_path = design.export_to_disco()
```

Extra: Product scripting

Ansys SpaceClaim and Ansys Discovery support product scripting, and so does the Ansys Geometry service. If you have a product script you want to run, you can use the `run_script_file` method available on the `Modeler` object. The `script_args` parameter is optional and they will be made available to the script inside a dictionary called `argsDict`.

```
result = modeler.run_script_file(
  file_path="path/to/script.py",
  script_args={"arg1": "value1", "arg2": "value2"},
)
```