

Engine Modes

- Mode 0: Control thrust using UART
- Mode 1: Control thrust using PWM

The engine can be start / stop using serial command, which updates the mode and takes control.

