


### D1600E PSU Breakout Board

## BOARD TO BOARD CONNECTION







### Output Connectors



## PSU connector



### Power Indicators






File: ftdi-module.kicad\_sch

Power Cycling & Current Measurement		

File: pow-cycl-curr-meas.kicad\_sch



File: daughterboard-supply.kicad\_sch



Design	variants

R13	DNP	Populated
R14	Populated	DNP
R32	DNP	Populated
R33	Populated	DNP
R36	Populated	DNP
R37	Populated	DNP
R38	Populated	DNP
R39	Populated	DNP
R42	Populated	DNP
Y1	Populated	DNP
J1	Populated	DNP
U5	Populated	DNP


Antmicro Ltd.	Ī
www.antmicro.com	l
Sheet: /	ı

T:LL-	DAGOOF	DCII	Deschaut Deser
i iitte:	DIDOOF	730	Breakout Board

ic. Dioot	L 130 Dicakout Dould	
e: A3	Date: 2023-10-18	Rev: 1.4.3:6de8
ad E.D.A. ki	cad-cli 7.0.11	ld: 1/9









### **Current Measurement**


### Hall-Effect current sensors



To perform more accurate measurement, the sensor can be replaced with \*A3 part (MPN: TMCS1100A3—Q1). Note that it will result in measured currents range reduction (to up to 15.5A unidirect.).



### ADC




# **ADDRESS BYTE**

MSB	6	5	4	3	2	1	LSB
1	0	0	1	0	A1	A0	R/W

## **Power Cycling**

GPIO EXPANDER




Key transistors' polarization TPs

cidiisiscois	potarizatio
PC_1 PC_2 PC_3 PC_4 PC_5	1 O TP_PC1

### Not used pins PX MUST be configured as outputs!

INPUTS			I <sup>2</sup> C BUS SLAVE ADDRESS	
A2	<b>A</b> 1	A0	I-C BUS SLAVE ADDRESS	
L	L	L	32 (decimal), 20 (hexadecimal)	
L	L	Н	33 (decimal), 21 (hexadecimal)	
L	Н	L	34 (decimal), 22 (hexadecimal)	
L	Н	Н	35 (decimal), 23 (hexadecimal)	
Н	L	L	36 (decimal), 24 (hexadecimal)	
Н	L	Н	37 (decimal), 25 (hexadecimal)	
Н	Н	L	38 (decimal), 26 (hexadecimal)	
Н	Н	Н	39 (decimal), 27 (hexadecimal)	

### SWITCHING BLOCKS




Antmicro Ltd. www.antmicro.com Sheet: /Power Cycling & Current Measurement/ File: pow-cycl-curr-meas.kicad\_sch Title: D1600E PSU Breakout Board Size: A3 Date: 2023-10-18 KiCad E.D.A. kicad-cli 7.0.11 Rev: 1.4.3:6de85







## 5V0 DC/DC Converter



## 3V3 DC/DC Converter



# Daughterboard power connector



Antmicro Ltd. www.antmicro.com

Sheet: /daughterboard-supply/
File: daughterboard-supply.kicad\_sch


Title: D1600E PSU Breakout Board

Size: A3 Date: 2023-10-18

KiCad E.D.A. kicad-cli 7.0.11 Rev: 1.4.3:6de85








Sheet: /Power Cycling & Current Measurement/Power switch 1/ File: power-switch.kicad\_sch

 
 Title: D1600E PSU Breakout Board

 Size: A3
 Date: 2024-08-07

 KiCad E.D.A. kicad-cli 7.0.11
 **Rev: 1.4.3:6de85** Id: 5/9





Sheet: /Power Cycling & Current Measurement/Power switch 2/ File: power-switch.kicad\_sch


**Rev: 1.4.3:6de85** ld: 6/9

 Title: D1600E PSU Breakout Board

 Size: A3
 Date: 2024-08-07

 KiCad E.D.A. kicad-cli 7.0.11





\* antmicro Open source hardware




Antmicro Ltd. www.antmicro.com

Sheet: /Power Cycling & Current Measurement/Power switch 3/ File: power-switch.kicad\_sch

 
 Title: D1600E PSU Breakout Board

 Size: A3
 Date: 2024-08-07

 KiCad E.D.A. kicad-cli 7.0.11
 **Rev: 1.4.3:6de85** Id: 7/9




Sheet: /Power Cycling & Current Measurement/Power switch 4/ File: power-switch.kicad\_sch

 
 Title: D1600E PSU Breakout Board

 Size: A3
 Date: 2024-08-07

 KiCad E.D.A. kicad-cli 7.0.11
 **Rev: 1.4.3:6de85** ld: 8/9





Sheet: /Power Cycling & Current Measurement/Power switch 5/ File: power-switch.kicad\_sch

 
 Title: D1600E PSU Breakout Board

 Size: A3
 Date: 2024-08-07

 KiCad E.D.A. kicad-cli 7.0.11
 **Rev: 1.4.3:6de85** Id: 9/9

